

---

# Virtuoso Power Manager Guide

Product Version IC23.1  
June 2023

© 2023 Cadence Design Systems, Inc.

Printed in the United States of America.

Cadence Design Systems, Inc. (Cadence), 2655 Seely Ave., San Jose, CA 95134, USA.

Open SystemC, Open SystemC Initiative, OSCI, SystemC, and SystemC Initiative are trademarks or registered trademarks of Open SystemC Initiative, Inc. in the United States and other countries and are used with permission.

**Trademarks:** Trademarks and service marks of Cadence Design Systems, Inc. contained in this document are attributed to Cadence with the appropriate symbol. For queries regarding Cadence's trademarks, contact the corporate legal department at the address shown above or call 800.862.4522. All other trademarks are the property of their respective holders.

**Restricted Permission:** This publication is protected by copyright law and international treaties and contains trade secrets and proprietary information owned by Cadence. Unauthorized reproduction or distribution of this publication, or any portion of it, may result in civil and criminal penalties. Except as specified in this permission statement, this publication may not be copied, reproduced, modified, published, uploaded, posted, transmitted, or distributed in any way, without prior written permission from Cadence. Unless otherwise agreed to by Cadence in writing, this statement grants Cadence customers permission to print one (1) hard copy of this publication subject to the following conditions:

1. The publication may be used only in accordance with a written agreement between Cadence and its customer.
2. The publication may not be modified in any way.
3. Any authorized copy of the publication or portion thereof must include all original copyright, trademark, and other proprietary notices and this permission statement.
4. The information contained in this document cannot be used in the development of like products or software, whether for internal or external use, and shall not be used for the benefit of any other party, whether or not for consideration.

**Disclaimer:** Information in this publication is subject to change without notice and does not represent a commitment on the part of Cadence. Except as may be explicitly set forth in such agreement, Cadence does not make, and expressly disclaims, any representations or warranties as to the completeness, accuracy or usefulness of the information contained in this document. Cadence does not warrant that use of such information will not infringe any third party rights, nor does Cadence assume any liability for damages or costs of any kind that may result from use of such information.

Cadence is committed to using respectful language in our code and communications. We are also active in the removal and replacement of inappropriate language from existing content. This product documentation may however contain material that is no longer considered appropriate but still reflects long-standing industry terminology. Such content will be addressed at a time when the related software can be updated without end-user impact.

**Restricted Rights:** Use, duplication, or disclosure by the Government is subject to restrictions as set forth in FAR52.227-14 and DFAR252.227-7013 et seq. or its successor

---

# Contents

---

## 1

<u>Virtuoso Power Manager</u> .....	9
<u>Licensing Requirements of Virtuoso Power Manager</u> .....	12
<u>Power Manager Toolbar</u> .....	13

## 2

<u>Virtuoso Power Manager Flow</u> .....	15
<u>Basic Flow in Power Manager</u> .....	16
<u>Recommended Use Model for Power Intent Creation and Verification</u> .....	17
<u>Power Intent of Large Designs</u> .....	18

## 3

<u>Setup for Automatic Extraction of Power Intent</u> .....	21
<u>Registering Name-Based Supply Nets</u> .....	23
<u>Registering Regular Expressions-Based Supply Nets</u> .....	26
<u>Supply NetSet Properties Prefix Registration</u> .....	28
<u>Excluding Power and Ground Nets from Name-Based Registration</u> .....	30
<u>Registering Monitor Nets</u> .....	32
<u>User-Defined Macros Registration</u> .....	33
<u>Registering Libraries</u> .....	34
<u>Special Cell and Standard Cell Modeling</u> .....	35
<u>Design Sub-Block Modeling During Top-Level 1801 Design Model Extraction</u> .....	38
<u>Reference Libraries or Cells</u> .....	39
<u>MLDB Libraries</u> .....	39
<u>Registering Device and Cell</u> .....	40
<u>Passive Devices</u> .....	43
<u>Resistors as Short Devices</u> .....	43
<u>Connectors</u> .....	44

# Virtuoso Power Manager User Guide

---

<u>Backtrace Enable Signals of Special Cells</u> .....	48
<u>Single Rail Cells</u> .....	50
<u>Stack Transistors</u> .....	52
<u>Terminal Name Registration for Devices</u> .....	55
<u>Performing In-Design Checks</u> .....	56
<u>Voltage Tolerance</u> .....	59
<u>Setting Supply States</u> .....	61
<u>Registering Supply Set and Power Domain</u> .....	65
<u>Registering Port Attributes</u> .....	68
<u>Miscellaneous Settings</u> .....	71
<u>Setup File Template</u> .....	75
<u>Loading Power Intent Extraction Options from a File</u> .....	82
<u>Saving Power Intent Extraction Options to a File</u> .....	83

## 4

<u>Power Intent Import</u> .....	85
<u>Import Flow</u> .....	85
<u>Importing Power Intent</u> .....	88
<u>Redirected netSet Property Creation and Optimization</u> .....	91
<u>Tie Connection Resolution</u> .....	93
<u>Handling of Low Power Special Cells</u> .....	98
<u>Support of Hierarchical 1801 for Import Flow</u> .....	100
<u>Honoring Command Sequence and Precedence</u> .....	101
<u>Removing Imported Power Intent</u> .....	102

## 5

<u>Running In-Design Checks</u> .....	105
<u>Defining the Severity of Design Checks</u> .....	107
<u>Level Shifter Checks</u> .....	108
<u>Isolation Checks</u> .....	121
<u>Bulk Checks</u> .....	123
<u>Checking a Design in Foreground Mode</u> .....	125
<u>Checking a Design in Background Mode</u> .....	127
<u>Loading the Violations Database</u> .....	132
<u>Filtering Violations</u> .....	138

# Virtuoso Power Manager User Guide

---

<u>Generating Signal Information</u> .....	139
--	-----

## 6

<u>Exporting Power Intent of a Design</u> .....	141
---	-----

<u>Export Flow</u> .....	142
--------------------------	-----

<u>Extracting the Power Intent from a Design</u> .....	143
--	-----

<u>Identification of Design Objects</u> .....	144
---	-----

<u>Design Partitioning</u> .....	145
----------------------------------	-----

<u>Creation of Power Domains</u> .....	153
--	-----

<u>Default Power Domain</u> .....	156
-----------------------------------	-----

<u>Power View</u> .....	157
-------------------------	-----

<u>Exporting 1801 Design Model</u> .....	158
--	-----

<u>Exporting 1801 Power Model</u> .....	162
---	-----

<u>Exporting Liberty Power Model</u> .....	166
--	-----

<u>Special Isolation Cells in Liberty Power Model Export</u> .....	171
--	-----

<u>Export of Switch Function and Isolation Enable Condition Expressions</u> .....	174
---	-----

## 7

<u>Verifying Power Intent of a Design</u> .....	177
---	-----

<u>Preparing and Running CLP</u> .....	177
--	-----

<u>Checking Design Hierarchy</u> .....	182
--	-----

<u>Power Intent Check</u> .....	182
---------------------------------	-----

<u>Power Intent Verification Requirements</u> .....	183
---	-----

## A

<u>Virtuoso Power Manager Environment Variables</u> .....	185
---	-----

<u>addNotInGndPgFunction</u> .....	186
------------------------------------	-----

<u>allowConstantExpressions</u> .....	187
---------------------------------------	-----

<u>allowDomainWithoutElements</u> .....	188
---	-----

<u>allowEmptyDomains</u> .....	190
--------------------------------	-----

<u>allowInoutLDOPins</u> .....	191
--------------------------------	-----

<u>allowInoutMonitorPins</u> .....	192
------------------------------------	-----

<u>allowInOutPortAsRegulated</u> .....	193
--	-----

<u>allowIsUnconnectedAsAttrInLiberty</u> .....	194
--	-----

## Virtuoso Power Manager User Guide

---

<u>considerShortThreshold</u>	195
<u>createExtractionLogFile</u>	197
<u>createPinsOnImport</u>	198
<u>delimiterForInternalPower</u>	199
<u>enableCDMAAttr</u>	201
<u>exportSwitchFunctionDerivationForAllUsedVirtualSupplies</u>	202
<u>exportIsoEnableConditionDerivationForAllTopIsolatedPorts</u>	203
<u>extractionLogPath</u>	204
<u>extractParasiticDiode</u>	205
<u>lpDBGGlobalSearchLibs</u>	207
<u>lpDBGGlobalSearchViews</u>	208
<u>lpDBPurgeOnDesignPurge</u>	209
<u>lsSingleRailInputPrefix</u>	210
<u>maxConsecutiveTxChannelCrossingsForABT</u>	212
<u>maxConsecutiveTxGateCrossingsForABT</u>	213
<u>maxInputPinsForAlgoStdCellABT</u>	214
<u>maxOutputPinsForAlgoStdCellABT</u>	215
<u>overrideSigTypeFromSetup</u>	216
<u>minTimeElapseForProgressInfo</u>	217
<u>overrideSigTypeFromSetup</u>	218
<u>powerDownFunctionForIOPorts</u>	219
<u>printAliveAndPermitAttributesinDotlib</u>	220
<u>printBusBitDirectionInLiberty</u>	221
<u>printCoupledSupplies</u>	223
<u>printModelInSDA</u>	225
<u>printProgressInfo</u>	226
<u>printSupplyNetInfo</u>	227
<u>reduceBoolExpressions</u>	228
<u>removeHierADSupForPorts</u>	229
<u>removeHierSupForInPorts</u>	230
<u>removeHierSupForOutPorts</u>	231
<u>removeInternalNetFromPgFn</u>	232
<u>removePST</u>	234
<u>runIDCInBackground</u>	235
<u>separatorForBit</u>	236
<u>signalPortsForIsoEnableConditionDerivation</u>	237

## Virtuoso Power Manager User Guide

---

<u>singleRailAttrPropagation</u>	238
<u>specialCellInfoFile</u>	239
<u>stopViewList</u>	240
<u>switchPinForNoPortAtSwitchablePower</u>	241
<u>switchViewList</u>	242
<u>updateRelatedSuppliesForNorNandIsoPorts</u>	243
<u>updateShortAttribute</u>	244
<u>updateUnconnPortsforAD</u>	245
<u>useANDForMultipleSupplies</u>	246
<u>useNandNorBaseIsolationTypes</u>	247
<u>vbHierScopeLevel</u>	248
<u>vbMaxHierDepth</u>	249
<u>virtualSuppliesForSwitchFunctionDerivation</u>	250
<u>writeMixedFormatPST</u>	251

## B

### Virtuoso Power Manager SKILL Functions . . . . . 253

<u>vpmDefinePowerSwitchInstance</u>	254
<u>vpmExportDotLib</u>	257
<u>vpmExportPowerIntent</u>	258
<u>vpmExportPowerModel</u>	259
<u>vpmExportPowerIntentSetup</u>	260
<u>vpmExtractPowerIntent</u>	262
<u>vpmGenerateSigInfo</u>	263
<u>vpmImportPowerIntent</u>	266
<u>vpmImportPowerIntentSetup</u>	269
<u>vpmLoadInDesignViolations</u>	271
<u>vpmRemoveImportedPowerIntent</u>	273
<u>vpmRemovePowerSwitchInstance</u>	275
<u>vpmRunInDesignChecks</u>	276
<u>vpmSetViolationBrowserOptions</u>	278

## C

### 1801 Support in Power Manager . . . . . 281

<u>General 1801 Command Support</u>	282
-------------------------------------	-----

# Virtuoso Power Manager User Guide

---

<u>1801 Special Cell Definition Command Support</u> .....	286
<u>Customized Commands</u> .....	288
<u>Liberty Attributes Support</u> .....	289

## D

<u>Virtuoso Power Manager Forms</u> .....	291
<u>Add 1801 File Binding Form</u> .....	292
<u>Add Device Form</u> .....	293
<u>Add Port Attributes Form</u> .....	294
<u>Add Power Domain Form</u> .....	295
<u>Add Supply Nets Form</u> .....	296
<u>Add Supply Sets Form</u> .....	297
<u>Add Supply State Form</u> .....	298
<u>Export Liberty Model Form</u> .....	299
<u>Export Power Intent Form</u> .....	300
<u>Generate Signal Information Form</u> .....	301
<u>Import Power Intent Form</u> .....	302
<u>Load Violations Form</u> .....	303
<u>Power Manager Setup Form</u> .....	303
<u>Supply Nets</u> .....	304
<u>Libraries</u> .....	305
<u>Devices</u> .....	305
<u>In-Design Checks</u> .....	306
<u>Export</u> .....	307
<u>Miscellaneous</u> .....	308
<u>Prepare CLP Form</u> .....	309
<u>Run CLP Form</u> .....	310
<u>Run In-Design Checks</u> .....	311
<u>Run In-Design Checks (Non-Blocking)</u> .....	312

---

# Virtuoso Power Manager

---

Virtuoso Power Manager provides an interface to specify, import, and export low power intent for designs. It provides the capability to perform static low power verification on designs by using Conformal Low Power (CLP) integration with Virtuoso and supports analog, digital, and mixed-signal implementations.

Power Manager, by using the import flow, can annotate and stitch the top-down power connectivity for a hierarchical design by using the connectivity model for inherited connections. Using the export flow, you can extract the power intent of a fully connected design schematic. You can also generate a Liberty-based macro cell for custom blocks using Power Manager for full-chip power intent verification.

When using special power-saving techniques for efficient power consumption, you often implement stringent power schemes throughout the design that add to the overall complexity while verifying the design. In addition, there are design scenarios that should be verified for the correct functioning of a circuit, for example, the correct biasing of MOS devices. To reduce the complexity, you should be able to perform a few basic-to advanced-level circuit design checks on schematic designs. The In-Design Checks feature in Power Manager provides such static checks that do not require circuit simulation.

An important consideration in IC design is to conserve power. Designers use special power saving techniques to achieve this objective. Some examples of these techniques include:

- Supplying different voltages for different groups of cells, therefore, creating multiple power domains.
- Using low power special cells to switch between the power-supply levels or to shut off groups of cells during specific periods of circuit activity, in turn, creating different power modes.

The definitions of the power domains, power modes, and low power special cells specify the power intent for a design. When you create a design that has some low power design techniques applied, you should be able to:

- Package and export the power intent along with the design by extracting the same from a hierarchical schematic.


# Virtuoso Power Manager User Guide

## Virtuoso Power Manager

- Verify the power intent of the design along with the functionality before it is further instantiated in other designs.
- Import an existing power intent and annotate it on the hierarchical schematic in terms of a completely resolved top-down power connectivity.

Power Manager addresses the need for the creation and verification of power-aware designs, including validating power intent changes during IP authoring. It provides the capability to annotate the design's power intent-related issues on the schematic. Therefore, it helps in the timely correction of power-related violations in the design.

Use Power Manager to specify, import, extract, and export the low power intent for designs. You can capture the power intent for the design (including its submodules) and map the power domains of an IP block with the domains of the designs. This helps in integrating an IP in the design.



Power intent definition at the design level is needed to connect IP blocks, which could be empty, partially complete, or non-structural, to top-level power ground (PG) pins. This definition, along with incremental change in power intent resulting from design edits, can be exported.

# Virtuoso Power Manager User Guide

## Virtuoso Power Manager


---

Low power verification is required to ensure structural and electrical accuracy for mixed-signal designs. Native low power checks within the Virtuoso Power Manager environment help in detecting low power violations during the IP authoring stage. The early feedback saves iterations later in the cycle. In-design checks work at the device level and enable the structural verification of custom AMS blocks. These are static circuit checks, which can be performed to fix design issues before proceeding to the dynamic verification (simulation) stage. The checks are performed after voltage propagation is done on the topology of a circuit. The voltage propagation does not require a transient simulation; therefore, a static check is faster than a dynamic check.

In-design checks are targeted to provide hints to designers about various low power and structural discrepancies in the design and help in improving the efficiency of the design development cycle by reporting design issues that can be fixed while the schematic design is still under development.

Verification can happen early in the design cycle and natively within the Virtuoso environment without invoking other tools; therefore, no data sharing or data translation occurs between tools. All formats are supported for checks, such as 1801, Liberty, or dotlib. Inherited and global power supply connections are also supported. In-Design Checks are applicable to discrete devices. The checks also work on hierarchical and read-only designs.

You can start Virtuoso Power Manager by clicking *Power Manager* from the *Launch* menu.



# Virtuoso Power Manager User Guide

## Virtuoso Power Manager

---

The Power Manager workspace window is opened.



### ***Related Topics***

[Licensing Requirements of Virtuoso Power Manager](#)

[Power Manager Toolbar](#)

## **Licensing Requirements of Virtuoso Power Manager**

You need the following licenses to use Power Manager.

<b>Base Product Name</b>	<b>License Feature Name</b>	<b>License Type</b>
Virtuoso Schematic Editor XL	Virtuoso_Schematic_Editor_XL (95115)	UHD
Virtuoso Power Manager	VIRTUOSO_POWER_MANAGER (95127)	J

The VIRTUOSO\_POWER\_MANAGER license is used until the last Power Manager schematic window along with the Power Manager Setup form is closed.

### ***Related Topic***

[Virtuoso Power Manager](#)








[Power Manager Toolbar](#)

## Power Manager Toolbar

In the Power Manager workspace, the following commands are available on the *Power Manager* toolbar in the workspace.

The toolbar lets you access the various commands and related forms supported by Power Manager. It is dockable and can be placed at the desired location within the window.





Refer to the following table for more information about the options on the toolbar.

Icon	Command	Use to...	Form
	Setup	Specify the setup information for running In-Design checks, importing, exporting, extracting, or removing power intent.	<a href="#">Setup for Automatic Extraction of Power Intent</a>
	Import Power Intent	Import the power intent for the given cellview.	<a href="#">Power Intent Import</a>
	Remove Power Intent	Remove all the power intent information from the current cellview.	<a href="#">Removing Imported Power Intent</a>
	Extract Power Intent	Extract the power intent of the given cellview.	<a href="#">Extracting the Power Intent from a Design</a>
	Export Power Intent	Export the power intent of the current cellview by using a <code>.upf</code> file.	<a href="#">Exporting 1801 Power Model</a>
	Export Liberty Model	Export the Liberty model of the current cellview by using a <code>.lib</code> file.	<a href="#">Exporting Liberty Power Model</a>
	Prepare CLP	Generate the input files at a user-specified location and therefore, provide an opportunity to view, inspect, and edit the files.	<a href="#">Preparing and Running CLP</a>

# Virtuoso Power Manager User Guide

## Virtuoso Power Manager

---

Icon	Command	Use to...	Form
	Run CLP	Start CLP and use the files created during CLP preparation, for power verification	<a href="#">Preparing and Running CLP</a>
	Run In-Design Checks	Perform static checks on the given design.	<a href="#">Running In-Design Checks</a>
	Load Violations	Load the file containing violations after the design check.	<a href="#">Loading the Violations Database</a>
	Generate Signal Info	Generate an output file that contains the net voltages for supply and signal nets, which are computed based on supply net and technology information provided in the Power Manager setup.	<a href="#">Generating Signal Information</a>

---

Alongside, these options are also available from the Power Manager pull-down menu in the workspace.

### ***Related Topic***

[Virtuoso Power Manager](#)

[Licensing Requirements of Virtuoso Power Manager](#)

---

## Virtuoso Power Manager Flow

---

The flows in Virtuoso Power Manager offer an automated solution for capturing the power intent of a design. Usually for small designs, it is convenient to write the power intent manually. As the design complexity increases, it becomes mandatory to have an automated solution. The complexity in designs can be about multiple power domains, different voltage levels, switchable power domains, or the functionality implemented using low power design techniques by the use of low power special cells, such as level shifters, isolation cells, and power switches.

You can seamlessly capture the power intent of digital, analog, and mixed-signal designs and verify that the power intent has been implemented correctly. In addition, you can also track power intent changes during IP authoring. You can export the power intent of the IP design in the standard IEEE 1801 format, which can be further utilized by the SOC verification team for full-chip low power verification.


### ***Related Topics***

[Basic Flow in Power Manager](#)

[Recommended Use Model for Power Intent Creation and Verification](#)

## Basic Flow in Power Manager

The basic Power Manager flow is illustrated below.



The Power Manager flow includes the following main tasks:

1. Prepare setup for capturing power intent.
2. Import existing 1801 power intent on a hierarchical schematic.
3. Update design.
4. Run In-Design Checks.
5. Extract relevant power intent information from design.
6. Export the extracted design information in the IEEE 1801 format.
7. Verify the exported power intent of the design.

### ***Related Topics***

#### Virtuoso Power Manager Flow

Recommended Use Model for Power Intent Creation and Verification

## **Recommended Use Model for Power Intent Creation and Verification**

Follow the use model described by the steps given below to get an accurate power intent for your design:

1. Prepare a setup file for importing power intent on a design, running In-Design Checks, or extracting power intent from a design. This requires registration of the components that describe power intent. For example, you can register power nets, ground nets, and special low power cells.

See [Setup for Automatic Extraction of Power Intent](#).

2. Register special low power cells or custom standard cells by using the Liberty definitions or a 1801 special cell definition file.

See [Registration of Low Power Special Cells and Standard Cells](#).

3. If there is an incomplete hierarchical design that already has the power intent available, for example, a digital block, use the import 1801 flow to complete the power connectivity of that hierarchical design. Perform the schematic hierarchy check while importing an existing 1801 power specification on a hierarchical schematic.

See [Power Intent Import](#).

4. Open the design in Power Manager and check for an existence of primitive cell instances or single supply cells, such as transistors or resistors at the top level of designs. If these cells exist at the top level, create one or more new blocks and move these cells to the new blocks.

This is required because the primitive instances do not have a power pin or ground pin and therefore, are not assigned to any power domain or domain mapping. In such a case, the design netlist generated for the verification includes these primitive cell instances, but the exported 1801 file does not include these instances. As a result, during power intent verification, when CLP does not find the power intent for these instances in the 1801 file, it reports errors or warnings. These can be avoided during netlisting by using the appropriate flags to customize the netlist so that it does not extract primitives.

See [Verifying Power Intent of a Design](#).

5. Load the setup file, including the customizations required for running the In-Design checks. Check the analog or mixed signal custom blocks using static, pre-configured in-design checks, and verify the low power design implementation.

# Virtuoso Power Manager User Guide

## Virtuoso Power Manager Flow


---

See [Running In-Design Checks](#).

Once the results obtained are satisfactory, extract the power intent details of the top design. Power Manager extracts the power intent of hierarchical design, which can be exported to a 1801 file. A separate OA view called the power view is also generated at the time of extraction that captures all the setup information, internal data structure, and the power intent details. This view can be reused in the same Virtuoso session.

See [Exporting Power Intent of a Design](#).

6. The standard and special cells in the design should have their associated schematic or Verilog Symbol views with the PG pin information. This is a requirement for the tool to generate a Verilog netlist with the PG information, before verifying the power intent.



CLP is a digital verification tool. It supports the inherited connections and global nets with explicit p/g connections to the standard cells because it needs maximum low power check coverage. CLP performs physical low power verification by tracing the explicit p/g nets and deriving power domain information accordingly. This is the most comprehensive design structural check.

7. Verify the power intent of your design.

See [Verifying Power Intent of a Design](#).

### ***Related Topics***

[Virtuoso Power Manager Flow](#)

[Basic Flow in Power Manager](#)

## **Power Intent of Large Designs**

If the top design is large, the power intent extraction step might lead to memory-related issues. In such cases, follow the bottom-up approach, where you first extract the power intent of sub-blocks separately in 1801 files and then, associate the 1801 files with their respective instances in the top design. Consequently, when you extract power intent for the top design, the tool consumes less memory. Also, you can apply the bottom-up approach when extraction options cannot be shared between the top design and the sub-blocks. For example, when the power / ground nets definitions, power / ground net voltage definitions, or power net–ground net voltage pair definitions in the top design are different from the sub-block definitions, use the bottom-up approach.

# Virtuoso Power Manager User Guide

## Virtuoso Power Manager Flow

---

### ***Related Topics***

[Virtuoso Power Manager Flow](#)

[Basic Flow in Power Manager](#)

[Recommended Use Model for Power Intent Creation and Verification](#)

# Virtuoso Power Manager User Guide

## Virtuoso Power Manager Flow

---

---

## Setup for Automatic Extraction of Power Intent

---

To run in-design checks or to extract the power intent from a design, you need to provide inputs that are required by the tool for correct identification of design topology and define key set of rules. For example, you can define a setup that identifies all the power nets in your design, creates power domains, creates supply states, or redefines the severity of certain checks.

The Power Manager setup can be classified as:

- **Common setup:** This type of setup information is common to a set of designs. It includes technology, environment, data integrity checks, and so on. This setup information is stored in a CSF-searchable location and is applied when no design-specific information is found.
- **Project-specific setup:** This information consists of the project-specific setup and design-specific details. It includes all types of settings and it is automatically applied if available for a design. You can register and specify values in the Power Manager Setup form and save them in the setup file for a project to ensure that each command is implemented according to the project setup.

A setup file can be placed at one of the following three locations:

- Device-level information inside PDK Library in `lpLibSetup.il`
- Project-level common settings at the CAD level inside `.cadence/dfII/vpm` or some other CSF-compatible path in `lpSetup.il`
- User-defined settings that are defined in Power Manager Setup form through registration and saved in a setup template file

There are two options in the setup template to control the enabling of the project-level (CAD) settings in the final merged setup loaded for Power Manager.

- `loadEnvironmentOptions:`

## Virtuoso Power Manager User Guide

### Setup for Automatic Extraction of Power Intent

---

Controls whether the `.cadence/dfII/vpm/lpSetup.il` file is loaded automatically as a part of the final merged setup.

- ❑ If set to `true`, the project-level settings are considered as a part of the final setup.
- ❑ If set to `nil`, the project level settings are ignored for the final setup.
- ❑ If this option is not specified in the Power Manager setup template, it is assumed to be `true` and is considered for the final setup.

#### ■ `pushUnmodifiedEnvOptions`:

Controls the reading of the project-level (CAD) settings, at a later stage. For example, if there is any update in the project-level settings and the changes need to be applied in the final merged setup for the Power Manager.

- ❑ If set to `true`, any changes done in the project-level settings are read and updated.
- ❑ If set to `nil`, any changes done in the project-level settings are ignored in the final setup.

You can define these options in the setup if you want to read the project-level setup initially or always want to ensure that the user-defined setup is synchronized with the project-level (CAD) setup.

The final setup is the result of merging all the three setups, which can be verified by exporting in the file:

```
vpmExportPowerIntentSetup("random_computation_flat" "random_computation_top"  
"schematic" "lpSetup_export.il" ?filter "allSetupOptions" ?overwriteExisting t)
```

Currently, if there are common settings in the setup file, for example, supply nets are specified in CAD and user-defined setup, the user-defined setup has a higher precedence.



***The Power Manager Setup form gives you the flexibility to dynamically switch and update more than one design for power information. However, it is recommended to update one design at a time, close the form, and reopen it for updating the power intent information for a different design. This ensures that the setup information is not inadvertently lost when switching from the setup for one design to the other.***

### ***Related Topics***

[Registering Name-Based Supply Nets](#)

[Registering Regular Expressions-Based Supply Nets](#)

[Registering Libraries](#)

[Registering Device and Cell](#)

[Performing In-Design Checks](#)

[Registering Supply Set and Power Domain](#)

[Miscellaneous Settings](#)



[Setup File Template](#)

[Loading Power Intent Extraction Options from a File](#)

[Saving Power Intent Extraction Options to a File](#)

## Registering Name-Based Supply Nets


You can set a rule to register certain names as names of power nets or ground nets. If a net in your design has one of the registered names, the net is identified accordingly. It is recommended to follow a similar naming convention for supply net naming across the design hierarchy. Here are the steps to register the supply nets.

1. Double-click the fields in the *Registered Supply Nets* table to edit.
2. To add the supply nets, click  .  
It opens the [Add Supply Nets](#) form.
3. Specify the values in the form for registering supply nets.
4. Click  to remove added supply nets.

## Virtuoso Power Manager User Guide

### Setup for Automatic Extraction of Power Intent

5. Press `Shift + Ctrl` to select nets and register them as power or ground. Simultaneous registration of existing and user-defined nets as power/ground is possible.



### **Important**

The existing nets shown in the Add Supply Nets form are the nets corresponding to the top-level ports of the design in consideration.

You need to specify the voltage values of the net for the top-level supply nets. You also need to register internal nets, such as low drop out (LDO) nets or output of a voltage divider, and provide the voltage values for such internal nets. For a hierarchical design, the voltage values specified from the top-level nets are propagated to the levels below in the following ways:

## Virtuoso Power Manager User Guide

### Setup for Automatic Extraction of Power Intent

---

- If the cells used in the design do not have their associated Liberty file, the voltage propagation for them happens hierarchically as per the top-level voltage values.
- If the cells used in the design have their associated Liberty/1801 cell bindings, the voltage map (from Liberty) or power states (from 1801) are expected to match the voltage levels specified for top level supplies.

You can also define multiple voltages for a top-level net. If you define multiple voltages for both power nets and ground nets, Power Manager considers all possible supply states based on all the supply net voltages provided in the setup. In-Design Checks consider all possible supply states based on all the supply net voltages provided in the setup information. The supply states are created depending upon the unique voltage values for a power net–ground net pair.

Consider a voltage specification with supplies `VDD`, `VSS`, and `VDD1V2` where `VDD` is 0.8V and 1.0V, `VSS` = 0.0V and 0.4V, and `VDD1V2`=1.2v.

```
netVoltages (("VDD" (0.8 1.0))
("VDD1V2" (1.2))
("VSS" (0.0 0.4)))
```

The following power modes are created:

Supplies	VDD	VDD1V2	VSS
State	OFF	OFF	OFF
	ON(0.8V)	ON(1.2V)	ON(0V)
	ON(0.8V)	ON(1.2V)	ON(0.4V)
	ON(1.0V)	ON(1.2V)	ON(0V)
	ON(1.0V)	ON(1.2V)	ON(0.4V)

You must provide the supply net voltage values for creating the power states based on the switching behavior of the corresponding supply nets.

Specifying net voltages in the setup is not mandatory if the import flow is used.

### ***Related Topics***

[Registering Libraries](#)

[Registering Device and Cell](#)

[Performing In-Design Checks](#)

[Registering Supply Set and Power Domain](#)

[Miscellaneous Settings](#)

[Setup File Template](#)

[Loading Power Intent Extraction Options from a File](#)

[Saving Power Intent Extraction Options to a File](#)

## Registering Regular Expressions-Based Supply Nets

If you do not know the names of the nets that exist down the hierarchy, there are some naming conventions followed. Here are the steps to register the regular expressions-based supply nets.

1. Specify regular expressions for nets in the *Power Nets* or *Ground Nets* fields on the *Supply Nets* tab of the Power Manager Setup form.


For example, if you add `vdd` as a regular expression, such as `iovdd`, `avddd1`, or any net name that contains this is considered as power net. Similarly, if `GND` is specified as a regular expression, names such as `GND_A`, `GND_D`, and so on, are considered as ground nets. Also, if `[v] [V]`, `[d] [D]`, and `[d] [D]` are defined as regular expressions, all combinations are considered, such as `vdd`, `VdD`, `VDD`, `Vd̄d`, and so on.

2. Specify the registration information in the *Pwell*, *Nwell*, *Deep Pwell*, or *Deep Nwell* fields on the *Supply Nets* tab of the Power Manager Setup form.

# Virtuoso Power Manager User Guide

## Setup for Automatic Extraction of Power Intent

3. Click *OK*.



Power Manager checks for the presence of the registered nets and identifies them as power or ground nets. These registered nets are used to create power domains.

**Note:** You must register the top-level supply nets for cells that do not have an associated Liberty model.

### ***Related Topics***

#### Registering Name-Based Supply Nets

## Virtuoso Power Manager User Guide

### Setup for Automatic Extraction of Power Intent

---

[Registering Libraries](#)

[Registering Device and Cell](#)

[Performing In-Design Checks](#)

[Registering Supply Set and Power Domain](#)

[Miscellaneous Settings](#)

[Setup File Template](#)

[Loading Power Intent Extraction Options from a File](#)

[Saving Power Intent Extraction Options to a File](#)

## Supply NetSet Properties Prefix Registration

Registration of supply net properties includes identifying and registering of supply nets by using the property name prefix for inherited connections that have been specified in the

## Virtuoso Power Manager User Guide

### Setup for Automatic Extraction of Power Intent

*Supply NetSet Properties Prefix* section on the *Supply Nets* tab of the Power Manager Setup form.

The screenshot shows the 'Power Manager Setup' dialog box for 'DESIGN\_WORKSHOP\_VPM DESIGN1 schematic'. The 'Supply Nets' tab is selected. The 'Supply NetSet Properties Prefix' section is highlighted with a red box. The fields in this section are:

Field	Value
Power Nets	vdd
Ground Nets	vss
Pwell Nets	vdd_sub
Nwell Nets	vss_sub
Deep Pwell Nets	vdd_sub2
Deep Nwell Nets	vss_sub2

For non-Liberty cells, the supply name can also be derived from the prefix of the property name used in the net expression for supply net connectivity. Power Manager creates property names for net expressions with a specific prefix as specified in the setup. Prefix matching helps to identify the power/ground type for lower level cells when the tool creates redirected netSets for resolving supply net connectivity to the top level supplies.

For power/ground type, precedence is given to supply net names that are already registered in the setup. Else, the property prefix name is used. The prefix name is registered in the setup for different supply types such as follows:

## Virtuoso Power Manager User Guide

### Setup for Automatic Extraction of Power Intent

---

powerNetPropPrefix - vdd

groundNetPropPrefix - vss

pwellNetPropPrefix - hSup\_sub

nwellNetPropPrefix - lSup\_sub

deepwellNetPropPrefix - hSup\_sub2

deepnwellNetPropPrefix - lSup\_sub2

### ***Related Topics***

[Redirected netSet Property Creation and Optimization](#)

[Registering Name-Based Supply Nets](#)

[Registering Regular Expressions-Based Supply Nets](#)

[Registering Libraries](#)

[Registering Device and Cell](#)

[Performing In-Design Checks](#)

[Registering Supply Set and Power Domain](#)

[Miscellaneous Settings](#)

## **Excluding Power and Ground Nets from Name-Based Registration**

Net names with a certain pattern can be detected as a regular expression during the supply nets name-based registration. It can lead to an incorrect registration for the net as a power or ground net, for example, the Monitor and Sense pins used in the design to sense and test the supply signal level during functioning of the design.

To exclude power and ground nets from name-based registration:

1. Use the *Names* field in the *Excluded Nets* section on the *Supply Nets* tab of the Power Manager Setup form to exclude a subset of specific net names. These names are

## Virtuoso Power Manager User Guide

### Setup for Automatic Extraction of Power Intent

---

defined in the *Regular Expression Based Registration* section or defined using the signal type.

2. Use the *Regular Expressions* field in the *Excluded Nets* section to specify one or more power or ground regular expressions that have been registered using the *Regular Expression Based Registration* section or defined using the signal type.

For example, if the regular expression of power net is VDD, the nets such as VDD, VDDD, AVDD VDD\_SUB, VDD\_PH, VDD\_PHY, VDD\_PH1, and so on, are specified as power nets. However, if you want to exclude all nets containing OUTVDD from being power nets, you can specify OUTVDD to be excluded as a regular expression.

3. Click *OK*.



The screenshot shows a dialog box titled "Excluded Nets" with a dropdown arrow on the left. It contains two input fields: "Names" with the text "OUTVDD" and "Regular Expressions" with the text "OUTVDD\*".

In a setup file, the excluded nets are represented as follows:

```
;;; Exclude Nets
    excludePG (nil
        names ("VDD_PROBE" "VSS_PROBE")
        regExprs( "vdd.*en vdd.*fb vss.*en vss.*fb" )
    )
```

### ***Related Topics***

[Registering Name-Based Supply Nets](#)

[Registering Regular Expressions-Based Supply Nets](#)

[Registering Libraries](#)

[Registering Device and Cell](#)

[Performing In-Design Checks](#)

[Registering Supply Set and Power Domain](#)

[Miscellaneous Settings](#)

[Setup File Template](#)

# Virtuoso Power Manager User Guide

## Setup for Automatic Extraction of Power Intent

---


[Loading Power Intent Extraction Options from a File](#)

[Saving Power Intent Extraction Options to a File](#)

## Registering Monitor Nets

Use the *Monitor Nets* section on the *Supply Nets* tab of the Power Manager Setup form to:

1. Register a net as Monitor/Sense, to designate it as a net or port for probing or testing.
2. Specify the regular expression for probing or testing.



The screenshot shows a section titled "Monitor Nets" with a dropdown arrow. Below it are two input fields. The first field is labeled "Names" and contains the text "VDD\_PROBE VSS\_PROBE". The second field is labeled "Regular Expressions" and contains the text "VDD\_PROBE\* VSS\_PROBE\*".

Specify values in the *Names* field to register a subset of specific net names that have been registered in the *Regular Expression Based Registration* section or defined using the signal type as Monitor Nets.

Similarly, specify values in the *Regular Expressions* field to register a subset of power or ground regular expressions that have been registered in the *Regular Expression Based Registration* section or defined using the signal type as Monitor Nets.

In a setup file, the monitor nets are represented as shown below:

```
monitor (nil
  names ("VDD_PROBE" "VSS_PROBE")
  regExprs( "vdd.*sense vss.*sense" )
)
```

## ***Related Topics***

[User-Defined Macros Registration](#)

[Resistors as Short Devices](#)

[Connectors](#)

[Single Rail Cells](#)

[Stack Transistors](#)

## **User-Defined Macros Registration**

Any hierarchical blocks in design can be registered as macro. This helps in improving the extraction speed. These blocks can be iterative instances with hierarchical content, sub-blocks with iterations, iterative ports connected to instances, or deep hierarchical blocks with multiple instantiations.

In a setup file, you can specify user-defined macro cells in following manner:

```
userMacroCells ( ("hierCell2" "pwr_test" "hierCell2" "schematic")  
("hierCell" "pwr_test" "hierCell" "schematic"))
```

```
userMacroCells ("hierCell" "hierCell2")
```

### ***Related Topics***

[Excluding Power and Ground Nets from Name-Based Registration](#)

[Registering Name-Based Supply Nets](#)

[Registering Regular Expressions-Based Supply Nets](#)

[Registering Libraries](#)

[Registering Device and Cell](#)

[Performing In-Design Checks](#)

[Registering Supply Set and Power Domain](#)

[Miscellaneous Settings](#)

[Setup File Template](#)

[Loading Power Intent Extraction Options from a File](#)

[Saving Power Intent Extraction Options to a File](#)

## Registering Libraries

Use the registration options on the *Libraries* tab to register the libraries-related information. This information is used by Power Manager to read the standard and special cells modeling information. It is required to extract the power-related attributes of standard and special cells and avoids the need to access these cells for tracing the related supplies corresponding to the boundary ports.



Use the *Liberty/Tech Files* and *1801 File binding* sections to specify the Liberty models or 1801 special cell definition files as follows:

1. Click  to add and  to remove the Liberty/Tech Files.

Optionally, you can register a cell and bind it to its existing 1801 power intent file. The power-related information is read from the existing 1801 bound to the cell.

2. Click  to add,  to modify, and  to remove the binding information. It opens the [Add 1801 File Binding](#) form.
3. Specify the values in the *Cell* and *1801 File* fields. Click *OK*.

**Note:** This option is commonly used for black-boxing contents of a digital sub-block that has power intent.

### ***Related Topics***

[Registering Libraries](#)

[Special Cell and Standard Cell Modeling](#)

[Design Sub-Block Modeling During Top-Level 1801 Design Model Extraction](#)

## **Special Cell and Standard Cell Modeling**

The IEEE 1801 standard is a must for the design and verification of low power integrated circuits, the correct identification and mapping of all power attributes, topology-related attributes, and the functions of low power special cells or standard cells. This is achieved by the proper registration of the special cells and the standard cell models. If cells are registered, they are identified in the schematic view accordingly.

Low power special cells and standard cells include:

- Isolation cell
- Level shifter cell
- Power switch cell
- Always on cell
- State retention cell
- Combinational/Sequential elements

Power Manager extracts level shifter strategy, isolation strategy, and power switch strategy in the power intent based on the definition provided in a 1801 special cell definition file or Liberty models. The in-design checking uses the same information to verify the power domain crossings with or without these special cell instances.

You can register these cells in any of the following two ways:

## Virtuoso Power Manager User Guide

### Setup for Automatic Extraction of Power Intent

---

#### ■ By using the Liberty models of the cells

Special cells and standard cells, which have their Liberty model available, are recognized for their topology and various supply-related attributes by including the corresponding Liberty files. The Liberty files enable the following:

- ❑ The `pg_pin` attributes specified in the Liberty files help in identifying the nets used inside the cells as power or ground.

```
pg_pin(VDD) {
  voltage_name      : VDD;
  pg_type           : primary_power;
  direction         : inout;
}
```

- ❑ The voltage map specified in the Liberty files is used to extract the voltage levels of the corresponding supply and ground nets used.

```
voltage_map( VDD , 1.100000);
```

- ❑ The `cell` type specified in the Liberty files is used to identify the type of low power special cell or the standard cell, and extract it accordingly during 1801 power intent extraction or running In-Design Checks.

```
cell(Isolation_Cell) {
  is_isolation_cell : true;
}
```

- ❑ The function attributes specified in the Liberty files are used as follows:
  - The switch/enable function of the low power special cells is used for finding the switch functions, enable conditions, and for backtracing the control/enable signals of the special cells, such as power switch cell, isolation cell, and enable level shifter cells, for any of the boundary ports.

```
pg_pin(VDDSW) {
  switch_function : "psw_en";
}

pin(out_iso) {
  isolation_enable_condition : "en_iso";
}
```

- The output function of the standard cells is used during backtracing of the control/enable signals of the low power special cells that are generated by some combinational logic, for example, output of a NAND gate. Here for a NAND gate Liberty function attribute of its output can be used.

```
pin (Y) {
  direction : "output";
  function : "(!((!AN) B))";
}
```

#### ■ By using the 1801 special cell definition file

## Virtuoso Power Manager User Guide

### Setup for Automatic Extraction of Power Intent

---

When you provide a special cell definition file at the location specified in the setup file, before extracting the power intent, Power Manager reads the given file and recognizes the cells specified in that file as special cells. The 1801 special cell definition file aids in modeling of these cells by specifying the related attributes in their definition.

- ❑ Cell type
- ❑ Supply ports/Switchable supply ports
- ❑ Data ports
- ❑ Enable/control ports
- ❑ Voltage range
- ❑ Cell-specific attributes

**Example:**

```
define_isolation_cell -cells ISOHLDX1_OFF -power ExtVDD -ground VSS -
clamp_cell low -enable !ISO

define_level_shifter_cell -cells LSLHX1_TO -direction both -input_power_pin
ExtVDD -output_power_pin VDD -ground VSS -input_voltage_range {{0.8 1.4}} -
output_voltage_range {{0.8 1.4}}

define_power_switch_cell -cells HSWX1 -type header -power ExtVDD -
power_switchable VDD -ground VSS -stage_1_enable PSO -stage_1_output PSO_out -
exclude { HeadSwitch_WrapperA HeadSwitch_WrapperB }
```

**Note:** Use this method to register special cells for the standard and verified standard cell libraries, which do not have the Liberty models available. This method can also be used to register custom standard cells.

Setup registration for Liberty models and the special cell definition file is as follows:

```
libFiles (
"libs/fast_vdd1v0_basicCells.lib"
"libs/fast_vdd1v2_extvdd1v0.lib"
"libs/macro_lib.lib"
"libs/Headswitch.upf"
)
```

### ***Related Topics***

#### Registering Libraries

#### Design Sub-Block Modeling During Top-Level 1801 Design Model Extraction

#### Reference Libraries or Cells

## MLDB Libraries

# Design Sub-Block Modeling During Top-Level 1801 Design Model Extraction

The modeling information of hierarchical design blocks can be provided to digital verification tools, such as Conformal Low Power (CLP) as follows:

- Liberty macro models: The contents of analog sub-blocks need to be modeled in terms of Liberty power model export to be provided to CLP. CLP identifies the modeling information and reads the power-related attributes of the boundary ports of the block for crossing analysis.

The Macro Liberty power model for a sub-block can be specified as a Liberty file on the *Library* tab of the Power Manager Setup form and therefore, binding it to that block.

- 1801 file binding: If the power intent of a hierarchical sub-block is already available as a 1801 design model, the same can be bound to that block in the *1801 File binding* section on the *Library* tab of the Power Manager Setup form. These blocks are locked for extraction of 1801 power intent by Power Manager. The tool does not traverse down the hierarchy but just one level inside its schematic to make the interface connectivity to the top-level 1801 file. A 1801 file used for importing the power intent on a digital sub-block can also be used for cell binding of that block.

During the top-level 1801 design model extraction, Macro Liberty Power Model, the special cell definition file and the available power intent of the sub-blocks are consumed together. The top-level design model can further be verified using CLP.

Cell bindings can be registered in the setup as:

```
cell1801Bindings (  
  ("data_LevelShifter" "./data_LevelShifter.upf")  
)
```

**Note:** If the top design is large, the power intent extraction step might lead to memory-related issues. Therefore, for large designs, follow the bottom-up approach. In this approach, you can first extract the power intent of sub blocks separately in 1801 files and then associate the 1801 files with their respective instances in the top design. After this, when you extract power intent for the top design, the tool consumes less memory. Also, you can apply the bottom-up approach when extraction options cannot be shared between the top design and the sub blocks. For example, when the power / ground nets definitions, power / ground net voltage definitions, or power net-ground net voltage pairs definitions in the top design are different from the sub block definitions.

### ***Related Topics***

[Exporting Power Intent of a Design](#)

[Registering Libraries](#)

[Special Cell and Standard Cell Modeling](#)

[Reference Libraries or Cells](#)

[MLDB Libraries](#)

## **Reference Libraries or Cells**

If the design contains instances of any library or a particular cell, apart from the Liberty cell, it can be read-only, black box, or a reusable block. You can register those as reference libraries. The cells in reference libraries are not edited during the 1801 import flow. If the input 1801 file has a connect supply net command for a instance inside the blackbox cell, the cell is not edited to create the netSet or any supply ports. During import, the hierarchy is traversed to map all the supply nets to the supply set at the instance boundary. You can specify library and cells in the Add Reference Cells form on the Libraries tab of the Power Manager Setup form.

Reference library registration in the setup is as follows:

```
refLibCells (  
("analogLib" "*buf*"))
```

### ***Related Topics***

[Registering Libraries](#)

[Special Cell and Standard Cell Modeling](#)

[Design Sub-Block Modeling During Top-Level 1801 Design Model Extraction](#)

[MLDB Libraries](#)

## **MLDB Libraries**

Power Manager processes the Liberty files to read the standard cell, special cell, and macro cell model definitions and stores them in an OpenAccess-based proprietary database. This

## Virtuoso Power Manager User Guide

### Setup for Automatic Extraction of Power Intent

---

avoids the need to reprocess the Liberty files every time a command is executed. Such a database is called Model Library database (MLDB). MLDB reads and stores the PG pins, pins, and the non-characterized attributes for the various cell models provided through Liberty files. These attributes are saved in a different library than the design or PDK library, which can be utilized in various projects to extract details instead of parsing the Liberty files every time. This can save a lot of run time that is required to parse large Liberty files if it has to be done repeatedly for extracting power-related attributes. If no user-specified library is provided, the database is in-memory and can be used only for a particular Virtuoso session.

MLDB creation requires a new library to be created. The library includes a `tech.db` file, which contains all the power-related attribute information that is extracted by a single traversal from the registered Liberty files. The setup registration for MLDB is:

```
projectMldbLibName "MLDB_TESTCELL"
```

A new `.lib` file is added to MLDB only in one of the following conditions:

- You have re-imported a modified setup specifying additional `.lib` files and removed `.lib` files that are not required anymore.
- You have run a VPM command, such as `extract power intent` or `import power intent`.

The modified MLDB is saved when closing all the files or exiting Virtuoso.

### ***Related Topics***

[Registering Libraries](#)

[Special Cell and Standard Cell Modeling](#)

[Design Sub-Block Modeling During Top-Level 1801 Design Model Extraction](#)

[Reference Libraries or Cells](#)


## **Registering Device and Cell**


Register the device and terminal related information on the *Devices* tab of the Power Manager Setup form. This information is used by Power Manager to read the device type and its topology in the design. For devices with more than two terminals, you can associate terminals to have specific mapping. Correct recognition and identification of device type is important for the supply traversal to find the related supplies of the boundary ports associated with the design logic.

To register cells as devices:


## Virtuoso Power Manager User Guide

### Setup for Automatic Extraction of Power Intent

1. Use *Filter* in the *Cells* group box to search for a cell. The *Filter* option gives the flexibility to easily filter and sort the desired choice of devices to be registered.
2. Select a cell or a set of cells to register in the *Cells* group box.
3. Select the device type for assigning the devices in the *Device Type* group box.
4. Use  to perform the assignment.



To register devices by using a wildcard-character-based registration:



1. Click  to open the Add Device form.
2. Specify a library and cell name based on a wild character notation and register the device in the corresponding *Device Type*.

## Virtuoso Power Manager User Guide

### Setup for Automatic Extraction of Power Intent

---

For example, specifying `gpdk*` and `nmos*` registers all the devices with a name matching the pattern `nmos*` in all the libraries with the name matching the pattern `gpdk*` to the device type `nfet`.

3. Click  to remove the assignment.
4. Specify conditions/criteria with the assigned device by clicking .
5. Click *OK*.

If the Library Name or a cell name field is left blank, all available libraries (for a particular cell name pattern) or all available cells (for a particular library name pattern) will be accounted for and register based on the wild character specification.

Devices used in the design, such as MOS devices, resistors, capacitors, and diodes, need to be registered in the setup under the following categories.

- Transistors (nfet, pfet, npn, pnp)
- Short devices (including devices with n terminals)
- Pad cells
- Cells to be ignored

In a setup file, the device registration is represented as shown below:

```
;;; Devices
devices (nil
  pfet (
    (nil "pmos*" nil)
    ("analogLib" "pmos*" nil)
    ("gpdk*" "pmos*" nil)
  )
  nfet (
    (nil "nmos*" nil)
    ("analogLib" "nmos*" nil)
    ("gpdk*" "nmos*" nil)
  )
  pnp (
    (nil "pnp" nil)
    ("analogLib" "pnp*" nil)
    ("gpdk*" "pnp*" nil)
  )
  npn (
    (nil "nnp" nil)
  )
)
```

## Virtuoso Power Manager User Guide

### Setup for Automatic Extraction of Power Intent

---

```
("analogLib" "npn*" nil)
("gpdk*" "npn*" nil)
)
```

#### ***Related Topics***

[Registering Name-Based Supply Nets](#)

[Registering Libraries](#)

[Registering Device and Cell](#)

[Performing In-Design Checks](#)

[Miscellaneous Settings](#)

## **Passive Devices**

Passive devices, such as resistors, capacitors, short, and diodes are considered as special cells and registered in the setup depending upon how they are placed in the design.

### **Resistors as Short Devices**

Resistors are registered in setup as short devices. You can short the terminals of devices that have more than two terminals.

In a setup file, the short device registration is represented as shown below:

```
short (
("analogLib" "res" nil)
("myLib" "wireshortcell" nil (nil shortedTerminalMap (("t1" "t2") ("t3" "t4" "t5")
)))
)
```

Ensure that you register passive devices associated to a condition as mentioned in the setup file. For example, certain configurations in designs might require the resistors not to be registered as short devices.

The multi-term shorting of devices under the Short category is considered only during macro model extraction. However, it is not considered while netlisting, which is a part of CLP integration. Therefore, it leads to an error during CLP verification.

## Connectors

You can register cells under the connectors in the following scenarios:

- While relating power nets with ground nets for establishing power ground net pairing. When the extractor traces the power to the ground paths in order to pair power and ground nets, if there is a connector instance in the path, the related terminals of the registered connector instance (a multi-terminal cell) help to continue tracing from one end to the other end.
- While backtracing the data path from the control pins of the special cells to the macro or design ports to generate the enable or shutoff condition for low power rules or power domains.

In a setup file, the connector registration is represented as shown below:

```
connector (  
  (nil "stdBuf*" nil)  
  ("ALIB" "PMU" nil (nil shortedTerminalMap (("p" "q") ("o" "y"))))  
)
```

Capacitors used in the data path mostly for the purpose of AC coupling are treated as connectors. The capacitors that are directly connected to power or ground for the purpose of blocking DC signal are treated as ignored or open. These are blocked for supply/ground tracing. The multi-terminal capacitors are also registered as devices.

In a setup file, the capacitor registration is represented as shown below:

```
cap (  
  (nil "cap" nil)  
  (nil "mimcap" nil  
    (nil  
      shortedTerminalMap (("PLUS" "MINUS"))  
    )  
  )  
)
```

**Note:** You can also use the wildcard character in the Ignore, Short, Buffer, and Inverter registration.

## Virtuoso Power Manager User Guide

### Setup for Automatic Extraction of Power Intent

---

Diodes can be used in the design for the different purpose like in an antenna or ESD clamp structures. Their registration in a setup is specific to the polarity configuration in which they are connected.

In a setup file, the diode registration is represented as shown below:

```
diode (  
  ("analogLib" "diode" nil (nil pTerm "PLUS" nTerm "MINUS"))  
)
```

A diode is referred to as an antenna diode if the `nTerm` of diode is connected to power and `pTerm` of diode is connected to a pin. Or, `pTerm` of diode is connected to ground and `nTerm` of diode is connected to a pin.

Antenna diode-specific attributes are printed for input & inout terms connected to the antenna diode.

#### Power Type:

```
pin (MyInput) {  
  antenna_diode_related_power_pins : "VDD";  
  ...  
}
```

#### Ground Type:

```
pin (MyInput) {  
  antenna_diode_related_ground_pins : "VSS";  
  ...  
}
```

#### Power and Ground:


```
pin (MyInput) {  
  antenna_diode_related_power_pins : "VDD";  
  antenna_diode_related_ground_pins : "VSS";  
  ...  
}
```

## Virtuoso Power Manager User Guide

### Setup for Automatic Extraction of Power Intent

---

A parasitic diode is formed between the source or drain terminal of a MOS device and the bulk terminal. Here is an example of a PMOS device and a parasitic diode.




For a PMOS device, a diode that has the anode connected to the signal net and the cathode connected to the power supply is extracted. In this case, it is a power type diode.

# Virtuoso Power Manager User Guide

## Setup for Automatic Extraction of Power Intent

---

```
antenna_diode_related_power_pins : "VDD";
```



For an NMOS device, a diode that has the cathode connected to signal net and the anode connected to ground supply is extracted. In this case, it is a ground type diode.

```
antenna_diode_related_power_pins : "VSS";
```

### ***Related Topics***

[Passive Devices](#)

[Backtrace Enable Signals of Special Cells](#)

[Connectors](#)

[Single Rail Cells](#)

[Stack Transistors](#)

[Terminal Name Registration for Devices](#)

## Backtrace Enable Signals of Special Cells

This involves backtracing of the internal net to map the enable or control signals of special cells to the boundary ports. Backtracing is required to get the appropriate functional attribute related to the enable or control signals in the Liberty macro model after detecting the corresponding function of the logic generating the signals.

Liberty registration for standard and special cells in the setup is a mandatory requirement to extract a correct function for the enable or control signals of low power special cells as per the design implementation

The backtracing is supported for following registered configurations:

- For buffers, shorts, and inverters, the two-terminal devices with single input and output, such as inverters and buffers, can be backtraced. The polarity of the signal does not change while backtracing through instances, unless the instances are inverter cells. You can register these cells as Inverter. If an instance with more than two terminals is present in the path, backtracing stops and an error message is displayed. Inverter and buffer registration is done as shown below.

```
inverter (  
  (nil "stdInv*" nil)  
  ("gpdk*" "inv*" nil)  
)
```

```
buffer (  
  (nil "stdBuf*" nil)  
  ("gpdk*" "buf*" nil (nil shortedTerminalMap (("p" "q") ("o" "y"))))  
)
```

**Note:** The terminal map is a mandatory requirement for backtracing when a cell contains multiple input and output and is registered as an inverter or a buffer.

- For standard isolation or level-shifter instances, signals are backtraced from output pin to input pins. For power switch instances, the signals are backtraced from the acknowledge pin (buffered enable) to enable the pin of the instance. This lets the backtracing to be performed for the control signals of all the power switch cells to the same macro port resulting in the correct enable and shutoff conditions.
- For simple logic gate, the backtracing is done through the special cell enable pin to the output pin of the logic gate that has multiple input pins is supported. All input pins of a logic gate can be backtraced separately to the maximum extent possible.

However, a cell can be registered as LogicGate (simple logic gate) only if it matches any of the following criteria:

## Virtuoso Power Manager User Guide

### Setup for Automatic Extraction of Power Intent

---

- ❑ There are no multiple output pins in the cell.
- ❑ The boolean function is present in the setup file.
- ❑ Only AND, NAND, OR, NOR, and XOR Boolean functions are considered.

The cells are registered as LogicGate devices along with Boolean functions of the cells.

```
logicGate (  
  ("sample" "or*" nil (nil booleanFunction "OR"))  
  ("sample" "xor*" nil (nil booleanFunction "XOR"))  
  ("sample" "and*" nil (nil booleanFunction "AND"))  
  ("sample" "nand*" nil (nil booleanFunction "NAND"))  
  ("sample" "inv" nil (nil booleanFunction "NOR"))  
)
```

- A custom logic can also be registered with the desired terminal mapping between its output and input ports to be suitably backtraced if it lies in between the enable/control signal and the boundary port generating it. For any block net, all the modules from parent of leaf cell to parent of block net are checked if one or more of these are custom devices. In case, more than one modules are found as custom devices, the top most module is given the priority.

```
customLogic (  
  ("ALIB" "WiFi" nil (nil relatedTerminalMap  
    "y1=x1&x2,y2=x3|x4,y3=x5^x6"))  
)  
)
```

- Algorithm Standard Cell

The function of output pins is extracted in terms of input pins by backtracing through transistors or other primitive elements, such as resistors and capacitors. You can use the [maxInputPinsForAlgoStdCellABT](#) and [maxOutputPinsForAlgoStdCellABT](#) flags while doing logic extraction for any unregistered cells.

- Cells registered as transistors

While back tracing through transistors back tracing would stop if the successive channel or gate crossings before continuing back tracing reaches a predefined limit. The [maxConsecutiveTxGateCrossingsForABT](#) and [maxConsecutiveTxChannelCrossingsForABT](#) flags are utilized while back tracing through transistor logic, either seen in its flat form or seen inside algorithm standard cell. Which back-tracing through the transistors, the back tracing would stop if the successive channel or gate crossings before continuing back tracing reaches a predefined limit.

## Virtuoso Power Manager User Guide

### Setup for Automatic Extraction of Power Intent

---

- The user-defined macros and switch functions in internal and regulated nets can be backtraced.
- You can print the derivations of `switch_function` and `isolation_enable_condition` expressions.
- Power Manager also extracts the following user defined attributes:
  - `switch_function_off`:
    - String type user-defined simple attribute for `pg_pin` group
    - Printed along with a `switch_function`
    - A boolean expression of macro cell input pins that evaluates to 1 only when output supply is fully OFF.
  - `isolation_enable_condition_off`
    - String type user-defined simple attribute for pin group
    - Printed along with the `isolation_enable_condition`
    - A boolean expression of macro cell input pins that evaluates to 1 only when the isolation function of a level shifter or isolation cell is fully disabled.
- The reporting of automatically identified transfer functions of cells/pins in the backtracing path is also supported.

### ***Related Topics***

[Passive Devices](#)

[Connectors](#)

[Single Rail Cells](#)

[Stack Transistors](#)

[Terminal Name Registration for Devices](#)

## **Single Rail Cells**

Single rail cells are custom cells. These can be custom standard cells, an unimplemented sub-block, or a complex hierarchical custom logic having a single primary power and ground supplies. Usually, a Liberty model does not exist for such cells. Consequently, the single rail

## Virtuoso Power Manager User Guide

### Setup for Automatic Extraction of Power Intent


---

cell registration enables blackboxing of any hierarchical sub-block so that the extractor recognizes it as a leaf cell. All ports connected to a single rail cell (directly or through some elements) are mapped according to the port definitions as defined in standard cell registration.

Single rail devices commonly used have the following features:

- Single rail device registration can be done with global attributes set at the cell level for multiple cells. In addition, the registration can also be done explicitly for a single cell.
- Defining the global supply values is optional.
- By default, all non-supply and non-bias pins are considered to be data pins. These data pins are related to the supply pins (RPP/RPG) and the bias pins (RBP).
- Single rail cells are also supported for bias supplies, which might be different from primary supplies.

On the Device tab in the Power Manager Setup form, when you click  after selecting the `singleRailCell` device type, the `singleRailCell` Attributes form opens. Additionally, you can view the form by selecting any cell registered as a single rail cell device.



In a setup file, the `singleRailCell` registration is represented as shown below:

```
singleRailCell ( nil
  cells (
    ("myLib"      "aBuf*" nil)
    ( nil          "bBuf*" nil)
    ("myLib"      "cBuf*" nil
      (nil
        power          "VDD"
```

# Virtuoso Power Manager User Guide

## Setup for Automatic Extraction of Power Intent

---

```
        ground          "VSS"
        pwell           "VPP"
        nwell           "VNN"
        deeppwell       "VPPP"
        deepnwell       "VNNN"
    )
)
    )
power          "VDD"
ground         "VSS"
pwell         "VPP"
nwell         "VNN"
deeppwell     "VPPP"
deepnwell     "VNNN"
)
```

### ***Related Topics***

[Passive Devices](#)

[Backtrace Enable Signals of Special Cells](#)

[Connectors](#)

[Stack Transistors](#)

[Terminal Name Registration for Devices](#)

### **Stack Transistors**


Stack Transistor devices are used in the advanced node designs for reduced power consumption at lower gate lengths. Stack Transistor devices commonly used have the following features:

- The same master is used for creating different device variants, such as PMOS or NMOS.
- The Stack Transistor device has a series of cascaded PMOS or NMOS devices inside.

# Virtuoso Power Manager User Guide


## Setup for Automatic Extraction of Power Intent


- A parameter on the device Pcell master defines the device type used inside for stacking.



## Virtuoso Power Manager User Guide

### Setup for Automatic Extraction of Power Intent

On the Device tab in the Power Manager Setup form, when you click  after selecting the `stackTransistor` device type, the Device Parameter Names form opens.



When you click the `stackMOSfet` device type, the Device Parameter Names form opens.

It is used to specify the device parameter names for the stack MOS device to define the device as PMOS or NMOS. You can specify more than one parameter names.

**Note:** If the device terminal have names different from the conventional naming, you need to provide a terminal mapping for the same during device registration.

In a setup file, the stack MOS device registration is represented as shown below:

```
stackTransistor (
```

# Virtuoso Power Manager User Guide

## Setup for Automatic Extraction of Power Intent

---

```
(nil "STACKMOS*" nil)
("analogLib" "STACKMOS*" nil)
("gpdk*" "STACKMOS*" nil)
)
stackTransistorDeviceParamNames "SourceCell"
```

### ***Related Topics***

[Passive Devices](#)

[Backtrace Enable Signals of Special Cells](#)

[Connectors](#)

[Single Rail Cells](#)

[Terminal Name Registration for Devices](#)

### **Terminal Name Registration for Devices**


While traversing through the connections of transistor instances, the Power Manager needs to identify the gate, source, and drain terminals of the registered transistor devices. Therefore, in addition to registering the devices, you need to register the names of the device terminals of these devices. You can register terminal names with an appropriate terminal type in the Power Manager Setup form and subsequently, in the setup file as shown below:

```
txTermTypeNames (nil
source      "s S source SOURCE Source"
drain      "d D drain DRAIN Drain"
gate       "g G gate GATE Gate"
bulk       "b B BULK well SUB"
collector  "c C collector"
emitter    "e E emitter"
base       "b B base BASE Base"
substrate  "S BULK well SUB"
```

## Virtuoso Power Manager User Guide

### Setup for Automatic Extraction of Power Intent

)



### Caution

**If you are using a PDK that is not provided by Cadence, it is essential to register the transistors and terminal names to ensure correct extraction of boundary ports and automatic pairing of power nets and ground nets.**

### Related Topics

[Passive Devices](#)

[Backtrace Enable Signals of Special Cells](#)

[Connectors](#)

[Single Rail Cells](#)

[Stack Transistors](#)

## Performing In-Design Checks


Power Manager supports running a set of predefined and configurable circuit checks for mixed-signal designs that include devices and standard cells. You can define the severity of reporting of these checks on the *In-Design Checks* tab.

## Virtuoso Power Manager User Guide

### Setup for Automatic Extraction of Power Intent

To perform in-design checks:

1. Specify the severity level of the results reported for the *Level Shifter*, *Isolation*, and *Bulk* checks in the Checks Categories section.



**Note:** For reporting violations generated from a specific check, the error severity for that check must be set to *Error* or *Warning*. If set to *Ignore*, the reporting of violations for the corresponding check is disabled.

# Virtuoso Power Manager User Guide

## Setup for Automatic Extraction of Power Intent

2. Add filter patterns in the *Filters* field to filter some of the error and warning messages.

```
▼ Filters  
5054*Receiver*1.10V  
5054*Receiver*[23].[59]0V  
3062*I0/I?*Receiver*mn?  
3063  
5056*Driver
```

These errors are reported and exist in the design, but these are not a problem for the design in the given scenario.

The image shows a sequence of three screenshots illustrating how a filter is applied. The first screenshot shows the 'Filters' field with '5056\*Driver' selected. The second screenshot shows the 'Audit Design Report' with a table of violations. The 'Filtered' count is 1, and a red box highlights this row. The third screenshot shows the 'Filter Option Used' section of the report, where 'lprcFilters = ("5056\*Driver")' is shown, and a corresponding error message is filtered out.

```
▼ Filters  
5056*Driver
```

```
#####  
# Audit Design Report #  
#####  
# Design : PSolib/Concurrent_Switching/schematic  
# Program Version : @(#)$CDS: virtuoso version ICADV18.1-64b 01/17/2020 19:12 (cpgbld02.cadence.com)  
# Program Sub-Version : ICADV18.1-64b.500.9.EA31  
# Start Time : Tue Jan 21 12:03:15 2020  
# Finish Time : Tue Jan 21 12:03:15 2020  
#####  
##### Audit Design Violations Summary #####  
#####  
Errors : 12  
Warnings : 0  
Informations : 0  
Filtered : 1  
Missing Level Shifters : 2  
Redundant Level Shifters : 0  
Floating Level Shifters : 0  
Always Off Level Shifters : 0  
Always On Level Shifters : 0  
Protected Level Shifters : 0  
Unprotected Level Shifters : 0  
Unreliable Level Shifters : 0  
Incompatible Level Shifters : 10  
Missing Isolations : 0  
Redundant Isolations : 0  
Incompatible Isolations : 0  
Incompatible_Bulk Supply : 0
```

```
#### Filter Option Used ####  
lprcFilters = (  
    "5056*Driver"  
)  
#### Filtered Violations ####  
(43) : *FILTERED-ERROR* (LP-5056): Found invalid 'driver' for data pin 'A' of level shifter instance 'I42' in cellview 'P
```

## Voltage Tolerance

The *Tolerance* section provides the flexibility to add tolerance for power and ground rail supply net voltage values for level shifter checks. All data path crossings within the tolerance limits are not flagged as violations. All the upper bound tolerances are positive numbers or zero and the lower bound tolerances are negative numbers or zero. The missing level shifters are reported for the signal crossings operating at different voltages when at least one of the following conditions, indicated by the GUI options, is true:

- *Input Voltage Upper Bound*: The driver power voltage is more than the receiver power voltage by the upper bound input voltage tolerance. This value should be  $\geq 0$ .
- *Input Voltage Lower Bound*: The driver power voltage is less than the receiver power voltage by the lower bound input voltage tolerance. This value should be  $\leq 0$ .
- *Input Ground Voltage Upper Bound*: The driver ground voltage is more than the receiver ground voltage by the upper bound ground input voltage tolerance. This value should be  $\geq 0$ .


The following table shows an example of scenario's which would reflect a level shifter error and the ones which would not reflect the error.

VDD1 (Driver)	VDD2 (Receiver)	Diff	Upper Bound	Lower Bound	Error Status
1.4	1.6	-0.2	0.1	-0.1	Error
1.4	1.6	-0.2	0.1	-0.3	No Error
1.5	1.6	-0.1	0.1	-0.1	No Error

## Virtuoso Power Manager User Guide

### Setup for Automatic Extraction of Power Intent

- *Input Ground Voltage Lower Bound*: The driver ground voltage is less than the receiver ground voltage by the lower bound ground input voltage tolerance. This value should be  $\leq 0$ .



### ***Related Topics***

[Registering Name-Based Supply Nets](#)

[Registering Libraries](#)

[Registering Device and Cell](#)

[Miscellaneous Settings](#)

## Setting Supply States


When a design uses multiple voltages for efficient power management, they can be switched on and off or scaled up or down to different voltage values as per design requirements. These are power states. A power state can be defined as a set of power and ground nets with their respective voltage values. IC designers choose the states as per the performance need of a design. Some common schemes that use the power states are dynamic voltage, frequency scaling, and run and standby performance modes.

As the number of power and ground supplies increases, their combination increases multiple folds. To perform checks, it is critical to define the valid power states. Check the specified supply states in a design. A voltage net can be ON at different supply voltages and off at a particular voltage value.

For a power net, OFF is considered as 0 and ON can be 1.0V, 1.1V, 0.8V, and so on.



For a ground net, OFF is considered as the signal that is not available.


To populate the supply states:


1. Click  to add the supply states in a design. It opens the [Add Supply State](#) form.
2. Click the *Get Default Supply State* button to remove all the existing voltages/values pairs from the Add Supply State form if already existing. You have an option to apply this default state directly or after adding/deleting/modifying some supplies and their values. The default supply states have a unique non-existent name.

## Virtuoso Power Manager User Guide

### Setup for Automatic Extraction of Power Intent

3. Optionally, click  to modify, and  to remove the supply states.




4. Additionally, use  to copy existing supply states from the table. The Copy Supply State form shows all the supplies with their respective voltage values of the currently selected *Supply State* in the table. By default, the name of the copied state is shown as

## Virtuoso Power Manager User Guide

### Setup for Automatic Extraction of Power Intent

"State Name + \_copy". You can add, delete, or edit voltages and their values. You can also modify the name of the state.



The *Registered Supply Nets* table in the Supply Nets tab is always in synchronized with the Supply States. If the supply nets are already available and registered in the *Registered Supply Nets* table, the same nets are available for selection in the Add Supply State form along with different voltage values in the lists. Conversely, while filling

## Virtuoso Power Manager User Guide

### Setup for Automatic Extraction of Power Intent

the Add Supply State form, if you introduce a new supply net with a set of voltage values, the values are automatically updated in the *Register Supply Nets* table.

The screenshot shows two tables in the Power Manager interface:

**Supply States Table:**

Supply State	VDD	VDDA	VSS	VSS2
SS1	1.500000	2.500000	OFF	
SS2	2.3	1.0	OFF	
SS3		OFF		1.

**Registered Supply Nets Table:**

Name	Type	Voltage	Ext Sw
VSS2	Ground	1.100000 0.00...	<input type="checkbox"/>
VSS1	Ground	0.000000	<input type="checkbox"/>
VSS	Ground	0.000000	<input type="checkbox"/>
VDDDB	Power	1.000000	<input type="checkbox"/>
VDDA	Power	1.000000 2.50...	<input type="checkbox"/>
VDDSW	Power	1.100000 2.90...	<input type="checkbox"/>
VDD1	Power	1.800000	<input type="checkbox"/>
ExtVDD	Power	1.000000	<input type="checkbox"/>
VDD	Power	2.300000 1.10...	<input type="checkbox"/>

**Note:** The supply information registered in the *Supply States* table is read by the Power Manager when the *Use Supply States* option is selected. If it is not selected, the supply information is read from the *Registered Supply Nets* table in the Supply Nets section of the Power Manager Setup form.

5. Select the check boxes in the *Report Options* section based on your preferences.

The **Report Options** section contains the following settings:

- Similar Violations Limit:
- Violations for ports without attributes
- Violations for all net voltages
- Isolation violations for always-on to switched supply crossings

### ***Related Topics***

[Registering Port Attributes](#)

[Performing In-Design Checks](#)

[Registering Supply Set and Power Domain](#)

## **Registering Supply Set and Power Domain**

A power domain is a part of the design that operates at a specific voltage. While capturing the power intent, you need to specify the power domains for the top level of the design. There can be a single or multiple power domains associated with the different sections of the design addressed by a specific supply set.

During automatic extraction, Power Manager identifies a power net and a ground net from the pair defined explicitly in the setup as a supply set in the *Export* tab of the Power Manager Setup form. It associates the supply set with the power domain as specified in the setup.

## Virtuoso Power Manager User Guide

### Setup for Automatic Extraction of Power Intent

You can specify a supply set as a primary supply set for the power domains mentioned in the setup. In addition, you can also define the supply set for the power and ground that cannot be paired by traversing the design hierarchy or parsing the Liberty file.



To register supply set and power domain:

1. Click to add, to modify, and to remove the supply set and power domain information.

It opens the Add Supply Set and Add Power Domain forms, respectively.

2. Click *OK*.

The Supply Set field is automatically populated if the field is found blank or the user-defined names are in the SS<delimiter>XYZ<delimiter>ABC format. The automatically generated supply set names follow the <SS><delimiter><powerSupply><delimiter><groundSupply> format.

## Virtuoso Power Manager User Guide

### Setup for Automatic Extraction of Power Intent

---

The Power Domain field is automatically populated if the field is found blank or the user-defined names are in the PD<delimiter>XYZ format. The automatically generated power domain name follows the <domainPrefix><delimiter><supplySetName> format.

In the following example, the power net VDD and VSS are registered as a supply set, also a top-level power domain is registered as PD\_TOP, which is associated with this supply set having power nets and ground nets as VDD and VSS, respectively.

```
;;; Supply Sets
supplySets (
  (nil
    supplySetName    "SS_VDD_VSS"
    power            "VDD"
    ground           "VSS"
  )
  (nil
    supplySetName    "SS_VDDA_VSSA"
    power            "VDDA"
    ground           "VSS"
  )
)

;;; Power Domains
powerDomains (
  ( nil
    domainName       "PD_TOP"
    elements         "."
    primarySupplySet "SS_VDD_VSS"
    includeScope t
  )
  ( nil
    domainName       "PD_LS"
    elements         "I0"
    primarySupplySet "SS_VDDA_VSS"
  )
)
```

**Note:** Specifying supply sets and power domains in the setup is not mandatory if the 1801 import flow is used.

If you do not register power net and ground net pairs, the ground net associated with a power net is automatically traced, consequently, creates a supply set and an associated power domain. Consequently, all the other supply sets are created. This is possible only when there

exists a path from a power net to a ground net through a network of transistors and/or two terminal devices. In other cases, you need to register the supply set.

### ***Related Topics***

[Add Supply Set](#)

[Add Power Domain](#)

[Registering Supply Set and Power Domain](#)

[Performing In-Design Checks](#)

[Registering Port Attributes](#)

## **Registering Port Attributes**

There are specific design configurations where a boundary port is connected to different blocks that have different supply sets. This leads to ambiguities during the 1801 power intent extraction or the In-Design checks to associate the boundary ports to a power domain.

To register port attributes:


1. Add ports by using the Add Port Attributes form in the *Port Attributes* section on the *Export* tab of the Power Manager Setup form to resolve such an ambiguity. For analog macros, Power Manager offers a mechanism of hierarchical supply traversal till device level to extract power attributes for the boundary ports.
2. Specify the port names or regular expression in the *Ports* field.
3. Define the direction attribute by using *Applies To*.
4. Define the ports for exclusion in the *Exclude Ports* field.
5. Select the driver and receiver supply set.

## Virtuoso Power Manager User Guide

### Setup for Automatic Extraction of Power Intent

---

- Specify if it is the an Analog, Unconnected, and Feedthrough port and click OK.



Alternatively, you can use `portAttributes` in the setup template as shown:

```
portAttributes (  
  (nil  
  ports "enable_pin"  
  driverSupplySet "SS_VDD_GND"  
  receiverSupplySet "SS_VDD_GND"  
  isAnalog<t/nil>  
  isUnconnected<t/nil>))
```

You can specify the following for a particular list of ports defined using `portAttributes`:

Driver and receiver supply set associated with the digital ports.


Analog and unconnected ports, where you can add a separate set of ports that do not have the `driverSupplySet` or `receiverSupplySet`.

The port attributes specified using `portAttributes` should take the highest precedence and override other definitions. The 1801 power intent extraction or the in-design checks consider the attributes specified for ports by using `portAttributes`, if registered in the setup template. If you specify both the driver and the receiver supply set for a port, they are used during extraction. If you specify only a driver supply set for input

## Virtuoso Power Manager User Guide

### Setup for Automatic Extraction of Power Intent

port, the 1801 power intent extraction or the In-Design Checks use it and trace only the receiver supply set and conversely.



7. Select the following options in the *Export Options* section to control the extractor behavior for the specific design scenarios:
  - Consider inputOutput terms for internal power criterion:* For details, see [allowInoutLDOPins](#).
  - Consider inputOutput terms for monitor power criterion:* For details, see [allowInoutMonitorPins](#).
  - Consider symmetrical source and drain for supply tracing:* Defines a port with a predefined supply set or power domain that can be checked for the correct or compatible connection at the receiver side. By default, this option is deselected. Supply tracing is done by Power Manager for MOS terminals (Source and Drain) by considering them asymmetric in nature. When this option is selected, Power Manager traces through all devices irrespective of the way they are connected in the design.
  - Use anonymous supply for top level ports:* Enables the use of an anonymous supply for the top-level ports instead of the default supply set.

### **Related Topics**


[Add Port Attributes Form](#)

[Registering Supply Set and Power Domain](#)

## Performing In-Design Checks

# Miscellaneous Settings

Specify the generic settings on the *Miscellaneous* tab.



### ■ *Delimiter*

Used for specific notations, for example, redirect netSets created during the 1801 import flow, automatically generated supply set and power domain names, and so on.

### ■ *Switch View List* to `schematic symbol`: It controls the order of the traversal of the design hierarchy during power intent extraction.

### ■ *Stop View List* to `symbol`: It defines the stop point where the design traversal must be stopped by the extractor during power intent extraction.

`switchViewList` and `stopViewList` can be specified in the Power Manager setup template or defined using the `switchViewList` and `stopViewList` environment variables.

### ■ *Use Signal Type* (`considerSignalType`) to ignore or consider the `sigType` attribute of nets for detecting the supply nets during power intent extraction. By default, this option is set to `nil` and the attribute is not considered during name-based registration for detecting supply nets. However, if set to `t` and there is a conflict between the `sigType` attribute and name-based registration, name-based registration takes precedence.

#### Setting the signal type to identify the power nets and ground nets

Each net has a `Signal Type` attribute that when set to `power` or `ground` can be used to identify the net as a power net or a ground net, respectively. The default signal type of a net is `signal`. During the automatic extraction, Power Manager

## Virtuoso Power Manager User Guide

### Setup for Automatic Extraction of Power Intent


---

looks for the `considerSignalType` attribute. When set to `true`, it creates power domains considering all the nets that have the signal type defined as power or ground.

**Note:** If there is a conflict between the `sigType` attribute and name-based registration, name-based registration takes precedence.

You can set the signal type for pins or nets in your design in one of the following ways:

- Select a pin or net on the schematic and in the Property Editor assistant, update the *Signal Type* property.



## Virtuoso Power Manager User Guide

### Setup for Automatic Extraction of Power Intent


- Right-click a net and choose *Properties* to open the **Edit Object Properties** form. Update the *Signal Type* property in this form.

The screenshot shows the 'Edit Object Properties' dialog box. The 'Apply To' section has 'only current' and 'wire segment' selected. The 'Show' section has 'user' checked. The main table lists properties: Net Name (VDD!), Net Expression, Property Name (vdd\_\_cell\_psw\_0), Default Net (VDD!), Evaluated Name (VDD!), Width (narrow selected, 0.0625), Signal Type (signal selected), Color, and Line Style. The 'User Property' section includes vpmOrigin. A dropdown menu for 'Signal Type' is open, showing options: signal, ground, power, clock, analog, tieOff, tieHi, tieLo, scan, reset, optical, singleModeOptical, and multiModeOptical. Buttons for 'OK', 'Cancel', 'Modify', 'Previous', 'Next', and 'Help' are visible.

## Virtuoso Power Manager User Guide

### Setup for Automatic Extraction of Power Intent

- Specify the appropriate signal type while creating a new pin by using the **Create Pin** form. The *Signal Type* field, which is by default set as `signal`, specifies the pin type.



For the power pins, you can set the value in this field as `power`.

If you use a specific set of names, such as, `vdd`, `vdd!`, or `VDD`, for the power pins in your designs and `vss`, `vss!`, or `VSS`, for the ground pins, it is recommended that you register those names by using the `ciRegisterNet` API in `.cdsinit` file. If you use a registered name for a pin on the **Create Pin** form and the signal type is set as `signal`, the default value, the tool automatically sets the signal type of that pin as `power` or `ground` respectively. In that case, you need not specify the signal type explicitly for each new pin or net created in the design. Later, if you do not need to use the registered names, you can set the registration as `nil`.

The name-based registration in the setup file template for the Power Manager is as follows:

```
;;; Supply Nets
supplyNets (nil
  power (nil
    names ("vdd" "avdd" "dvdd" "VDD" "AVDD" "DVDD")
    regExprs ("[vV][dD][dD]" "[vV][cC][cC]"))
```

# Virtuoso Power Manager User Guide

## Setup for Automatic Extraction of Power Intent

---

```
)
ground (nil
  names ("vss" "avss" "dvss" "VSS" "AVSS" "DVSS")
  regExprs ("[vV][sS][sS]" "[gG][nN][dD]" "gnd*")
```

- ❑ Select *Load Setup From Environment* and *Use Setup Changes From Environment* to load setup or change the environment setup.

### ***Related Topics***

[Registering Name-Based Supply Nets](#)

[Registering Libraries](#)

[Registering Device and Cell](#)

[Performing In-Design Checks](#)

## **Setup File Template**

```
lpSetupOptions = '(nil

;;; Supply Nets
supplyNets (nil
  monitor (nil
    names ("VDD_PROBE" "VSS_PROBE")
    regExprs ("VDD_PROBE*" "VSS_PROBE*")
  )
  excludePG (nil
    names ("OUTVDD")
    regExprs ("OUTVDD*")
  )
  ground (nil
    names ("Vss" "Vssa" "Vss_Int")
    regExprs ("[vV][sS][sS]")
  )
  power (nil
    names ("Vdd_1v8" "Vdd_3v3" "Vdd_Int")
    regExprs ("[vV][dD][dD]" "[vV][cC][cC]")
  )
)
```

## Virtuoso Power Manager User Guide

### Setup for Automatic Extraction of Power Intent

---

```
;;; Supply Net Voltages
netVoltages (
  ("Vss_Int" (0.0))
  ("Vdd_1v8" (1.8 1.0))
  ("Vssa" (0.0))
  ("Vdd_3v3" (3.3))
  ("Vss" (0.0))
  ("Vdd_Int" (3.3 1.0))
)

;;; External Switchable Nets
externalSwitchableNets nil

;;; Devices
devices (nil
  cap (
    ("analogLib" "cap" nil)
  )
  pfet (
    (nil "pmos*" nil)
    ("analogLib" "pmos*" nil)
    ("gpdk*" "pmos*" nil)
  )
  nfet (
    (nil "nmos*" nil)
    ("analogLib" "nmos*" nil)
    ("gpdk*" "nmos*" nil)
  )
  short (
    ("analogLib" "res" nil)
    ("analogLib" "rcwireload" nil
      (nil
        shortedTerminalMap (("t1" "t2") ("t3" "t4" "t5"))
      )
    )
  )
  diode (
    ("analogLib" "diode" nil
      (nil
        pTerm "PLUS"
        nTerm "MINUS"
      )
    )
  )
)
```

## Virtuoso Power Manager User Guide

### Setup for Automatic Extraction of Power Intent

---

```
    )
  )
)

;;; Transistor Terminal Names
txTermTypeNames (nil
  substrate "S BULK well SUB"
  bulk      "B BULK well SUB"
  emitter   "e E emitter"
  collector "c C collector"
  source    "s S source SOURCE Source"
  drain     "d D drain DRAIN Drain"
  gate      "g G gate GATE Gate"
  base      "b B base BASE Base"
)

;;; Library Files
libFiles (
  "./DESIGN1/LIBRTY/fast_vdd1v0_basicCells.lib"
  "./DESIGN1/LIBRTY/macro.lib"
  "./DESIGN1/TECHUPF/diode.upf"
  "./DESIGN1/TECHUPF/lshifter.upf"
  "./DESIGN1/TECHUPF/isolation.upf"
  "./DESIGN1/TECHUPF/pswitch.upf"
  "./DESIGN1/LIBRTY/macro.lib"
  "./DESIGN1/LIBRTY/VPMWS_ANA_OpAmp.lib"
)

;;; Text Files Specifying Library Files
libInputFiles nil

;;; Cell 1801 File Bindings
cell1801Bindings nil

;;; User Macro Cells
userMacroCells nil

;;; Reference Library-Cells
refLibCells nil
```

## Virtuoso Power Manager User Guide

### Setup for Automatic Extraction of Power Intent

---

```
;;; Supply Sets
supplySets (
  (nil
    supplySetName "SS_vdd3v3_vss"
    power         "Vdd_3v3"
    ground        "Vss"
  )
  (nil
    supplySetName "SS_vdd1v8_vss"
    power         "Vdd_1v8"
    ground        "Vss"
  )
  (nil
    supplySetName "SS_vddsw_vss"
    power         "Vdd_Int"
    ground        "Vss_Int"
  )
)
```

```
;;; Power Domains
powerDomains (
  (nil
    domainName      "PD_vddsw_vss"
    elements         "I4"
    primarySupplySet "SS_vddsw_vss"
  )
  (nil
    domainName      "PD_vdd3v3_vss"
    elements         "."
    primarySupplySet "SS_vdd3v3_vss"
    includeScope    t
  )
  (nil
    domainName      "PD_vdd1v8_vss"
    elements         "I0 I2"
    primarySupplySet "SS_vdd1v8_vss"
  )
)
```

```
;;; Port Attributes
portAttributes nil
```

## Virtuoso Power Manager User Guide

### Setup for Automatic Extraction of Power Intent

---

```
;;; Maximum number of similar violations to be reported
maxSimilarViolations1

;;; Use supplyStates
useSupplyStates1

;;; Supply States
supplyStates (
  ("SS1" ("Vss 0.000000" "Vdd_Int 3.300000" "Vdd_3v3 3.300000" "Vssa
0.000000" "Vdd_1v8 1.800000" "Vss_Int 0.000000"))
  ("SS2" ("Vss 0.000000" "Vdd_Int 3.300000" "Vdd_3v3 OFF" "Vssa 0.000000"
"Vdd_1v8 1.800000" "Vss_Int 0.000000"))
)

;;; Input Voltage Tolerance Lower-Bound
inputVoltageToleranceLowerBound0.100000

;;; Input Voltage Tolerance Upper-Bound
inputVoltageToleranceUpperBound0.100000

;;; Input Ground Voltage Tolerance Lower-Bound
inputGroundVoltageToleranceLowerBound0.100000

;;; Input Ground Voltage Tolerance Upper-Bound
inputGroundVoltageToleranceUpperBound0.100000

;;; In-Design Checks Filter Patterns
lprcFilters nil

;;; Missing Level-Shifter Check Severity
missingLSCheckSeverity"error"

;;; Incompatible Level-Shifter Check Severity
incompatibleLSCheckSeverity"error"

;;; Redundant Level-Shifter Check Severity
redundantLSCheckSeverity"warning"

;;; Protected Level-Shifter Check Severity
protectedLSCheckSeverity"info"
```

## Virtuoso Power Manager User Guide

### Setup for Automatic Extraction of Power Intent

---

```
;;; Unprotected Level-Shifter Check Severity
unprotectedLSCheckSeverity"error"

;;; Unreliable Level-Shifter Check Severity
unreliableLSCheckSeverity"ignore"

;;; Floating Level-Shifter Check Severity
floatingLSCheckSeverity"error"

;;; Always Enabled Level-Shifter Check Severity
alwaysEnabledLSCheckSeverity"error"

;;; Unused Enable Level-Shifter Check Severity
unusedEnableLSCheckSeverity"error"

;;; Missing Isolation Check Severity
missingISOCheckSeverity"warning"

;;; Incompatible Isolation Check Severity
incompatibleISOCheckSeverity"warning"

;;; Redundant Isolation Check Severity
redundantISOCheckSeverity"warning"

;;; Incompatible Bulk Check Severity
incompatibleBulkCheckSeverity"error"

;;; Report isolation violations for always-on-switched domain crossings
reportOnOffISOViolationsnil

;;; Check ports without any portAttributes definition in setup
checkPortsWithoutAttributesnil

;;; Report violations for all net voltages
reportLPRCViolationsForAllNetVoltagesnil

;;; Prefixes for Supply Net netSet Props
powerNetPropPrefix "vdd"
groundNetPropPrefix "vss"
pwellNetPropPrefix "vdd_sub"
```

## Virtuoso Power Manager User Guide

### Setup for Automatic Extraction of Power Intent

---

```
nwellNetPropPrefix "vss_sub"  
deppwellNetPropPrefix"vdd_sub2"  
deepnwellNetPropPrefix"vss_sub2"
```

```
;;; Project MLDB Library Name  
projectMldbLibName""
```

```
;;; Reference MLDB Library Names  
referenceMldbLibNames nil
```

```
;;; replaceExistingLibs  
replaceExistingLibst
```

```
;;; Replicates missing driver_supply_set or receiver_supply_set for input,  
output ports respectively.
```

```
replicateMissingDriverReceiverSupplySetnil
```

```
;;; Power Domain Name Prefix  
powerDomainNamePrefix"PD"
```

```
;;; Enable Automatic Creation of Power Domains  
autoCreatePowerDomainsnil
```

```
;;; Consider signal type for detecting PG nets  
considerSignalTypenil
```

```
;;; Set the mode (design/auto) for extraction  
extractionMode"design"
```

```
;;; Set how the PST/Power State are Created  
powerStateCriteria"Conservative"
```

```
;;; Set if All Off PST/Power Stated are Created  
includeAllOffStatesnil
```

```
;;; Control printing of nets identified as supply nets  
printSupplyNetInfonil
```

```
;;; Set if inout pins are allowed as LDO pins  
allowInoutLDOPinsnil
```

## Virtuoso Power Manager User Guide

### Setup for Automatic Extraction of Power Intent

---

```
;;; Set if inout pins are allowed as monitor pins
allowInoutMonitorPinsnil

;;; Delimiter for use in power intent objects like Supply Set Names
delimiter"__"

;;; View Name list for hierarchy elaboration
switchViewList"schematic symbol"

;;; Stack transistor device param names
stackTransistorDeviceParamNames""

;;; View Name list for pruning the hierarchy elaboration
stopViewList"symbol"

;;; Set if the environment options are to be loaded
loadEnvironmentOptionsnil

;;; Set if the options not overridden by the user are to be updated
pushUnmodifiedEnvOptionst

;;; Use anonymous supply set for non-annotated top level ports
topPortsHaveAnonSupplyt
)
```

### ***Related Topics***

[Registering Name-Based Supply Nets](#)

[Registering Libraries](#)

[Registering Device and Cell](#)

[Performing In-Design Checks](#)

## **Loading Power Intent Extraction Options from a File**

If you have the power intent extraction setup options in a template file, you can load them and reuse them for the same or a different design.

To load the extraction options,

1. In the Power Manager toolbar, click *Power Manager Setup*.
2. In the Power Manager Setup form, click *Load* to select the template file.
3. Browse the file. The tool reads all the extraction options and loads the settings.

**Note:** The format of the loaded setup file should match the format of a standard setup file.

4. To apply the changes, click OK.

### *Important*

The Load option adds setup information from the file to the setup form. To put on the changes, click *Apply*.

The setup can also be imported by using the `vpmlImportPowerIntentSetup` SKILL function. This can be used for batch mode processing. The common settings can also be saved in `.cadence/dfII/vpm/lpSetup.il` without the need to reload the setup. These settings can be referenced in any cellview.

### ***Related Topics***

[Saving Power Intent Extraction Options to a File](#)

[Setup File Template](#)

## **Saving Power Intent Extraction Options to a File**

You can save the power intent extraction setup options in the setup form to a template file and reuse them for the same or a different design.

To save the extraction options,

1. In the Power Manager toolbar, click *Power Manager Setup*.
2. In the Power Manager Setup form, click *Save*.
3. Browse the file. The tool saves all the extraction options and settings to the file.
4. To apply the changes, click OK.

## Virtuoso Power Manager User Guide

### Setup for Automatic Extraction of Power Intent

---

#### *Important*

A confirmation dialog is displayed when you click the Cancel button of the Setup form. It ensures that the unsaved data can be saved in time.

#### ***Related Topics***

[Loading Power Intent Extraction Options from a File](#)

[Setup File Template](#)

---

## Power Intent Import

---

If the power intent for a design is available in the required (1801) formats, you can import it to update the design with the specified power intent. For this, it is required that the cellview is editable. You can import the power intent to specify it for a cell being instantiated in the design. If you create instances of an IP block in the design for which power intent is available in a 1801 or Liberty file, you can import the file and update the design as per the power intent in the file. This helps in correctly connecting the power domains of the IP to the power domains of the top-level design. In addition, you can register special low power cells that are imported from the library.

### ***Related Topics***

[Import Flow](#)

[Redirected netSet Property Creation and Optimization](#)

[Tie Connection Resolution](#)

[Handling of Low Power Special Cells](#)

[Support of Hierarchical 1801 for Import Flow](#)

[Removing Imported Power Intent](#)

## Import Flow

You can import the power intent and utilize it in the following scenarios:


- Use the power intent specified for a design in the top-down power propagation scheme. If you have a hierarchical schematic design for which the power intent is available in a 1801 file, you can import the 1801 file and update the power connectivity of each hierarchical block used in the design as per the power intent. This enables in correctly connecting the power domains of the IP to the power domains of the top design (SOC or a chip).

## Virtuoso Power Manager User Guide

### Power Intent Import

- If you have a digital block with a Verilog netlist available from a digital place and route tool, supply connectivity can be built for this block by using the Cadence Verilog Import flow along with the initial imported power intent available for SOC where the digital block is integrated. This defines the power requirements across digital and analog boundaries.
- Register special low power cells that are imported from a 1801 special cell definition file. The registered details are consumed by all the designs that use this file for creating the power connectivity of the cells as per their power domains. The special cell definition file is registered to be included as per the setup. For details, refer to [Registering Supply Set and Power Domain](#).

The illustration below gives an overview of the import flow.



### Import Flow in Virtuoso Power Manager

Here are the key stages of the import flow.

- Traversal of design hierarchy to find supply net expressions and explicit terminals.

Elaboration and traversal of the complete design hierarchy is done to identify the standard and special cells that have an associated Liberty model or a special cell definition file. This is done for the supply and topology recognition. These cells are considered as stop cells and the tool does not traverse through these cells for power/ground nets. Only the top level is read to collect the supply information (inherited nets or explicit terminals), which is further mapped to the power/ground information specified in the Liberty model or the special cell definition file.

- Standard and special cells identification using Liberty models or the 1801 special cell definition file.

# Virtuoso Power Manager User Guide

## Power Intent Import

---

The special cell rules are read as specified in the input 1801 file to create the corresponding supply connections and resolve them for the top supplies. In a hierarchical design for cells that do not have an associated Liberty or a special cell definition, supply nets information is gathered from the different levels of hierarchy. Power Manager traverses down the hierarchy to the level where it finds supply nets of inherited nets (Net Expressions) or explicit supply terminals.

- Reading the input 1801 power specification.

The power intent is read from the 1801 file and is updated in the design with all the 1801 commands supported by Power Manager. All unsupported commands or unsupported arguments of the supported commands are flagged in the log.

- Creation and optimization of the redirected netSets.

netSet properties are created in the design hierarchy, wherever required. This enables the top-level block to be instantiated in another top-level SoC schematic. The inherited pins are created in the block schematic. The inherited terminals have the same name as the supply nets in the 1801 file. The tie connections are resolved in the design hierarchy.

- Creation of the top-level supply ports and supply nets.

Supply pins are created corresponding to the power domain nets and global nets during 1801 import by reading the `create_supply_port` and `create_supply_net` commands for a successful LVS check.

Refer to the following scenarios that are considered while creating the pins.


- ❑ If a pin already exists and it belongs to the same net as mentioned in the 1801 file, it is used.
- ❑ To create an inherited pin, a pin that exists in the same net as mentioned in the 1801 file is used. However, the pin net should be global and should match the power domain net for which the pin needs to be created. The pin is converted into an inherited pin by associating a terminal net-expression with the existing pin. If the existing pin is already an inherited pin but with the different net-expression, the net-expression is replaced.
- ❑ All pins created during the 1801 import are removed when you click *Remove Power Intent*. If any pin existed prior to import and was converted to an inherited pin or the net-expression was changed, it is converted back to a normal pin or the original net-expression is restored, respectively.
- ❑ For the 1801 import flow, pins are not created in the design schematic for the supply nets that do not have a corresponding `create_supply_port` command in the input 1801 file. These supply nets are internally generated supply nets that have a corresponding `create_supply_net` command in the input 1801 file.

## Virtuoso Power Manager User Guide

### Power Intent Import

---

The direction of the pins created aligns with the direction specified in the `create_supply_port` command in the input 1801 file.



It is recommended that after importing a 1801 file, you run *Check – Hierarchy* or the *File – Check and Save*. These commands create nets corresponding to the netSet properties and set the signal type of power nets and ground nets according to the power intent.

### ***Related Topics***

[Importing Power Intent](#)

[Redirected netSet Property Creation and Optimization](#)

[Tie Connection Resolution](#)

[Handling of Low Power Special Cells](#)

[Support of Hierarchical 1801 for Import Flow](#)

[Removing Imported Power Intent](#)

## **Importing Power Intent**


To import the power intent for the currently open cellview:

## Virtuoso Power Manager User Guide

### Power Intent Import

---

1. Click *Power Manager – Import Power Intent*. It opens the Import Power Intent form. The currently opened cellview details are specified in the form automatically.



2. Specify the switch view list sequence as mentioned in the setup.
3. Specify the name of the 1801 file in the *1801 File* field. Alternatively, browse to select the 1801 file to import the power intent for the design.
4. Select the *Resolve Top netSets* check box to control the creation of the global net along with the port creation.
5. Click *OK*.

## Virtuoso Power Manager User Guide

### Power Intent Import

---

The following illustration shows the output for the supply port VDDA import when `createPinsOnImport` has been set and *Resolve Top netSets* is deselected.



#### *Important*

Alternatively, the `vpmImportPowerIntent` SKILL function has been provided to import the power intent information for a cellview.

#### ***Related Topics***

[vpmImportPowerIntent](#)

[Import Power Intent Form](#)

[Miscellaneous Settings](#)

[Redirected netSet Property Creation and Optimization](#)

[Tie Connection Resolution](#)

[Handling of Low Power Special Cells](#)

[Support of Hierarchical 1801 for Import Flow](#)

[Removing Imported Power Intent](#)

## **Redirected netSet Property Creation and Optimization**



While creating the supply connectivity across the design hierarchy, there could be conflicts where the same net expression property gets resolved to different supply nets at the top. For correct supply connectivity resolution in such scenarios, a redirecting netSet property is created and an optimization algorithm is executed to ensure that the redirection of netSet property happens across the design hierarchy only where required. Redirection is done where having a pure global net expression can cause issues in the supply connectivity across the design hierarchy. This ensures minimum number of netSet properties at the top instance.

Wherever the property name is created, the prefix is added as mentioned in the setup to identify various `pg_type`. Redirected property name is realized as

# Virtuoso Power Manager User Guide

## Power Intent Import

[@Prefix\_cellname\_count:%:topsuplyname!]. The illustration below represents the creation of redirected netSet property in the design.



In a design if there is a hierarchy and no Liberty stop cell, Power Manager traverses to the level where net expressions exist. Or, if the net expressions are already redirected to have different property names, it is the reference for the tool to make the connectivity.

### ***Related Topics***

[Importing Power Intent](#)

[Redirected netSet Property Creation and Optimization](#)

[Tie Connection Resolution](#)

[Handling of Low Power Special Cells](#)

[Support of Hierarchical 1801 for Import Flow](#)

[Removing Imported Power Intent](#)

## **Tie Connection Resolution**


In a Verilog netlist if an input pin of a standard cell instance or a special low power cell, such as level shifter or isolation cell instance, is connected to a numerical constant `1'b1` or `1'b0`, the input pin gets connected to a global supply net in the schematic created after Verilog import using Verilog In. The name of the global supply net is specified at the time of Verilog import. After Verilog import, all such input pins connect through a common wire creating tie connections. The label of the common wire matches the global supply net name.

To avoid shorting of nets after importing the 1801 file, it is important that all such pins are connected to wire stubs with a label. However, the wire stubs are not physically connected to each other. To achieve this, use the two connect by name options, *Connect Power Net By Name* and *Connect Ground Net By Name*, during Verilog import. This connects each tied-off input pin with the wire stub that has a label. It enables you to modify the tied-off input pin

## Virtuoso Power Manager User Guide

### Power Intent Import

connections without creating incorrect connectivity in the design through shorting of the nets during the 1801 import. Use create Net Expression as per the design requirement.



To resolve the tie connections of various instances, all the labels that require an update are identified during import. The labels on the wire stubs that are attached to the tied-off input pins are updated. These labels present at the top level or in the lower level block are identified for updates based on the following conditions:

- The label is attached to a wire, which has one end point floating (not connected to anything) and the other end point connected to an instance.
- The wire net name is registered as a power or ground in a setup.
- Wire nets must have a netType property associated. The power nets must have the netType property as `supply1`. The ground nets must have the netType property as `supply0`.


Wire net having the netType property is one of the conditions because it ensures that the label and wire have been added using Verilog In.

# Virtuoso Power Manager User Guide

## Power Intent Import

It avoids modification of labels in standard cells, for example, an inverter schematic can have terminal MOS devices with bulk/source/drain terminals connected to wire stubs that have a label, and the wire nets are registered as power or ground in the setup.


Once the target wire label is identified, the 1801 import flow processes these nets to create unique inherited tie nets for each occurrence of such nets in the entire design hierarchy, for example, `tie0!` or `tie1!`. This prevents shorting of nets during the import flow. The tie net expression is further resolved based on whether it is a top-level net or a sub-block net.



# Virtuoso Power Manager User Guide

## Power Intent Import


- For tie net at the top level, the instance pin to which it is connected is identified along with the related power and ground net of the connected instance pin. The wire labels are updated according to the 1801 file definition.



## Virtuoso Power Manager User Guide

### Power Intent Import

- For a tie net in a sub-block, the instance pin to which it is connected is identified along with the related power and ground net of the connected instance pin. The tie net expression is resolved to its final power or ground value based on a netSet property.



The final resolution of the tie connections in schematic designs to the appropriate power and ground nets mentioned in the 1801 file is aligned to the following rules:

- For standard cell instances, the tie connection at the input pin is resolved with the power/ground net of the power domain of the instance.
- For isolation instances, the data pin with tie connection is resolved with the power/ground net of the power domain in which the isolation cell is located.
- For isolation instances, the enable pin with tie connection at the input pin is resolved with the power or ground net of the always-on power domain of an isolation instance. This depends on the `-isolation_supply_set` or `default_isolation` arguments according to location or domain.

- For level shifter instances, the data pin with tie connection is resolved with the power/ground net of the `input_supply_set` argument.
- For enabled level shifter instances, the enable pin with tie connection is resolved with the power or ground net of the output power domain of the enabled level-shifter instance. If the `output_supply_set` argument is not available, the supply set of the receiving logic is considered.
- For isolation and level shifter combo cell instances, the enable pin with tie connection is resolved with the power/ground net of the input power domain of the enabled level shifter instance.

### ***Related Topics***

[Importing Power Intent](#)

[Redirected netSet Property Creation and Optimization](#)

[Handling of Low Power Special Cells](#)

[Support of Hierarchical 1801 for Import Flow](#)

[Removing Imported Power Intent](#)

## **Handling of Low Power Special Cells**

The 1801 import flow supports the following low power special cells:

### ■ **Level Shifter**

Import 1801 flow supports different level shifter configurations, such as single rail, dual rail and enabled single /dual rail (combo cell). For each level shifter instance, the load and drivers along with their power domains are determined and the netSet properties are created based on the criteria mentioned below.

- If a level shifter cell is connected to a standard cell or port at both ends, the load and driver domains are used to resolve PG connections.
- If a level shifter instance is a multi-rail cell, the driver domain resolves the input supply connections and the load domain resolves the output supply connections. Level shifter rule specified in the input 1801 file enables in determining the load and the driver domains. The rule is considered to find the supply set based on `input_supply_set` and `output_supply_set` argument. Level shifter rules are specified in input 1801 as:

# Virtuoso Power Manager User Guide

## Power Intent Import

---

```
set_level_shifter ls_rule -domain pd_ls -applies_to inputs -rule
low_to_high -location self -input_supply_set SS_VDD_VSS -output_supply_set
SS_VDDA_VSS
```

If not specified, Power Manager finds the driver and load supply set for the level shifter by traversing the design path and resolving the connectivity accordingly.

- ❑ If a level shifter instance is a single-rail cell, the load domain resolves the output PG connections. `input_signal_level` is required in the Liberty model of the level shifter to identify the cell type as single rail level shifter.
- ❑ If a level shifter instance is connected to an isolation cell at one end, the load or driver domain on the other end is determined. If the driver domain is known, it resolves the input supply connections. If the load domain is known, it resolves the output supply connections.

**Note:** A single-rail level shifter cell has only output supply.

- ❑ If a level shifter instance is connected to an isolation cell at one end, the power domain for the end connected to the isolation instance is determined from the isolation instance. Therefore, the power domain at the isolation cell intersection is the same as the power domain of the isolation cell itself.

### ■ Isolation Cell

Initially, the load and driver of the isolation cell are traced and then, the netSet properties are created based on the criteria mentioned below.

- ❑ If an isolation cell is connected to a standard cell or a port on both the ends, the power domains of the load as well as the driver are used to resolve the PG connections and create netSet properties.
- ❑ If an isolation cell instance is a multi-rail cell and has a switchable power or ground pin, then the switchable domain is used to resolve the switchable PG connections. The non-switchable domain resolves the non-switchable PG connections.
- ❑ If an isolation cell instance is a single-rail isolation cell, only one of the load or driver domain that is non-switchable is used to resolve the PG connections. The isolation rule specified in input 1801 file assists in determining the load and the driver domains. The rule will be considered to find a supply set based on `isolation_supply_set` defined in the isolation rule. Isolation rules are specified in input 1801 file as:

```
set_isolation ISO -domain PD_VDD_VSS -location self -elements {I1/In} -
isolation_supply_set SS_VDD_VSS -isolation_signal I0/en -isolation_sense
high -location self
```

**Note:** `isolation_supply_set` is required if `default_isolation` is not mentioned in the power domain stated in the input 1801 file.

**Note:** You can provide an expression containing multiple pins for enable in the `tech.upf` file for isolation cells and level shifter cells. For example, `define_isolation_cell -cells ISOHX1_OFF -enable "EN1&EN2&!EN3" -power VDD -ground VSS.`

## ■ Power Switch

For power switch, the load and drivers supply along with the control net are determined and the netSet properties are created accordingly. The power switch rule specified in input 1801 file enables in determining the load and the driver domains. The rule is considered to find a supply set based on `input_supply_port`, `output_supply_port` and `control_port`.

Power switch rules are specified in the input 1801 file as:

```
create_power_switch I3_I0 -output_supply_port { VDD VDDSW } -input_supply_port
{ ExtVDD VDD } -control_port { PSO psw_en } -on_state { on ExtVDD {!PSO} }
-off_state { off PSO } -domain PD_TOP
```

If the `create_power_switch` has a `-instance` option, the name of the switch instance(s) are provided that are covered by the power switch rule. If the `create_power_switch` has a `-domain` option, the power switch rule targets all power switches that are inserted within the domain boundary.

## ***Related Topics***

[Importing Power Intent](#)

[Redirected netSet Property Creation and Optimization](#)

[Tie Connection Resolution](#)

[Support of Hierarchical 1801 for Import Flow](#)

[Removing Imported Power Intent](#)

## **Support of Hierarchical 1801 for Import Flow**

The import 1801 flow in Power Manager also supports a hierarchical 1801 input file. A hierarchical 1801 has the `load_upf` and `set_scope` commands which set the scope to each of the specified list of instances and executes the set of 1801 commands in the child 1801 file, specified as the argument of the `load_upf` command. Upon return, the current scope is restored to what it was prior to invocation. Supply nets and ports will be created for `load_upf/set_scope` block, based on the `create_supply_net` and

# Virtuoso Power Manager User Guide

## Power Intent Import

---

`create_supply_port` commands mentioned in the parent 1801 file, along with that, it will also obey the settings for `createExtractionLogFile` and `ResolveTopNets`.

For all the instances in the design, domain assignment is based on `create_power_domain` and if no element has the power domain specified, it will belong to default power domain. In case there is no default power domain in the scope, then its upper scope default power domain will be looked at to assign the power domain.

## Honoring Command Sequence and Precedence

The traversal of the input 1801 file in the import flow follows a set of the below-mentioned rules related to the command sequence and their precedence.

- Any explicit assignment of the elements (instances) in the `create_power_domain` command takes precedence over the extent that includes elements (instances) as a part of that power domain.

If there is an existing explicit domain assignment with `create_power_domain` in the elements section, irrespective of the ordering of `create_power_domain`, `set_scope`, or `load_upf` commands, the precedence of scope is defined by the nearest ancestor that has an explicit domain assignment using `create_power_domain`.

This can be shown in the following case considering the sequence of commands in the input 1801file:

```
set_scope "/"
create_power_domain PD2 -elements {I0/I2} ...
create_power_domain PD1 -element { . } ....
set_scope "I0"
create_power_domain PD3 -elements { . } ...
```

**Result:** I0/I2 gets assigned to the power domain PD2 and not PD3

- Explicit assignment of multiple domains to the same instance is an error and 1801 stops the import process. This can be shown in the following case:

```
set_scope "/"
create_power_domain PD1 -elements {I0} ...
set_scope "I0"
create_power_domain PD2 -element { . } ...
```

**Result:** Error case

- `connect_supply_net` always takes precedence over `create_power_domain`. If there are more than one `connect_supply_net` commands for the same supply net, the last command in the order is honored. In case of multiple `connect_supply_net` commands, the last command is applicable.

# Virtuoso Power Manager User Guide

## Power Intent Import

---

```
set_scope "/"
create_power_domain PD1 -elements {I0} ...
set_scope "I0"
create_power_domain PD2 -element { . }...
```

**Result:** I0/vdd is connected to VDD2

### ***Related Topics***

[Importing Power Intent](#)

[Redirected netSet Property Creation and Optimization](#)

[Tie Connection Resolution](#)

[Handling of Low Power Special Cells](#)

[Removing Imported Power Intent](#)

## **Removing Imported Power Intent**

To remove the updates done in the design using Import 1801 flow, which include newly created pins, nets, net expressions, and netSet properties on the blocks, you can use the Remove Power Intent option. This removes these objects and restores the previous state of the design before the importing the power intent. This can be accessed from the Power Manager menu and the Power Manager toolbar.

To remove the power intent information from a design:

1. Click *Launch – Power Manager – Remove Power Intent*.
2. Click *Yes*.

Alternatively, use the [vpmRemoveImportedPowerIntent](#) SKILL function for removing the power intent.

### ***Related Topics***

[Importing Power Intent](#)

[Redirected netSet Property Creation and Optimization](#)

[Tie Connection Resolution](#)

# Virtuoso Power Manager User Guide

## Power Intent Import

---

[Handling of Low Power Special Cells](#)

[Support of Hierarchical 1801 for Import Flow](#)

# Virtuoso Power Manager User Guide

## Power Intent Import

---

---

## Running In-Design Checks

---

The in-design checks aim to provide hints to designers for multiple design guidelines or checks and helps in improving the efficiency of the design development cycle. Such checks help checking complex mixed-signal designs that have multiple voltage islands, an increased fusion of analog and digital blocks, more interfaces to check within analog blocks, an increased use of complex power distribution, different modes for achieving power savings, and the use of third-party IPs in various forms. You can also generate signal information for the design, which can be used as a good debugging aid to analyze different power domain crossings in a design.

In-design checks can be run on any physical design schematic having complete power connectivity. Designs that have the power connectivity introduced post the 1801 Import flow are also suitable candidates for running in-design checks.

The In-Design Checks functionality includes the following structural checks:

- Low power checks
  - Level Shifter Checks
  - Isolation Checks
- Bulk Checks

### ***Related Topics***

[Level Shifter Checks](#)

[Isolation Checks](#)

[Bulk Checks](#)

[Checking a Design in Foreground Mode](#)

[Checking a Design in Background Mode](#)

[Loading the Violations Database](#)

## Virtuoso Power Manager User Guide

### Running In-Design Checks

---

[Filtering Violations](#)


[Generating Signal Information](#)

## Defining the Severity of Design Checks

Power Manager through its in-design checking functionality performs various static low power structural checks for level shifters and isolation cells. It also aids in checking for invalid connectivity of bulk node for transistors used in the design by performing the bulk checks.

To define the severity for the checks:

1. On the *In-Design Checks* tab of the Power Manager Setup form, select the Level Shifter or Isolation tab.
2. Specify the severity level for various low power checks in the *Severity* section.



### ***Related Topics***

#### Level Shifter Checks

[Isolation Checks](#)

[Bulk Checks](#)

[Checking a Design in Foreground Mode](#)

[Checking a Design in Background Mode](#)

[Loading the Violations Database](#)

[Filtering Violations](#)

[Generating Signal Information](#)

## Level Shifter Checks

The following checks are performed for various types of level shifters in a design.

### ■ Missing Level Shifter check

Checks all the data connections for voltage compatibility. If the voltage values for driver and receiver are not compatible, an error is generated. In this check, the type of missing level shifter (high-to-low or low-to-high) is reported. The driver supplies might be MOS drain terminals, standard cell output, or output macro domain ports. Loads can be MOS gate terminals, standard cell input, or macro domain ports. In addition, domain crossings operating at different voltages without level shifters are reported in one of the following scenarios:

- ❑ The driver power voltage is less than the receiver power voltage by the lower bound input voltage tolerance.
- ❑ The driver power voltage is more than the receiver power voltage by the upper bound input voltage tolerance.
- ❑ The driver ground voltage is less than the receiver ground voltage by the lower bound ground input voltage tolerance.

## Virtuoso Power Manager User Guide

### Running In-Design Checks

- ❑ The driver ground voltage is more than the receiver ground voltage by the upper bound ground input voltage tolerance.




- ❑ The driver voltage value is less than the maximum device voltage.

## Virtuoso Power Manager User Guide

### Running In-Design Checks


- The driver voltage is less than the receiver voltage



## Virtuoso Power Manager User Guide

### Running In-Design Checks

- No maximum device voltage found.




- The device-specific maximum device voltage value has been defined. The violations are reported at:
- Pass-tx gate (exceeds maximum device voltage)

## Virtuoso Power Manager User Guide

### Running In-Design Checks

- M9 and M10 gates (exceeds maximum device voltage)




- The device-specific tolerance value has been defined. The violations are reported at
- Pass-tx gate (missing level shifter)
- M9 and M10 gates (exceeds maximum device voltage)

# Virtuoso Power Manager User Guide

## Running In-Design Checks


- No violations reported at pass-tx source/drain



## Virtuoso Power Manager User Guide

### Running In-Design Checks

- Negative voltage with common ground supply. The violations are reported for PM1, NM1 (exceeds maximum device voltage)




- Tolerance Settings

## Virtuoso Power Manager User Guide

### Running In-Design Checks

You can define the lower and upper tolerance values for input and input ground voltages in the *Tolerance* section.



The default value of the lower limit of the input power and input ground voltage is  $-0.10$ . It should be less than or equal to 0.

The default value of the upper limit of the input power voltage and input ground voltage is  $0.10$ . It should be greater than or equal to 0.

The missing level shifter check also supports the following:

- User-defined Registering Port Attributes for checking the boundary ports.
- Supply States for explicit voltage values.

**Note:** Power states that are OFF are not considered for reporting missing level shifter errors.

# Virtuoso Power Manager User Guide

## Running In-Design Checks

### ■ Incompatible Level Shifter check

In this check, all domain crossings at different operating voltages are checked for the level shifters voltage ranges. An error is reported if operating voltages are found incompatible, for example, high level shifters in a low-to-high crossing or conversely.


Incompatibility in operating voltages can arise due to the following:

- ❑ Voltage levels of signals

This checks for incompatible driver or receiver for a data pin with respect to input or output supply voltage range for a level shifter.

- ❑ Voltage levels of supply

This checks for incompatibility of level shifter supplies with respect to the input or output voltage range supported by the level shifter.



### ■ Redundant Level Shifter check


All domain crossings with level shifters at the same operating voltages are reported. In addition, the domain crossings at the macro boundary with a redundant level shifter are reported.

**Note:** A valid level shifter in one supply state is not considered redundant in any other

# Virtuoso Power Manager User Guide


## Running In-Design Checks

power state.



### ■ Protected Level Shifter check

The data is protected by using an enable signal. The protected level shifters in design along with their enable condition are highlighted.



### ■ Unprotected Level Shifter check


An unprotected dual rail level shifter is reported when all the following conditions are true:

- Level shifter instance has no enable pin.
- One domain of the level shifter instance is in the OFF state.

# Virtuoso Power Manager User Guide


## Running In-Design Checks

- ❑ The second domain of level shifter instance is in ON state.



### ■ Floating Level Shifter check

The floating level shifters have their enable signal evaluated as floating. During the check, the level shifter is reported if its enable input can be traced to a floating value. While performing the in-design checks, the tool should ignore all supply states where all supplies are in OFF state. The tool also ignores all supply states in which no power supply or no ground supply is in the ON state. An information message is issued to indicate that the supply states are ignored.




### ■ Potentially Floating Level Shifter check

This check identifies if a level shifter is driven by logic elements, such as an inverter or buffer, which have their input tied to a power net and the supply is in the OFF state. Such a level shifter cannot be considered as floating because the supply net could have carried

# Virtuoso Power Manager User Guide

## Running In-Design Checks

some charge while in the ON state and could be slowly discharging towards 0V. This discharge might enable PMOS gates and clamp the level shifter. Consequently, such level shifter instances are categorized as potentially floating level shifters.




### ■ Always Enabled Level Shifter check

This check highlights the level shifters that have the enable pin tied to a fixed supply voltage and therefore, the state of the level shifter never changes. It keeps the data output always clamped. While trying to determine the enable expressions for enabled level shifters, the sense value for a signal (an occurrence net) is used if the corresponding module net and the module have a signal-sense registered using the `define_signal_attribute`.

# Virtuoso Power Manager User Guide


## Running In-Design Checks

and the occurrence net (top level net) for at least, one of the off\_supplies mentioned in the definition, is in off state. If there are conflicting definitions across the span of the net, a warning message is issued.



### ■ Unused Enable Level Shifter check

This check highlights a level shifter that has the enable pin tied to a fixed supply voltage of opposite polarity. In this case, the enable pin is not used effectively. The unused enable level shifters have an enable signal tied to a fixed voltage and data output is never clamped.



### ***Related Topics***

[Defining the Severity of Design Checks](#)

[Isolation Checks](#)

# Virtuoso Power Manager User Guide

## Running In-Design Checks

### Bulk Checks

### Checking a Design in Foreground Mode

### Checking a Design in Background Mode

### Loading the Violations Database

### Filtering Violations


### Generating Signal Information

## Isolation Checks

The following checks are performed for various types of isolation or level shifters in a design.

### ■ Missing isolation check

Reports all domain crossing involving at least one switchable domain and another switchable or always on domain without isolation. The driver supply could be MOS drain terminals, standard cell output, or output macro domain ports. Similarly, load could be MOS gate terminals, standard cell input, or macro domain ports.



In addition, reports violations for the following scenarios when a receiver supply can be floating if the driving isolation or level shifter cell supply is off.

## Virtuoso Power Manager User Guide

### Running In-Design Checks

---

- ❑ A level shifter output is considered floating if the level shifter output supply is off.
- ❑ A non-enabled isolation cell output is considered floating when the isolation supply is off.
- ❑ A NAND isolation output can be considered valid if ground supply is off and enable driver supply is on and the output pin is not specified as non-floating.
- ❑ A NOR isolation output can be considered valid if power is off and enable driver supply is on and the output pin is not specified as non-floating.
- ❑ Any other enabled isolation cell output is always considered floating when the isolation supply is off.

The check reports violations for the following scenarios where level shifter and isolation cell data pins can be floating if the driver output supply is floating.

- ❑ A non-enabled level shifter input data pin that cannot accept a floating input.
- ❑ An enabled level shifter data pin that can receive a floating input if the supply for the enable driver is on and the level shifter data pin is not specified as non-floating. A non-enabled isolation cell data pin that cannot accept a floating input if the cell is single rail.
- ❑ A non-enabled isolation cell data pin that receives a floating input if the cell is dual rail and if the backup supply is on and the isolation cell data pin is not specified as non-floating.
- ❑ An enabled isolation cell data pin that can receive a floating input if the supply for the enable driver is on and the isolation cell data pin is not specified as non-floating.

#### ■ **Incompatible isolation check**


Reports violation for an enabled isolation or level shifter cell if the related supply for cell's enable pin is on but the supply for the enable pin's driver is off.

#### ■ **Redundant isolation check**

# Virtuoso Power Manager User Guide

## Running In-Design Checks

Reports an error if the driver and receiver of an isolation cell are switched on and off simultaneously or they are never turned off. This helps in optimizing the design area and power by indicating the redundant circuit elements.



### Related Topics

[Defining the Severity of Design Checks](#)

[Level Shifter Checks](#)

[Bulk Checks](#)

[Checking a Design in Foreground Mode](#)

[Checking a Design in Background Mode](#)

[Loading the Violations Database](#)

[Filtering Violations](#)

[Generating Signal Information](#)

## Bulk Checks


The incompatible bulk check flags transistors, which have the bulk terminal-related supply incompatible with the related supply of its source or drain terminal.

- For a P-type transistor, a violation is reported in the following scenarios:
  - The voltage for the related bulk supply net is less than the voltage for the related source or drain supply net.

# Virtuoso Power Manager User Guide

## Running In-Design Checks

- ❑ The bulk node is OFF compared to either the source or drain terminal that are fully ON in a particular supply state.
- For an N-type transistor, a violation is reported in the following scenarios:
  - ❑ The voltage for the related bulk supply net is more than the voltage for the related source or drain supply net.
  - ❑ The bulk node is fully ON compared to the source or drain terminal that are OFF in a particular supply state.



### ***Related Topics***

[Defining the Severity of Design Checks](#)

[Level Shifter Checks](#)

# Virtuoso Power Manager User Guide

## Running In-Design Checks

---

### Isolation Checks

#### Checking a Design in Foreground Mode

#### Checking a Design in Background Mode

#### Loading the Violations Database


#### Filtering Violations

#### Generating Signal Information

## Checking a Design in Foreground Mode

To run the In-Design Checks in foreground mode, perform the following steps:

1. Load the setup in the Power Manager Setup form.
2. Choose *Power Manager – Run In-Design Checks*. The Run In-Design Checks form is opened.



3. Select the appropriate value for the *Scope* field. The *Library*, *Cell*, *View*, and *Instance Path* are read-only fields.

You should choose the *Current Cellview* option in the following scenarios:

- You have a Power Manager setup for the specific design. The setup includes specific information for the design, such as supply states, supply nets, net voltage, and so on.

# Virtuoso Power Manager User Guide


## Running In-Design Checks

- ❑ You want to validate the complete design.

If you are making changes to a part of an existing design and you want to know how the changes in the hierarchy affect the accuracy of the design within that sub-hierarchy, you can validate a portion of the design by choosing the *Hierarchical Instance* option in the following scenarios:

- ❑ You have a Power Manager setup for the top-level design, which includes all relevant information about supply states, supply nets, net voltage, and so on.
- ❑ You want to descend to the lower-level cell and want the scope of the design checks limited to the hierarchy of the lower cell and its interface connections.

4. Click *OK*. An `inDesign.log` file, such as the one shown here, appears.



```
PS0lib.Concurrent_Switching.inDesign.log
File Edit View Help
#####
# In-Design Checks Report
#####
# Design      : PS0lib/Concurrent_Switching/schematic
# Program Version : @(#)CDS: virtuoso version ICADVM20.1-64b 09/02/2020 17:21 (nofchw095) $
# Program Sub-Version : ICADVM20.1-64b.main.61
# Start Time   : Thu Sep  3 13:14:36 2020
# Finish Time  : Thu Sep  3 13:14:36 2020
#####
##### In-Design Checks Violations Summary #####
#####
Errors          : 9
Warnings        : 0
Informations    : 0
Filtered        : 0

Missing Level Shifters      : 1
Redundant Level Shifters    : 0
Floating Level Shifters     : 0
Unused Enable Level Shifters : 0
Always Enabled Level Shifters : 0
Protected Level Shifters    : 0
Unprotected Level Shifters  : 0
Unreliable Level Shifters   : Ignored
Incompatible Level Shifters : 8
Missing Isolations         : 0
Redundant Isolations       : 0
Incompatible Isolations    : 0
Incompatible Bulk Supply    : Ignored

##### Missing Level Shifter Violation Details #####
#####
(1) : *ERROR* (LP-5054): Could not find 'high-to-low', 'power' level shifter for net 'I5/p' in cellview 'PS0lib/Concurrent_
3 L1
```

### ***Related Topics***

[Defining the Severity of Design Checks](#)

[Level Shifter Checks](#)

[Isolation Checks](#)

[Bulk Checks](#)

[Checking a Design in Background Mode](#)

[Loading the Violations Database](#)

[Filtering Violations](#)

[Generating Signal Information](#)

## **Checking a Design in Background Mode**


While checking a design, you can enable background mode to perform other processes in the same Virtuoso session while the in-design checks are run in the background. To run the In-Design Checks in background mode, perform the following steps:

1. Set the [runIDCInBackground](#) environment variable to `t`.
2. Load the setup in the Power Manager Setup form.

## Virtuoso Power Manager User Guide

### Running In-Design Checks

3. Choose *Power Manager – Run In-Design Checks*. The Run In-Design Checks (Non-Blocking) form is opened.




4. Select the appropriate value for the *Scope* field. The *Library*, *Cell*, *View*, and *Instance Path* are read-only fields.
5. Specify the run directory.
6. Select *Overwrite Existing Directory (directory will be removed)* to replace any existing run directory with the same name.
7. Click *Start* to initiate the In-Design Checks run in the background. Only the on-disk copy of design is used for running the checks.

## Virtuoso Power Manager User Guide

### Running In-Design Checks

The *View Run Log* button is enabled to view the replay log for the background process.



8. [Optional] View the *Run Status* field and the graphic on the form being updated as the run progresses.
9. Click the *View Audit Log* button when the background process has completed successfully to view the audit log for the In-Design Checks run. Similarly, click the *Load*

# Virtuoso Power Manager User Guide

## Running In-Design Checks

*Violations* button when the background process has completed to view the backannotated violations on the design.

The screenshot shows the 'Run In-Design Checks' dialog box. At the top, the title bar reads 'Run In-Design Checks'. Below the title bar, there are several input fields and options:


- Scope:** Radio buttons for 'Current Cellview' (unselected) and 'Hierarchical Instance' (selected).
- Library:** Text field containing 'DESIGN\_WORKSHOP\_VPM'.
- Cell:** Text field containing 'DESIGN1'.
- View:** Text field containing 'schematic'.
- Instance Path:** Text field containing '/'. Below this field, the text 'On-disk copy of the design will be used for checks.' is displayed.
- Run Directory:** Text field containing './idcRun.DESIGN\_WORKSHOP\_VPM.DESIGN1'. To the right of the field is a button with three dots.
- Overwrite Existing Directory (directory will be removed):** A checkbox that is currently unchecked.
- Run Status:** Text field containing 'COMPLETED, at Apr 13 14:45:37 2021'.

Below the input fields, there is a schematic diagram of a power network with a green checkmark overlaid on it. To the right of the diagram are three buttons: 'Load Violations' (with a warning icon), 'View Run Log' (with a document icon), and 'View Audit Log' (with a list icon). At the bottom of the dialog, there are four buttons: 'Start' (highlighted in red), 'Stop', 'Close', and 'Help'.

## Virtuoso Power Manager User Guide

### Running In-Design Checks

- [Optional] Click *Stop* to halt the active in-design checks run in the background if an incorrect version of design is used or some updates need to be done in the design. The run is stopped after you confirm.



- [Optional] Click *Close* to halt the active in-design checks run in the background and close the form. The run is stopped and the form is closed after you confirm.

**Note:** If you specify the run directory of a specific Virtuoso session in some other Virtuoso session, the last saved status of the run is loaded. Subsequently, you can view the last results, related setup file, and violations. You can complete the run if it was not completed earlier.

### ***Related Topics***

#### Defining the Severity of Design Checks

[Level Shifter Checks](#)

[Isolation Checks](#)

[Bulk Checks](#)

[Checking a Design in Foreground Mode](#)

[Loading the Violations Database](#)

[Filtering Violations](#)

[Generating Signal Information](#)

## **Loading the Violations Database**


The errors generated are cross-probed to the accurate schematic location to enable the editing and correction. While analyzing violations using the Annotation Browser, the mode in which a marker cellview is opened depends upon the Annotation Browser options. This means that it is possible that the marker cellview is opened in edit mode even if the top cellview or current design is opened in read-only mode. If a marker cellview is opened in edit mode and you perform any action that attempts to close the marker cellview, you are prompted to save or discard the changes.

To load the violations database, perform the following steps:

# Virtuoso Power Manager User Guide

## Running In-Design Checks

1. Choose *Power Manager – Load Violations*.




2. Select the appropriate value for the *Scope* field. The *Library*, *Cell*, *View*, and *Instance Path* are read-only fields.

# Virtuoso Power Manager User Guide

## Running In-Design Checks


- Specify the file name and click *OK*. The Annotation Browser displays the violations in the design.



## Virtuoso Power Manager User Guide

### Running In-Design Checks

- Specify the scope of the violations, which is based on the cellview hierarchy, to be displayed in the Annotation Browser.



Annotation Browser provides easy and in-context error browsing mechanism through context menu for the violation nodes.


Here is the list of the levels until which you can probe for various nodes:

- Right-click the Always Enabled Level Shifter node. Then, click *Probe – Inst/Driver/ Receiver*.
- Right-click the Incompatible Level Shifter Signal node. Then, click *Probe – Net/Inst/Driver/ Receiver*.

## Virtuoso Power Manager User Guide

### Running In-Design Checks

- Right-click the Incompatible Level Shifter Supply node. Then, click *Probe – Inst.*




- Right-click the Missing Level Shifter node. Then, click *Probe – Net/Driver/Receiver.*

## Virtuoso Power Manager User Guide

### Running In-Design Checks

- ❑ Right-click the Protected Level Shifter node. Then, click *Probe – Inst/ Driver/ Receiver*.



- ❑ Right-click the Redundant Level Shifter node. Then, click *Probe – Inst*.
- ❑ Right-click the Unused Enabled Level Shifter node. Then, click *Probe – Inst/Driver/ Receiver*.
- ❑ Right-click the Bulk Error node. Then, click *Probe – Inst*.
- ❑ Right-click the Missing Isolation node. Then, click *Probe – Net/Driver/ Receiver*.
- ❑ Right-click the Incompatible Isolation signal node. Then, click *Probe – Driver/ Receiver*.
- ❑ Right-click the Redundant Isolation signal node. Then, click *Probe – Inst*.

### **Related Topics**

[Defining the Severity of Design Checks](#)

[Level Shifter Checks](#)

[Isolation Checks](#)

[Bulk Checks](#)

[Checking a Design in Foreground Mode](#)

[Checking a Design in Background Mode](#)

[Filtering Violations](#)

[Generating Signal Information](#)

## **Filtering Violations**

You can add the filter patterns to waive off violations in the *Filters* field on the Runs In-Design Checks tab of the Power Manager Setup form. These indicate the permissive deviations in the design. The tool filters the errors messages or violations matching the pattern specified in the *Filters* field. The Annotation Browser does not display the filtered violations. All matching violations are reported as the filtered messages in the In-Design Checks Report. See [Performing In-Design Checks](#).

### ***Related Topics***

[Defining the Severity of Design Checks](#)

[Level Shifter Checks](#)

[Isolation Checks](#)

[Bulk Checks](#)

[Checking a Design in Foreground Mode](#)

[Checking a Design in Background Mode](#)

[Loading the Violations Database](#)

[Generating Signal Information](#)

## Generating Signal Information

You can assign the voltage information to each design net based on the possible voltage values defined in the Signal Information Report that the net can have under multiple design conditions.

To generate the signal information report:

1. Load the setup file. The setup file is needed for identifying the design elements and registering voltage values for different nets.
2. Choose *Power Manager – Generate Signal Info*. Alternatively, use `vpmGenerateSigInfo`. The Signal Information Report is created.

```

DESIGN_WORKSHOP_VPM.DESIGN1.sigInfo.txt
File Edit View Help
-----
#####
#                               Signal Information Report                               #
#####

# Design      : DESIGN_WORKSHOP_VPM/DESIGN1/schematic
# Program Version : @(#)$CDS: virtuoso version ICADVM18.1-64b 01/21/2020 18:53 (cpgbld01) $
# Program Sub-Version : ICADVM18.1-64b.500.9
# Current Date   : Wed Jan 29 11:11:55 2020

# Net Name      Sig Type      Voltages
-----
Vdd_1v8l        power          1.00,1.80
Vdd_3v3l        power          3.30
Vdd_Intl        power          3.30
Vssl            ground         0.00
Vssl_Intl       ground         0.00
Vssal           ground         0.00
CLKTOP3         signal         0.00,3.30
CLKTOP4         signal         0.00,3.30
D_IN<1>         signal         0.00,3.30
D_IN<2>         signal         0.00,3.30
D_IN<3>         signal         0.00,3.30
D_IN<4>         signal         0.00,3.30
EN_ISO1         signal         0.00,3.30
EN_ISO12        signal         0.00,3.30
FSWACKT        signal         0.00,3.30
FSWENT         signal         0.00,3.30
HIN1           signal         0.00,1.00,1.80
HIN2           signal         0.00,3.30
HIN3           signal         0.00,3.30
HOUT1          signal         0.00,3.30
HOUT2          signal         0.00,3.30
HOUT3          signal         0.00,3.30
HSWACKT        signal         0.00,3.30
HSWENT         signal         0.00,3.30
IO/CK          signal         0.00,1.00,1.80
IO/I59/net11   signal         0.00,1.00,1.80
IO/I59/net12   signal         0.00,1.00,1.80
IO/I59/net13   signal         0.00,1.00,1.80
IO/I59/net14   signal         0.00,1.00,1.80
IO/I59/net15   signal         0.00,1.00,1.80
IO/I59/net16   signal         0.00,1.00,1.80
3
L1 C1
  
```

# Virtuoso Power Manager User Guide

## Running In-Design Checks

---

### ***Related Topics***

[Defining the Severity of Design Checks](#)

[Level Shifter Checks](#)

[Isolation Checks](#)

[Bulk Checks](#)

[Checking a Design in Foreground Mode](#)

[Checking a Design in Background Mode](#)

[Loading the Violations Database](#)

---

## Exporting Power Intent of a Design

---

The power intent of the design specified in the 1801 file acts as a design source along with the logical intent (synthesized Verilog netlist). This collection of source input files is utilized by different tools, including the formal verification tools. The 1801 information is expected to successively refine at various design stages, one of which is the case where the design information changes (ECO). Here, a 1801 file incorporating all the design changes is required to be regenerated to have a logical equivalence with the updated design schematic.

The export flow enables you to extract the design connectivity from the schematic and export the low power design intent to a 1801 file. This helps in adding the updated content in incremental stages of IP authoring, which can finally be verified for correctness using CLP along with a VerilogPG netlist.

### ***Related Topics***

[Export Flow](#)

[Extracting the Power Intent from a Design](#)

[Exporting 1801 Design Model](#)


[Exporting 1801 Power Model](#)

[Exporting Liberty Power Model](#)

[Special Isolation Cells in Liberty Power Model Export](#)

## Export Flow

The illustration below gives an overview of the export flow.



### Export Flow in Virtuoso Power Manager

Here are the key stages of the export flow.

- Extraction of design
  - Partitioning of the design
  - Identification of PG net types, standard, special and other cell types
  - Propagation of power information to sub blocks down the hierarchy
  - Creation of power domains and power modes
- Creation and export of Design Model of the design
- Creation and export of Power Model of the design
- Creation and export of Liberty Macro Model of the design

### ***Related Topics***

#### Identification of Design Objects

[Design Partitioning](#)

[Exporting 1801 Design Model](#)

[Exporting 1801 Power Model](#)

[Exporting Liberty Power Model](#)

[Special Isolation Cells in Liberty Power Model Export](#)


## Extracting the Power Intent from a Design

If your design includes objects that describe the power intent for the design, you can extract the power intent, which can further be exported to a 1801 file, to be used further in design flow.

To extract power intent from a design:

1. Open the design in Power Manager.
2. Prepare the setup for automatic extraction. Load the setup from Power Manager toolbar or menu.
3. On the Power Manager toolbar or menu, click *Extract from Design*.

The Extract Power Intent form appears.



The library, cell, and view name list of the currently open cellview are shown in the form. The fields specify the information of the cellview, which is non-editable, being extracted.

For a pure schematic-based design, Power Manager always extracts a flat (design model, power model, or macro model) 1801. If there are hierarchical blocks in the design that have their own associated 1801 file, the tool does not extract details of that block and generates a hierarchical 1801, instead by integrating the 1801 file of the lower-level blocks. During the

## Virtuoso Power Manager User Guide

### Exporting Power Intent of a Design

---

extraction of design schematic the identification of design objects and partitioning is performed.

#### ***Related Topics***

[Setup for Automatic Extraction of Power Intent](#)

[Export Flow](#)

[Identification of Design Objects](#)

[Design Partitioning](#)

[Exporting 1801 Design Model](#)

[Exporting 1801 Power Model](#)

[Exporting Liberty Power Model](#)

[Special Isolation Cells in Liberty Power Model Export](#)

### **Identification of Design Objects**

The design extraction involves the identification of the essential design objects, which are required for building a correct power intent. These include:

- Identification of power and ground nets associated with each cell in the design hierarchy by using the name-based registration in the setup file.
- Identification of the standard and special cells that have associated Liberty models or a 1801 special cell definition file at the path specified in the setup. When found, the tool identifies the cells defined in the 1801 file as standard or special cells.


#### ***Related Topics***

[Design Partitioning](#)

[Setup for Automatic Extraction of Power Intent](#)

## Design Partitioning

A design can contain different types of cells. For example, the following example design contains various types of blocks.



During extraction, the extractor handles each type of cell differently. For example, if a cell is already bound with a 1801 file that was previously imported in the schematic of the cell, the extractor refers to the 1801 file instead of re-extracting the power information of the cellview.

Similarly, for all multi-supply cells that contain primitive cell instances that were identified during the partitioning stage, the extractor extracts the cellview-level power domain information and stitches it to the top-level domains. Instances of single supply cells are considered as standard cells and their power attributes are derived from their corresponding Liberty model and stitched to the top-level power domains. Therefore, before extracting power intent, the tool needs to identify different types of cells and blocks in the design.

## Virtuoso Power Manager User Guide

### Exporting Power Intent of a Design

---

During partitioning, the Schematic Editor traverses through the design and identifies the following types of cells:

Cell Type	Description
Primitive cells	<p>A cell that meets the following criteria:</p> <ul style="list-style-type: none"><li>■ Does not contain any instances</li><li>■ Does not have any power pin or ground pin</li></ul> <p>Examples: PMOS, NMOS, RES</p>
Passive cells	<p>A cell that meets the following criteria:</p> <ul style="list-style-type: none"><li>■ Contains only primitive instances</li><li>■ Does not have any power pin or ground pin</li></ul> <p>Examples: resistor bank or capacitor bank</p>
Low power special cells	<p>A cell that is registered as a special low power cell.</p> <p>Examples: isolation cell, level shifter, power switch</p>
Single supply voltage cells	<p>A cell that meets the following criteria:</p> <ul style="list-style-type: none"><li>■ Contains zero or more primitive cell or passive cell instances</li><li>■ Has one power pin and one ground pin</li></ul> <p>Example: single-rail cell</p>
Multiple supply voltage cells	<p>A cell that meets the following criteria:</p> <ul style="list-style-type: none"><li>■ Contains zero or more primitive cell or passive cell instances</li><li>■ Has more than one power pin and one or more ground pins</li></ul> <p>Example: multi-rail cell</p>

## Virtuoso Power Manager User Guide

### Exporting Power Intent of a Design

Cell Type	Description
1801 cells	A cell that contains the existing 1801 model. The power intent that has been imported by using the <i>File – Import Power Intent</i> command is being applied to this cell.
Macro cells	<p>A cell that meets any one of the following criteria:</p> <ul style="list-style-type: none"> <li>■ Contains one or more instances of primitive cell or passive cell and one or more instances of single supply cell, multiple supply voltage cell, or 1801 cell</li> <li>■ Contains one or more instances of primitive cell or passive cell and has more than one power pin and one or more ground pin</li> <li>■ Has more than one power pin and one or more ground pin, but does not contain any cell, that is, an empty cell with multiple supply voltages</li> </ul>
Hierarchy cells	<p>A cell that meets the following criteria:</p> <ul style="list-style-type: none"> <li>■ Contains instances of single supply cell, multiple supply voltage cell, macro cell, or 1801 cell</li> <li>■ Does not contain any primitive cell or passive cell</li> </ul>

After the design partitioning, the next step is the design elaboration. The design elaboration involves the creation of an Embedded Module Hierarchy (EMH), which is a model for storing the hierarchical design data supported at the open access database level. For Power Manager, this open access cellview is called the power view. The extractor traverses the entire schematic hierarchy to achieve the following:

- Builds a data structure that contains the OA equivalent objects from the database objects encountered. The structure includes a top-level design, instances, nets, terms, instTerms and net connectivity.

## Virtuoso Power Manager User Guide

### Exporting Power Intent of a Design

---

- Utilizes all the instances of the cells that have Liberty models, associated power views, and associated 1801 model.
- Extracts power intent by tracing the connectivity. The connectivity tracing is done considering the block domain of open access cellview, that is, the flat representation of the entire schematic hierarchy in EMH.
- Identifies power nets and ground nets and their equivalent power or ground nets by the sigType in the schematic or the name-based registration in the setup.
- Identifies switchable or non-switchable power nets or ground nets. This is the output from switch supply pin of switch cell instances (Power Switch).
- Pairs the power nets and ground nets. PG net pairing is done by looking at the related PG pins of standard cell instances, special cell instances, macro cell instances. In addition, pairing is also done by tracing a path between the top-block power and ground nets through the source-drain terminals of transistors, shorts, and connector devices in the top block.
- Models various states where every single supply each state is assigned a specific voltage or the state of supply sets, that is, collection of supplies instead of individual supplies by using PST for exporting design and power models.
- Assigns instances to the power domains.
- Creates power states and the power modes. Also, assigns power domains to these power modes.
- Identifies boundary ports and assigns these ports to the power domains. This identification is done based on tracing the connectivity through transistors and two terminal devices. Related power and ground nets of ports are derived by analyzing the related supplies of the driver or receiver instTerms in the top block. While identifying ports for creating power domains, it is checked whether the port could be related to more than one power domain by virtue of its connections to one or more instances that may belong to multiple power domains. In such a situation, the port is not associated with any power domain and the warning messages are issued depending on the situation. There are three scenarios where the ports are not related to any of the power domains due to ambiguity in deciding the power domain:


**Case 1:** In this scenario, port C can be related to either of the two supply sets (SS\_\_VDD\_\_VSS and SS\_\_VDDext\_\_VSS) due to its connectivity to M2, which falls in

## Virtuoso Power Manager User Guide

### Exporting Power Intent of a Design

---

the path of  $VDD$ ,  $VSS$  as well as  $ExtVDD$ ,  $VSS$ . Therefore, port C is not related to any supply set because there is ambiguity related to its power domain.




**Case 2:** In this scenario, the port IN1 is driving two inverter instances that belong to different supply sets and so it can be assigned either to  $SS\_VDD\_VSS$  or

## Virtuoso Power Manager User Guide

### Exporting Power Intent of a Design

---

SS\_\_vdd\_\_vss. Therefore, port IN1 is not related to any supply set because there is ambiguity related to its power domain.




**Case 3:** In this scenario, the port `TOP_IN` drives two pins, `IN1` and `IN2`, of a hierarchical instance. Inside the instances (not shown in the image), `IN1` and `IN2` are separately driving two inverters, which are in two separate supply sets `SS__VDD1__VSS` and `SS__VDD2__VSS`, respectively. The port `TOP_IN` can be assigned either

## Virtuoso Power Manager User Guide

### Exporting Power Intent of a Design

SS\_\_VDD1\_\_VSS or SS\_\_VDD2\_\_VSS, therefore, it is not related to any supply set due to ambiguity in its power domain.



In such scenarios, you can provide the information of data ports to explicitly specify their supply set, forcing the tool to associate the data ports to the desired power domain.

While extracting power intent, Power Manager gives precedence to the explicit registration of the port attributes and traces connectivity through transistors and the two-terminal devices. Each data terminal that can be traced to a power terminal is created as a boundary port for the corresponding power domain. If a data terminal is connected to more than one power terminal, it is attached to the power domain as specified in the port attribute registered in the setup for that data terminal. If the port attribute is not registered in the setup, the tool would associate the data terminal to all possible power domains found by connectivity tracing.

**Note:** While extracting power intent, the tool checks each macro cell and the top cell to find ports that are not related to any supply terminal. The tool does not assign such ports to any power domain and displays a warning message for each cell to report such ports in that cell, as shown below:

```
\w *WARNING* (LP-3034): Could not determine driver/receiver supplies for logic port 'enps_3v3_i, dll_amux_ao, dll_ibias_10u_ai' in the
```

## Virtuoso Power Manager User Guide

### Exporting Power Intent of a Design

---

Liberty or setup files. Ensure that the required supplies are defined in the files.

- Derives domain shutoff conditions by backtracing the enable pins of switch cell instances in the top block to the top block ports and combining those ports in suitable expression as per the design.
- Integrates sub blocks that have their own 1801files.
  - If the 1801 block has a power intent specified as a Liberty macro model, it identifies the top-level domain that maps to the macro-level domain and creates a domain mapping. PG net voltages in macro cells are assigned from the top net voltages. This might lead to a conflict if the net voltage specified in the macro model are of different voltage levels as compared to the voltage levels of the top net voltage. This conflict can be noted at the verification stage of the power intent.
  - If the 1801 block has power intent of the design model type, Power Manager collates all the power domains in the 1801 block hierarchy and integrates the 1801 cell in the same way as for a block with the macro model type.
- Identifies low power special cells and creates power switch rules, isolation rules, and level shifter rules, as required. Enable conditions are derived by backtracing the enable pins of special cells.

**Note:** If a level shifter cell contains an enable pin, it is identified as both an isolation cell and as a level shifter cell. Such cells are also referred as combo cells. In this case, while extracting power intent, the tool defines it as a level shifter cell as well as an isolation cell. In addition, corresponding level shifter and isolation rules are defined.

### ***Related Topics***

[Identification of Design Objects](#)

[Power Intent Import](#)

[Power View](#)

[Registering Supply Set and Power Domain](#)

[Power Intent Import](#)

## Creation of Power Domains

While extracting power intent, Power Manager automatically identifies the power nets and ground nets in the design as described below. Further, for each power net, it finds the ground net associated with it and for each unique pair of power net and ground net, creates a power domain.

### Identifying Switchable and Non-Switchable Power Nets and Ground Nets

- A net is identified as a non-switchable power net if either of the following conditions are met:
  - The sigType property of the net is power
  - The net name is registered as a power net
  - The net is not an output of a switch cell and cannot be hierarchically traced to an output of a switch cell.
- A net is identified as a switchable power net if either of the following conditions are met:
  - The net is an output of a head-switch cell
  - The net can be hierarchically traced to an output of a head-switch cell
- A net is identified as a non-switchable ground net if:
  - The sigType of the net is ground.
  - The net name is registered as a ground net.
  - The net is not an output of a switch cell and cannot be hierarchically traced to an output of a switch cell.
- A net is identified as a switchable ground net if either of the following conditions are met:
  - The net is an output of a foot-switch cell
  - The net can be hierarchically traced to an output of a foot-switch cell

**Note:** If you have not registered any names for power nets and none of the nets in the design have their signal type set to power, then Power Manager does not extract any power domains.

After identifying the power nets and ground nets, the unique power net/ground net pairs (Supply sets) are identified. For this, the tool traces the paths from a power net to a ground net. The tool also considers the power net/ground net pairs registered in the setup.

Supply sets can be defined in the setup for the following scenarios.

## Virtuoso Power Manager User Guide

### Exporting Power Intent of a Design

---

- The primary supply set for the power domains mentioned in the setup.
- The power and ground nets that cannot be paired by traversing the design hierarchy or parsing the Liberty in case of a Liberty cell.

Supply set identification can be done explicitly in a setup template or by automatic identification.

If you want to partition the design for assigning a particular instance to some power domain, provide the list of domain, instances, and primary supply set.

If power domains and supply set information is provided in the setup, the following is the sequence of tasks being done:

- `create_power_domain` commands are created in the exported 1801 file based on the number of power domains.
- Primary supply set are referred from the setup.
- Extra supplies that need not to be a part of setup are identified by the tool.
- `connect_supply_net` command is generated for supply nets that are a part of extra supplies.
- For any other instance that is not a part of any power domain remains in the default domain.
- If there is no power domain assignment, a single power domain is created and all the instances are connected by using `connect_supply_net`.

The following examples show how power domains are created:


Example 1:

## Virtuoso Power Manager User Guide

### Exporting Power Intent of a Design

---

Consider the following design that does not have the user-defined supply sets and power domains specified in the setup:



In this case, the tool traverses through the design and creates the following power domains:

- SS\_\_VDD1\_\_GND1
- SS\_\_VDD2\_\_GND2
- SS\_\_VDD3\_\_GND3


Example 2:

## Virtuoso Power Manager User Guide

### Exporting Power Intent of a Design

---

Now, consider the following design that contains a head-switch.



In this case, the tool creates one default power domain and two supply sets:

- `pd__VDD__VSS`
- `SS_VDD_VSS`
- `SS_NET1_VSS`

Example 3:

If a primitive instance has one netSet property each for a power and ground supply, it is added to the power domain created for that power and ground supply pair even if the instance does not have any power/ground pins in the symbol/schematic view. If a power domain does not exist for that power and ground supply pair, a new power domain is created and the primitive instance is added to it. However, if the primitive instance has more than one netSet property for power or ground, it does not contribute towards the creation of a power domain and a warning message is displayed in the power intent extraction log.

## Default Power Domain

If the `create_power_domain` command has the `-include_scope` or `-elements {.}` switch, it is considered as the default domain. When no such default domain is found, any `create_power_domain` command that does not have the `-elements` switch is considered as the default domain. However, multiple `create_power_domain` commands cause the 1801 import to fail with an appropriate error message.

# Virtuoso Power Manager User Guide

## Exporting Power Intent of a Design

---

### ***Related Topics***

[Export Flow](#)

[Exporting 1801 Design Model](#)

[Exporting 1801 Power Model](#)

[Exporting Liberty Power Model](#)

[Special Isolation Cells in Liberty Power Model Export](#)

[Registering Supply Set and Power Domain](#)

### **Power View**

Power view is an OpenAccess view generated corresponding to each cell that is being extracted to export the power intent. The power view stores the following information:

- Set up information of the cellview prior to extraction
- Extracted and/or imported power intent information
- The design information derived from the schematic design (EMH and native OA objects)
- Internal data structures

The power view is co-managed with the schematic view of the design. The view is automatically updated upon extraction when the setup or design changes. There is no need to explicitly load the setup for each successive extraction run until the power view exists for a cell and there is no change in the setup information of the design. The power view by default gets created in the design library within the design cell, adjacent to the design view/ schematic. If the parent library is non-editable, `lpDBGGlobalSearchLibs` and `lpDBGGlobalSearchViews` can be used to save the power view in an editable user-defined library. The power view is also automatically purged when the associated schematic cellview is purged for reasons, such as on closing the schematic or calling the `dbPurge/dbClose SKILL` function.

### ***Related Topics***

[lpDBGGlobalSearchLibs](#)

[lpDBGGlobalSearchViews](#)

[Export Flow](#)

# Virtuoso Power Manager User Guide

## Exporting Power Intent of a Design

---

[Extracting the Power Intent from a Design](#)

[Creation of Power Domains](#)

[Exporting 1801 Design Model](#)

[Exporting 1801 Power Model](#)

[Exporting Liberty Power Model](#)


[Special Isolation Cells in Liberty Power Model Export](#)

## Exporting 1801 Design Model

You can export the power intent specified for your design to a 1801 design model file. To export power intent from a design:

1. Open the design in Power Manager.
2. Prepare the setup for automatic extraction. For more details about how to prepare the setup, refer to Setup Preparation for Automatic Extraction of Power Intent. Load the setup from Power Manager toolbar/menu.
3. Click *Power Manager – Extract from Design*.
4. Click *Power Manager – Export from Design*.

The Export Power Intent form appears. The library, cell, and view names of the cell that is currently open are displayed by default in the form.



5. In the *1801 File* field, specify the path and the name of file for exporting the power intent.

## Virtuoso Power Manager User Guide

### Exporting Power Intent of a Design

---

6. Select the *Overwrite Existing File* check box to overwrite the file.

7. Click *OK*.

The `vpmExportPowerIntent` SKILL function has been provided to export the 1801 Design Model information for a cellview.

In 1801 design model, the power intent of the sub-blocks is exported along with power intent of the top design. For a pure schematic-based design, the Power Manager always extracts a flat 1801.

An example of an exported 1801 design model file is shown below:

```
set_design_attributes -attribute top_ports_have_anon_supply 0
##### Supply Ports (Section 1)#####
create_supply_port VDD      -direction inout
create_supply_port VDDA     -direction inout
create_supply_port VDDSW    -direction inout
create_supply_port VSS      -direction inout

##### Supply Nets (Section 2)#####
create_supply_net VDD      -resolve parallel
create_supply_net VDDA     -resolve parallel
create_supply_net VDDSW    -resolve parallel
create_supply_net VSS      -resolve parallel

##### Supply Net Connections (Section 3)#####
connect_supply_net VDD      -ports { VDD }
connect_supply_net VDDA     -ports { VDDA }
connect_supply_net VDDSW    -ports { I3/I0/VDD }
connect_supply_net VSS      -ports { VSS }

##### Supply Sets (Section 4)#####
create_supply_set SS_VDDA_VSS -function { power VDDA } -function { ground VSS }
create_supply_set SS_VDDSW_VSS -function { power VDDSW } -function { ground VSS }
create_supply_set SS_VDD_VSS -function { power VDD } -function { ground VSS }

##### Power Domains (Section 5)#####
create_power_domain PD_TOP -include_scope -supply { primary SS_VDD_VSS } \
-supply { extra_supplies_1 SS_VDDSW_VSS }
create_power_domain PD_LS -elements { I0 } -supply { primary SS_VDDA_VSS } \
-supply { extra_supplies_1 SS_VDD_VSS }
```

## Virtuoso Power Manager User Guide

### Exporting Power Intent of a Design

---

```
##### Standard Cells (Section 6)#####
connect_supply_net VDD -ports { I0/I20/I0/VDD }
connect_supply_net VDDSW -ports { I3/I1/VDD }
##### Special Cells #####
connect_supply_net VDD -ports { I0/I22/ExtVDD }
connect_supply_net VDDSW -ports { I3/I0/VDD }
##### Macro Cells #####
connect_supply_net VDD -ports { I2/VDD_ext }
connect_supply_net VSS -ports { I2/VSS_ext }

##### Port Attributes (Section 7)#####
set_port_attributes -port en_iso -receiver_supply SS_VDD_VSS
set_port_attributes -port in1 -receiver_supply SS_VDD_VSS
##### Isolation Rules #####
set_isolation PD_TOP_ISO 0 -domain PD_TOP -elements { out_iso } -
isolation_supply_set SS_VDD_VSS -isolation_signal en_iso -isolation_sense high -
location self -clamp_value 0

##### Level Shifter Rules (Section 8)#####
set_level_shifter PD_LS_ls_0 -domain PD_LS -elements { I0/out_ls } -
input_supply_set SS_VDDA_VSS \ -output_supply_set SS_VDD_VSS -location self -rule
both
##### Switch Rules #####
create_power_switch I3_I0 -output_supply_port { VDD VDDSW } -input_supply_port {
ExtVDD VDD } \
-control_port { PSO psw_en } -on_state { on ExtVDD {!PSO} } -off_state { off PSO }
-domain PD_TOP

##### Supply Port States (Section 9) #####
add_port_state I3/I0/VDD -state { V110 1.1 } -state { OFF off }
add_port_state VDD -state { V110 1.1 } -state { OFF off }
add_port_state VDDA -state { V130 1.3 } -state { OFF off }
add_port_state VSS -state { OFF 0 }

##### Power State Table (Section 10) #####
create_pst top_pst -supplies [list I3/I0/VDD VDD VDDA VSS ]
add_pst_state State_1 -pst top_pst -state { V110 V110 V130 OFF }
add_pst_state State_2 -pst top_pst -state { OFF V110 V130 OFF }
add_pst_state State_3 -pst top_pst -state { OFF OFF OFF OFF }
```

The following points explain the different sections of the exported 1801 design model:

- **Section 1:** The `create_supply_port` command defines a supply port in the scope of the power domain. These are created for all the top-level supply ports identified.

## Virtuoso Power Manager User Guide

### Exporting Power Intent of a Design

---

- **Section2:** The `create_supply_net` command creates a supply net in the scope of the power domain. These are created for all the top-level supply nets identified.
- **Section3:** The `connect_supply_net` command connects a supply net to the specified ports. These commands are for handling the interface connectivity. The commands are for both the top level as well as for hierarchical interface connectivity. This resolves the connectivity of PG nets from down the hierarchy to the top level PG nets for different blocks. Section6 also performs the same task.
- **Section4:** The `create_supply_set` command creates the supply set name within the current scope. This defines the primary and extra supply sets or available supplies associated with the different power domains.
- **Section5:** The `create_power_domain` command defines a power domain and the set of instances that are in the extent of the power domain. It may also specify whether the power domain can be partitioned further by the subsequent commands.
- **Section6:** The `connect_supply_net` command defines the standard, special, and macro cells.
- **Section7:** The `set_port_attributes` command specifies the information associated with data ports of instances. The attributes of this command identify a port's related supplies (driver or receiver) and the boundary of a power domain.
- **Section8:** These commands define the low power strategy (Level Shifters, Isolation, and Power Switch) adopted for the ports on the interface of a power domain. This is required to correct for voltage differences between the driving and receiving supplies of a port or to ensure correct electrical and logical functionality when domains are in different power states.

The correct strategy adopted is also based on the cell type identified while reading the schematic based on their Liberty model or special cell definition file registered in the setup.

- **Section9:** The `add_port_state` command adds the state information to a supply port. If the voltage values are specified, the supply net state is `FULL_ON` and the voltage value is the single nominal value or within the range of min to max. If the supply net state is off, the voltage value is `OFF`.
- **Section10:** The `add_pst_state` command defines the name for a specific state of the supply nets defined for the power state table (PST). This command defines system power states of the IP.

The output supply port that is the output of a power switch, output of a LDO, or voltage regulator can be identified by explicit user registration in the setup. In addition, the output supply port can be identified from the Liberty model or the 1801 file, if available for the block.

The commands associated with the output port would appear in Section1, Section2, Section9, and Section10.

A hierarchical internal net is not generated for commands related to Section1, Section2, Section3, and Section6. Any block with internal net (not available at the top) should be extracted and 1801 generated. Then, use the 1801 binding for the top block.

For more information on the 1801 commands, refer to *IEEE Standard for Design and Verification of Low-Power Integrated Circuits*.

### ***Related Topics***

[vpmExportPowerIntent](#)

[Registering Supply Set and Power Domain](#)

[Registering Device and Cell](#)

[Extracting the Power Intent from a Design](#)

[Creation of Power Domains](#)

[Exporting 1801 Power Model](#)

[Exporting Liberty Power Model](#)

[Special Isolation Cells in Liberty Power Model Export](#)

## **Exporting 1801 Power Model**

You can export the power intent specified for the design to a 1801 power model file. To export power intent from a design,

1. Open the cellview in Power Manager.
2. Prepare the setup for automatic extraction.
3. Load the setup from the Power Manager toolbar/menu.
4. On the Power Manager toolbar/menu, click *Extract from Design*.
5. Use `vpmExportPowerModel` to export the 1801 Power Model information for a cellview.

## Virtuoso Power Manager User Guide

### Exporting Power Intent of a Design

---

In the 1801 power model, the power intent of the top design is only exported as the power intent information, with no sub-block power intent details. A power model is used to define the power intent of a hard IP cell. The command pair `begin_power_model` and `end_power_model` create a definitive boundary for the power intent for the hard IP cell. A model name is created, and it is targeted for a specific macro cell.

The interfaces of the hard IP power model include the top-level power domain for this IP cell and all the supplies of IP. This power domain is also used to specify the system power states at the hard IP level.

An example of an exported 1801 power model file is shown below:

```
upf_version 2.1
##### Power Model Initialization (Section 1)#####
begin_power_model top_model -for top
##### Supply Ports (Section 2)#####
create_supply_port VDD! -direction inout
create_supply_port VDDA! -direction inout
create_supply_port VSS! -direction inout
##### Supply Nets (Section 3)#####
create_supply_net VDD -resolve parallel
create_supply_net VDD1 -resolve parallel
create_supply_net VDDA -resolve parallel
create_supply_net VDDSW -resolve parallel
create_supply_net VSS -resolve parallel
create_supply_net VSS1 -resolve parallel
connect_supply_net VDD -ports { VDD }
connect_supply_net VDDA -ports { VDDA }
connect_supply_net VDDSW -ports { I3/I0/VDD }
connect_supply_net VSS -ports { VSS }
##### Supply Sets (Section 4)#####
create_supply_set SS_VDDA_VSS -function { power VDDA } -function { ground VSS }
create_supply_set SS_VDDSW_VSS -function { power VDDSW } -function { ground VSS }
create_supply_set SS_VDD_VSS -function { power VDD } -function { ground VSS }
##### Power Domains (Section 5)#####
create_power_domain PD_MACRO -elements { . } \
-supply { primary SS_VDD_VSS } \
-supply { extra_supplies_0 SS_VDD+VDDSW_VSS } \
-supply { extra_supplies_1 SS_VDDA_VSS } \
-supply { extra_supplies_2 SS_VDDSW_VSS }
##### Port Attributes (Section 6)#####
set_port_attributes -port en_iso -receiver_supply SS_VDD_VSS
```

## Virtuoso Power Manager User Guide

### Exporting Power Intent of a Design

---

```
set_port_attributes -port in1 -receiver_supply SS_VDD_VSS
set_port_attributes -port in2 -receiver_supply SS_VDD_VSS
set_port_attributes -port in3 -receiver_supply SS_VDD_VSS
set_port_attributes -port in4 -receiver_supply SS_VDD+VDDSW_VSS
set_port_attributes -port out1 -driver_supply SS_VDD_VSS
set_port_attributes -port out2 -driver_supply SS_VDD_VSS
set_port_attributes -port out3 -driver_supply SS_VDD_VSS
set_port_attributes -port out_iso -driver_supply SS_VDD_VSS
set_port_attributes -port out_psw -driver_supply SS_VDD_VSS
set_port_attributes -port outvdd -driver_supply SS_VDD_VSS
set_port_attributes -port psw_en -receiver_supply SS_VDD_VSS
```

##### Power States (Section 7)#####

```
add_power_state SS_VDDA_VSS -supply \
    -state { ON -simstate NORMAL \
        -supply_expr { power == { FULL_ON 1.300000 } &&
ground == { FULL_ON 0.000000 } }} \
    -state { OFF -simstate CORRUPT \
        -supply_expr { power == OFF && ground == OFF }}

add_power_state SS_VDDSW_VSS -supply \
    -state { ON -simstate NORMAL \
        -supply_expr { power == { FULL_ON 1.100000 } &&
ground == { FULL_ON 0.000000 } }} \
    -state { OFF -simstate CORRUPT \
        -supply_expr { power == OFF && ground == OFF }}

add_power_state SS_VDD_VSS -supply \
    -state { ON -simstate NORMAL \
        -supply_expr { power == { FULL_ON 1.100000 } &&
ground == { FULL_ON 0.000000 } }} \
    -state { OFF -simstate CORRUPT \
        -supply_expr { power == OFF && ground == OFF }}

add_power_state PD_MACRO -domain \
    -state { S0 -logic_expr { SS_VDD_VSS == ON && SS_VDDSW_VSS
== ON && SS_VDDA_VSS == ON }} \
    -state { S1 -logic_expr { SS_VDD_VSS == ON && SS_VDDSW_VSS
== ON && SS_VDDA_VSS == OFF }} \
    -state { S2 -logic_expr { SS_VDD_VSS == ON && SS_VDDSW_VSS
== OFF && SS_VDDA_VSS == ON }} \
    -state { S3 -logic_expr { SS_VDD_VSS == ON && SS_VDDSW_VSS
== OFF && SS_VDDA_VSS == OFF }}
```

# Virtuoso Power Manager User Guide

## Exporting Power Intent of a Design

---

```
##### Power Model End (Section 8)#####  
end_power_model
```

The following points explain the different sections of the exported 1801 power model:

- **Section1:** The `begin_power_model` command defines the boundary condition for the power model. This marks the beginning of the power model.
- **Section2:** The `create_supply_port` command defines a supply port in the scope of the power domain. These are created for all the top-level supply ports identified.
- **Section3:** The `create_supply_net` command creates a supply net in the scope of the power domain. These are created for all the top-level supply nets identified.
- **Section4:** The `create_supply_set` command creates the supply set name within the current scope. This section associates the interface supplies to the boundary supply ports or internally generated supplies.
- **Section5:** The `create_power_domain` command defines a power domain and the set of instances that are in the extent of the power domain. It may also specify whether the power domain can be partitioned further by subsequent commands.
- **Section6:** The `set_port_attributes` command specifies the information associated with data ports of instances. The attributes of this command identify a port's related supplies (driver or receiver) and define the boundary of a power domain.
- **Section7:** The `add_power_state` command adds the state information to a supply port. If the voltage values are specified, the supply net state is `FULL_ON` and the voltage value is the single nominal value or within the range of min to max. If the supply net state is off, the voltage value is `OFF`.
- **Section8:** The `end_power_model` command defines the boundary condition for the power model. The power model ends here.

### ***Related Topics***

[Setup for Automatic Extraction of Power Intent](#)

[vpmExportPowerModel](#)

[Registering Name-Based Supply Nets](#)

[Extracting the Power Intent from a Design](#)

[Creation of Power Domains](#)

[Exporting 1801 Design Model](#)

Exporting Liberty Power Model

Special Isolation Cells in Liberty Power Model Export

## Exporting Liberty Power Model

You can export the power intent specified for the design as a Liberty power model template file with the non-characterized attributes for `pg_pin` and pin groups of a library or cell, such as `related_power_pin`, `related_ground_pin`, `pg_type`, `direction`, `is_isolated`, `isolation_enable_condition`, `switch_pin`, `pg_function`, `switch_function`, and so on.

To export power intent from a design:

1. Open the cellview in the Power Manager.
2. Prepare the setup for automatic extraction. For more details about how to prepare the setup, refer to [Setup for Automatic Extraction of Power Intent](#).
3. Load the setup from the Power Manager toolbar/menu.
4. Click *Power Manager – Extract from Design*.
5. Click *Power Manager – Export Liberty Model*.

The [Export Liberty Model Form](#) form appears. The library, cell, and view names of the cellview that is currently open are displayed by default in the form.



6. In the *Liberty File* field, specify the path and the name of the file for exporting the Liberty power model.

## Virtuoso Power Manager User Guide

### Exporting Power Intent of a Design

---

7. Select the *Overwrite Existing File* check box to overwrite the file.
8. Click *OK*.

**Note:** `vpmExportDotLib` has been provided to export the Liberty power model information for a cellview.

Liberty power model is the power intent at the macro model level, for complex design blocks. This can also be referred as a black box model of the power characteristics of a complex design block or a hard IP. Power Manager helps in automatically extracting the power intent from the design schematic and exporting the low power attributes to a Liberty Power Model template. It can be further integrated while extracting the power intent of the top design. The Exported Liberty Power Model, having the PG attributes can be stitched to the baseline Liberty model from an IP characterization tool to generate a complete liberty file for schematic IP ready for verification and implementation.

While creating the Liberty power model for a macro cell, the following tasks are performed:

- Identifies power nets and ground nets and their equivalent power or ground nets.
- Identifies switchable or non-switchable power nets or ground nets.
- Identifies boundary ports for the macro.
- Relates the boundary ports to the related power and ground supply pairs by tracing.
- Identifies low power special cells and the boundary ports associated with boundary ports to print the relevant attributes.
- Backtraces the data path from the control pins of the low power special cells to the macro or design ports for generating enable or shutoff conditions.

The Liberty power model also enables creation of analog ports. Analog ports are a list of ports of a macro cell or a design that either drive the analog circuits or are driven by them. In a Liberty power model, a port is considered an analog port in the following cases:

- There is a user override, by defining `portAttribute`, in the setup that declares the pin as analog.
- The pin has a related power or a related ground found by tracing the power and ground path.
- The pin is not a driver or load of one or more instance pins that produce digital output, such as (Liberty or user-defined) standard cell input/output pin, which has a related power and a related ground attribute.
- The pin is not feedthrough and unconnected.

Ports identified as analog ports have the `is_analog` attribute associated with them.

# Virtuoso Power Manager User Guide

## Exporting Power Intent of a Design

---

An example of an exported Liberty Power Model file is shown below:

```
#####
/*
  Liberty Power Model Template (Section 1)
  =====
library          : upf_export;
cell             : top;
Program Version  : sub-version IC6.1.8-64b.main.174 ;
*/
#####(Section 2)#####
library(upf_export) {

    date          : "Wed Mar  6 18:02:38 2019 ";
    comment       : "Generated by Virtuoso Power Manager";
    voltage_unit  : "1V";

    voltage_map( VDD , 1.100000);
    voltage_map( VDDA , 1.300000);
    voltage_map( VDDSW , 1.100000);
    voltage_map( VSS , 0.000000);
#####(Section 3)#####
    cell(top) {
        switch_cell_type      : fine_grain;
        is_macro_cell        : true;
        pg_pin(VDD) {
            voltage_name      : VDD;
            pg_type           : primary_power;
            direction         : inout;
        }
        pg_pin(VDDA) {
            voltage_name      : VDDA;
            pg_type           : primary_power;
            direction         : inout;
        }
        pg_pin(VSS) {
            voltage_name      : VSS;
            pg_type           : primary_ground;
            direction         : inout;
        }
        pg_pin(VDDSW) {
```

## Virtuoso Power Manager User Guide

### Exporting Power Intent of a Design

---

```
    switch_function      : "psw_en";
    voltage_name        : VDDSW;
    pg_function         : VDD;
    pg_type             : internal_power;
    direction           : internal;
}
#####
pin(en_iso) {
    related_ground_pin  : VSS;
    related_power_pin   : VDD;
    direction           : input;
}
pin(in1) {
    related_ground_pin  : VSS;
    related_power_pin   : VDD;
    direction           : input;
}
pin(out1) {
    power_down_function : "!VDD + VSS";
    related_ground_pin  : VSS;
    related_power_pin   : VDD;
    direction           : output;
}
pin(out_iso) {
    is_isolated         : true;
    power_down_function : "!VDD + VSS";
    related_ground_pin  : VSS;
    related_power_pin   : VDD;
    isolation_enable_condition : "en_iso";
    direction           : output;
}
pin(out_psw) {
    power_down_function : "!VDD + VSS";
    related_ground_pin  : VSS;
    related_power_pin   : VDD;
    direction           : output;
}
pin(outvdd) {
    power_down_function : "!VDD + VSS";
    related_ground_pin  : VSS;
    related_power_pin   : VDD;
}
```

## Virtuoso Power Manager User Guide

### Exporting Power Intent of a Design

---

```
        direction          : output;
    }
    pin(psw_en) {
        antenna_diode_related_ground_pins : "VSS";
        switch_pin          : true;
        related_ground_pin  : VSS;
        related_power_pin   : VDD;
        direction          : input;
    }
} /* end of cell top */

} /* end of library upf_export */
```

The following points explain the different sections of the exported Liberty power model:

- **Section1:** This section includes the basic design information in terms of the library and cell names for which the Liberty power model has been extracted and the software version used for the same.
- **Section2:** This section represents the library description. These are library level features and attributes.

The library level `voltage_map` attribute associates the voltage name with the relative voltage values. These specified voltage names are referenced by the `pg_pin` groups defined at the cellview level. The voltage map can be a combination of both the primary power and ground supplies and bias power and ground supplies. Voltage values in the Liberty power model should follow the voltage values of the top-level design power intent where model is integrated unless a corresponding error is flagged at the power intent verification stage by CLP.

- **Section3:** This section represents the cell group information and the related attributes. The cell group statement gives the name of the cell being described. It appears at the library group level. The Liberty power model exports the power intent of the design, therefore, the information in this group comprises of:
  - `is_macro_cell`: The attribute identifies whether a cell is a macro cell.
  - `switch_cell_type`: This attribute supports macro cells with internal switches present to generate internal power. The valid values for this attribute are `coarse_grain` and `fine_grain`.
  - **Pin level attributes:** The different pin level attributes, such as `pg_pin`, `pg_type`, `power_down_function`, `related_power_pin`, `related_ground_pin`, `input_signal_level` and `output_signal_level` describe the specific information extracted from the design schematic by Power Manager extractor for all

the boundary ports (PG and data). The state of these attributes is dependent on the setup registration for PG nets, connectivity, and design topology.

- ❑ **Macro Cell Modeling:** The attributes `is_isolated`, `isolation_enable_condition`, `switch_pin`, `switch_function`, `pg_function`, and `pg_types` are required for macro cell modeling. These are required to model the cells, which use low power special cells, such as isolation cells and power switch cells connected to boundary ports.

For more information on the 1801 commands, refer to *Liberty User Guides and Reference Manual Suite* (Version 2017.06).

### ***Related Topics***

[Setup for Automatic Extraction of Power Intent](#)

[vpmExportDotLib](#)

[Extracting the Power Intent from a Design](#)

[Creation of Power Domains](#)

[Exporting 1801 Design Model](#)

[Exporting 1801 Power Model](#)

[Special Isolation Cells in Liberty Power Model Export](#)

## **Special Isolation Cells in Liberty Power Model Export**

Ports connected to NOR or NAND type isolations cells must be handled carefully in the Liberty power model export flow to ensure there are enough attributes to indicate related power or ground for actual data receivers in a megacell or to indicate that enable pins cannot be off in the partial power down state.

The following three scenarios are addressed in the tool while handling ports connected to isolation cells:

- Input ports connected to NOR/NAND isolation cell data pins
  - ❑ No changes are made to the `related_power_pin` or `related_ground_pin` attribute values.

## Virtuoso Power Manager User Guide

### Exporting Power Intent of a Design

---

- ❑ The `alive_during_power_up` attribute is added if a NOR/NAND isolation cell has inverted input. This ensures that the input cannot be floating when ports related power and ground pins are on.
- ❑ The `isolation_sink_power_pin` and `isolation_sink_ground_pin` attributes are added to indicate related power/ground pins for a data receiver inside a megacell.
- Input ports connected to NOR/NAND isolation cell enable pins
  - ❑ When the value of `updateRelatedSuppliesForNorNandIsoPorts = t`.
    - If the sink of the isolation cell is some logic visible inside a macro, the `related_power_pin` or `related_ground_pin` values are updated based on the supply powering the logic connected to the isolation output. The `alive_during_partial_power_down` or `permit_power_down` attributes are not added.
    - If the immediate fanout of an isolation cell is a top-level port, there is no change made to the `related_power_pin/related_ground_pin` attribute values. The `alive_during_partial_power_down` attribute is added only if the isolation cell output is not inverted to indicate that the enable driver supply must be on when the cell is in the partial power down state. The `permit_power_down` attribute is added only if the isolation cell output is not inverted. This attribute is added on the power pin for a NOR isolation cell and on the ground pin for a NAND isolation cell to indicate that the related supply can be off while in isolation mode.
  - ❑ When the value of `updateRelatedSuppliesForNorNandIsoPorts = nil` (default).
    - No changes are done in the `related_power_pin` or `related_ground_pin` attribute values. The `alive_during_partial_power_down` attribute is added only if the isolation cell output is not inverted to indicate that the enable driver supply must be ON when the cell is in the partial power down state. The `permit_power_down` attribute is added to the related power or ground `pg_pin` only if the isolation cell output is not inverted.
- Output ports connected to NOR/NAND isolation cell output pin
  - ❑ When the value of `updateRelatedSuppliesForNorNandIsoPorts = t`.
    - If the isolation enable immediate driver is not a macro input port, the related power pin or related ground pin values are updated based on the supply of the driver of the isolation cell enable pin.

## Virtuoso Power Manager User Guide

### Exporting Power Intent of a Design

---

- The `isolation_data_power_pin` and `isolation_data_ground_pin` attributes are added to indicate related power/ground for a data driver inside a megacell.
- If the isolation enable immediate driver is a macro input port, no changes are required in the `related_power_pin` or `related_ground_pin` attribute values. The `alive_during_partial_power_down` attribute is added to the output pin if the NOR/NAND isolation cell is without an inverted output. The `permit_power_down` attribute is added on the power pg pin of a NOR isolation cell or ground pg pin of a NAND isolation cell. The `isolation_data_power_pin` and `isolation_data_ground_pin` attributes are added to indicate the supply of the isolation cell data pin. A warning message is issued that the isolation enable signal is not buffered and is a direct connection to a macro port.
- When the value of `updateRelatedSuppliesForNorNandIsoPorts = nil` (default).
  - No changes are made to the `related_power_pin` or `related_ground_pin` attribute values. The `alive_during_partial_power_down` attribute is added only if the NOR/NAND isolation cell is without an inverted output. The `permit_power_down` attribute is added only if the isolation cell is without an inverted output. This attribute is added on the power pg pin of a NOR isolation cell or ground pg pin of a NAND isolation cell.
  - The `isolation_data_power_pin` and `isolation_data_ground_pin` attributes are added to indicate related power/ground for a data driver inside a megacell.
  - If the isolation enable immediate driver is not a macro input port, the `power_down_function` attribute is updated to include clamp driver supplies and the `isolation_enable_condition` attribute.
  - If the isolation enable immediate driver is a macro input port, the `power_down_function` attribute is updated to include a macro input port connected enable pin. The `alive_during_partial_power_down` is set `true` on the macro port connected to an enable pin. A warning message is issued that the isolation enable signal is not buffered and is a direct connection to a macro port.

### ***Related Topics***

[printAliveAndPermitAttributesinDotlib](#)

[updateRelatedSuppliesForNorNandIsoPorts](#)

[Extracting the Power Intent from a Design](#)

[Creation of Power Domains](#)

[Exporting 1801 Design Model](#)

[Exporting Liberty Power Model](#)

[Exporting Liberty Power Model](#)

## Export of Switch Function and Isolation Enable Condition Expressions

In a Liberty Power Model export, it is important to export the derivation or knowledge to interpret `switch_function` and `isolation_enable_condition` expressions to ensure that you are able to perform the following tasks:

- Correlate the generated expressions with a schematic.
- Establish the accuracy of the generated expressions and design intent.

You can register the names of virtual supply nets that need the `switch_function` derivation by using the following option in a setup file.

```
virtualSuppliesForSwitchFunctionDerivation "VDD VDD_CPU VDD_LDO"
```

You can register the names of the data port names that need the `isolation_enable_condition` derivation by using the following option in a setup file.

```
signalPortsForIsoEnableConditionDerivation "OUT OUT2 IN1"
```

Regular expressions for virtual supply and port names is supported. The step-by-step derivation of `switch_functions` for registered virtual supply nets and `isolation_enable_conditions` for registered data ports appear in the CIW and in the extractor log file. However, this information is shown only if the `pg_pin` or data pin is included in a Liberty model.

Alternatively, you can use the environment variables to export the derivations.

# Virtuoso Power Manager User Guide

## Exporting Power Intent of a Design

---

### ***Related Topics***

[exportSwitchFunctionDerivationForAllUsedVirtualSupplies](#)

[exportIsoEnableConditionDerivationForAllTopIsolatedPorts](#)

[signalPortsForIsoEnableConditionDerivation](#)

[virtualSuppliesForSwitchFunctionDerivation](#)

# Virtuoso Power Manager User Guide

## Exporting Power Intent of a Design

---

---

## Verifying Power Intent of a Design

---

After completing the power intent specification for your design, you need to verify the correctness of the power intent as per the design. When you verify the design by using Power Manager, the tool automatically runs Conformal Low Power (CLP) that reads the power intent and generates a report with appropriate messages.

### ***Related Topics***

[Preparing and Running CLP](#)

[Checking Design Hierarchy](#)

[Power Intent Verification Requirements](#)

## Preparing and Running CLP

Ensure that the following setup is done before you start verification using CLP:

- You have set the license for the Mixed-signal Option to Conformal Low Power (95127).
- You have set the path to the binary file of CLP, `lec`, in the UNIX path.
- You have checked the design hierarchy and ensured that there are no errors in the design.
- You have checked the power intent of the design to ensure its completeness.
- You have defined the reference Verilog and Liberty files by including `read library` statements in the dofile (a file with set of commands required as inputs for power intent verification). This ensures that Conformal Low Power does not report the missing reference libraries. For more information on Conformal Low Power, refer to *Conformal Low Power User Guide*.


To verify the power intent:

## Virtuoso Power Manager User Guide


### Verifying Power Intent of a Design

---

1. Click *Power Manager – Run CLP* if you already have the required dofiles.



2. [Optional] Otherwise, before running the CLP, use the Prepare CLP form to generate the 1801 file, Verilog netlist, and CLP dofile at the specified path.



**Note:** The *1801 File* and *Liberty Files* field do not require explicit user inputs, if a setup template file already exists and is loaded for the cellview to extract and verify the power intent.

The netlist generated by the *Prepare CLP* form is different from the general netlist created by NC-Verilog. This netlist includes a list of Verilog stub views for the macro models, single supply analog modules along with their power and ground pins, and the blocks that are binded to the existing power intent (1801). This makes the netlist more compatible with CLP. The log file generated, after the preparations for the CLP run are over, displays the results along with the following details:

- Date and time

## Virtuoso Power Manager User Guide

### Verifying Power Intent of a Design


---

- Design details
- Form field values
- Netlist/1801/dofile file paths
- Netlist error/warnings
- The 'si.env' file used for netlisting
- CLP log file path

## Virtuoso Power Manager User Guide

### Verifying Power Intent of a Design

- ❑ The CLP Run command for command line



3. Click *Run CLP* to start CLP and use the files created during CLP preparation, for power verification. The CLP run initiates when you click *OK*.


This two-step process, which includes preparing for CLP and running CLP, lets you check the input files and resolve issues, if any, before proceeding for the CLP run. Subsequently, you can run CLP from Power Manager by specifying a run directory and a CLP dofile.

# Virtuoso Power Manager User Guide

## Verifying Power Intent of a Design

Alternatively, you can run CLP from the command line once the input files are generated using Power Manager.

After the verification is complete, the generated report is displayed in a separate log window as shown below.



```

: Edit View Help
CONFORMAL (R) Verify
Version 18.10-s300 (23-Aug-2018) (64 bit executable)
Copyright (c) Cadence Design Systems, Inc., 1997-2018. All Rights Reserved

s program is proprietary and confidential information belonging to
Cadence Design Systems, Inc., and may be used and disclosed only as authorized
by a license agreement controlling such use and disclosure.

Warning: This version is 205 days old. You can download the latest version from http://downloads

Command: set lowpower option -witness_limit 0
Command: set lowpower option -native_1801
Command: set lowpower option -analysis_style post_route
Command: set lowpower option -no_use_strategy_location_as_hierarchy
Command: set lowpower option -only_extract_macro_with_attribute
Command: set lowpower option -check_iso_on_to_off_not_required
Command: set lowpower option -OVERWRITE_PHYSICAL_SUPPLY_SET_BY_SPA_FOR_BB0X
Command: set undef cell black_box
Command: SET D0FILE AB0RT off
Command: add search path ./prepareCLP
Command: read library -Liberty -nosensitive -both -LP \
/servers/cic_pe/bsachin/VPM/TESTCASES/Webinar3_TC_Export/libs/fast_vdd1v0_basicCells.lib
/servers/cic_pe/bsachin/VPM/TESTCASES/Webinar3_TC_Export/libs/fast_vdd1v0_extvdd1v0.lib
/servers/cic_pe/bsachin/VPM/TESTCASES/Webinar3_TC_Export/libs/fast_vdd1v2_extvdd1v0.lib
/servers/cic_pe/bsachin/VPM/TESTCASES/Webinar3_TC_Export/libs/fast_vdd1v0_extvdd1v2.lib
/servers/cic_pe/bsachin/VPM/TESTCASES/Webinar3_TC_Export/libs/macro lib.lib
```

### ***Related Topics***

[Power Intent Check](#)

[Prepare CLP Form](#)

[Verifying Power Intent of a Design](#)

[Checking Design Hierarchy](#)

[Power Intent Verification Requirements](#)

## Checking Design Hierarchy

Before verifying the power intent for your design, it is recommended that you check the connectivity information in the design hierarchy by choosing *Check – Hierarchy*. The **Check Hierarchy** form is displayed. Select the appropriate check options on this form and click *OK*.



For more details about the check options, refer to Check Hierarchy Form in the Virtuoso Schematic Editor user guide. This check is not run if you remove netSet properties from the design.

### Power Intent Check

Power intent can be defined as incomplete in any of the following scenarios:

- Incomplete power domains
  - Missing power net or ground net
  - Power or ground net is an internal net in a macro model
  - Missing base domain, when shut-off condition is present
  - Specified power or ground nets are not a part of design
- Incomplete low power rules
  - Incomplete isolation rules
  - Incomplete power switch rules
- Incomplete low power cells
  - Missing power or ground pins
  - Missing enable pins, specific for the isolation cells
- Missing off conditions
  - Missing off condition, when switchable domains are present
- Missing power modes
  - No power mode
  - Missing power mode in which all domains are on

## Virtuoso Power Manager User Guide

### Verifying Power Intent of a Design

---

- ❑ Missing power mode in which software domains are off
- Unmapped ports of the design—All ports of the design must either belong to a power domain, floating ports, or feed-through port list, or the power intent is treated as incomplete
- Unmapped supply nets in the design—All supply nets must be a part of some power domain (either as direct Power/Ground net or as equivalent power/ground net), or the power intent is treated as incomplete

#### ***Related Topics***

[Check Hierarchy Form](#)

[Verifying Power Intent of a Design](#)

[Checking Design Hierarchy](#)


[Power Intent Verification Requirements](#)

## **Power Intent Verification Requirements**

The accurate power intent verification using CLP has the following mandatory requirements before proceeding for preparing and subsequently running CLP.

- `cmos_sch`, `schematic`, or `Verilog_PG` (Non-text) required as stop views for PDK cells (Standard/Special cells).
  - ❑ If `cmos_sch`, `schematic`, or `Verilog_PG` (symbol) exists with power and ground pins, they can be consumed as it is.

A Verilog symbol view with the PG information is illustrated below.



- A netlist control file having flags for specific netlist customizations.

## Virtuoso Power Manager User Guide

### Verifying Power Intent of a Design

---

If you explicitly specify a netlist control file during preparation for running CLP, set the following flags appropriately:

- ❑ To ensure that the power and ground information is correctly captured in the netlist. This is required for correct power intent verification of the design.

- `hnlInhConnUseDefSigName='t`
- `vlogifDeclareGlobalNetLocal='t`
- `hnlPrintInhConAtTop='t`
- `hnlHonorInhConnEscapeName='t`
- `hnlVerilogDeclareScalarSig='t`
- `simVerilogEnableEscapeNameMapping='t`
- `hnlMapNetInName`
- `hnlMapTermInName`

- ❑ To ensure that redundant information does not show at the module or instance level in the netlist. For example, information of primitive devices (mos/resistor/capacitors and diodes).

`hnlUserIgnoreCVList`

- ❑ For creating the stub view (no module definition) for macro Liberty blocks, just an instance line with power/ground nets that is identified by traversing the schematic.

`hnlUserStubCVList`

### ***Related Topics***

[Virtuoso NC Verilog Environment User Guide](#)

[Open Simulation System Reference](#)

[Verifying Power Intent of a Design](#)

[Checking Design Hierarchy](#)

---

## **Virtuoso Power Manager Environment Variables**

---

The topic provides information on the names, descriptions, and graphical user interface equivalents for the Virtuoso Power Manager environment variables.

## **addNotInGndPgFunction**

```
lp addNotInGndPgFunction boolean { t | nil }
```

### **Description**

Controls printing `pg_function` for ground switchable supplies. The `pg_function` value is printed as `VSS` if the variable is set to `nil`. The default value is `nil`.

### **GUI Equivalent**

None

### **Example**

```
envGetVal ("lp" "addNotInGndPgFunction")  
envSetVal ("lp" "addNotInGndPgFunction" 'boolean nil)
```

### ***Related Topics***

[Handling of Low Power Special Cells](#)

## **allowConstantExpressions**

```
lp allowConstantExpressions boolean { t | nil }
```

### **Description**

Prints original expressions instead of constant-value expressions when set to `nil`. During boolean optimization, if a function expression evaluates to `true(1)` or `false(0)`, the corresponding expression values printed by default in a `dotlib` or `1801` file are `1` or `0` respectively. However, if constant-value expressions are not required, you can print original expressions.

### **GUI Equivalent**

None

### **Example**

```
envGetVal("lp" "allowConstantExpressions")  
envSetVal("lp" "allowConstantExpressions" 'boolean nil)
```

### ***Related Topics***

[Exporting 1801 Design Model](#)

[Exporting 1801 Power Model](#)

## **allowDomainWithoutElements**

```
lp allowDomainWithoutElements boolean { t | nil }
```

### **Description**

Controls the creation of power domains exported in the 1801 file based on their constituent elements.

When `allowDomainWithoutElements` is `t`, only power domains without elements are exported in the 1801 file. If this variable is set to the default value `nil`, the power domains that have instances/elements are exported in the 1801 file and the domains without any elements are not exported in the 1801 file.

### **Default scenario**

```
create_power_domain pd__vddB_init__vssB \  
-elements { i_block } \  
-supply { primary ss__vddB_init__vssB } \  
-supply { extra_supplies "" }
```

```
create_power_domain pd__vddA__vssA \  
-include_scope \  
-supply { primary ss__vddA__vssA } \  
-supply { extra_supplies "" }
```

### **Non Default scenario**

```
create_power_domain pd__vddB_init__vssB \  
-elements { i_block } \  
-supply { primary ss__vddB_init__vssB } \  
-supply { extra_supplies "" }
```

```
create_power_domain pd__vddB__vssB \  
-supply { primary ss__vddB__vssB } \  
-supply { extra_supplies "" }
```

```
create_power_domain pd__vddA__vssB \  
-supply { primary ss__vddA__vssB } \  
-supply { extra_supplies "" }
```

```
create_power_domain pd__vddA__vssA \  
-elements { . } \  
-supply { extra_supplies "" }
```

# Virtuoso Power Manager User Guide

## Virtuoso Power Manager Environment Variables

---

```
-supply { primary ss__vddA__vssA } \  
-supply { extra_supplies "" }
```

### GUI Equivalent

None

### Examples

```
envGetVal("lp" "allowDomainWithoutElements")  
envSetVal("lp" "allowDomainWithoutElements" 'boolean t)
```

### *Related Topics*

[Registering Supply Set and Power Domain](#)

## **allowEmptyDomains**

```
lp allowEmptyDomains boolean { t | nil }
```

### **Description**

Controls the printing of a supply or ground net as an internal power or internal ground pin if they are not associated with any power domain. The default value is `nil`. These supply or ground nets are not the related power or related ground pin of any signal pins.

### **GUI Equivalent**

None

### **Example**

```
envGetVal("lp" "allowEmptyDomains")  
envSetVal("lp" "allowEmptyDomains" 'boolean nil)
```

### ***Related Topics***

[Registering Supply Set and Power Domain](#)

## **allowInoutLDOPins**

```
lp allowInoutLDOPins boolean { t | nil }
```

### **Description**

Identifies supply nets, meeting the LDO net detection criteria, even when the nets are connected to `inout` pin/term, when the flag is set to `t`. The default value is `nil` and the extractor includes nets without a term or with an output term.

### **GUI Equivalent**

*Power Manager Setup Form – Export tab – Export Options – Consider inputOutput terms for internal power criterion*

### **Example**

```
envGetVal("lp" "allowInoutLDOPins")  
envSetVal("lp" "allowInoutLDOPins" 'boolean nil)
```

### ***Related Topics***

[Registering Name-Based Supply Nets](#)

[Registering Regular Expressions-Based Supply Nets](#)

## **allowInoutMonitorPins**

```
lp allowInoutMonitorPins boolean { t | nil }
```

### **Description**

Identifies supply nets, meeting the monitor net detection criteria, even when the nets are connected to `inout` pin/term, when the flag is set to `t`. The default value is `nil` and the extractor includes only the nets with the output term.

### **GUI Equivalent**

*Power Manager Setup Form – Export tab – Export Options – Consider inputOutput terms for monitor power criterion*

### **Example**

```
envGetVal("lp" "allowInoutMonitorPins")  
envSetVal("lp" "allowInoutMonitorPins" 'boolean nil)
```

### ***Related Topics***

[Registering Monitor Nets](#)

## **allowInOutPortAsRegulated**

```
lp allowInOutPortAsRegulated boolean { t | nil }
```

### **Description**

Considers supplies connected to the `inout` port as regulated. The default value is `nil`. By default, only supplies connected to output port or not connected to any port are considered as regulated supplies.

### **GUI Equivalent**

None

### **Example**

```
envGetVal("lp" "allowInOutPortAsRegulated")  
envSetVal("lp" "allowInOutPortAsRegulated" 'boolean nil)
```

### ***Related Topics***

[Registering Port Attributes](#)

## **allowIsUnconnectedAsAttrInLiberty**

```
lp allowIsUnconnectedAsAttrInLiberty boolean { t | nil }
```

### **Description**

Prints the `is_unconnected` attribute as the main code in the Liberty file, when the flag is set to the default value `t`. When the environment variable is set to `nil`, the `is_unconnected` attribute is printed as comment in the Liberty file. When `allowIsUnconnectedAsAttributeInLiberty` is `true`, the Liberty file has the following user-defined attributes printed as a part of the Library group attributes of the exported Liberty file.

```
define ("is_unconnected", "pin", "boolean");  
define ("is_unconnected", "pg_pin", "boolean");
```

### **GUI Equivalent**

None

### **Example**

```
envGetVal("lp" "allowIsUnconnectedAsAttrInLiberty")  
envSetVal("lp" "allowIsUnconnectedAsAttrInLiberty" 'boolean nil)
```

### ***Related Topics***

[Connectors](#)

## considerShortThreshold

```
lp considerShortThreshold boolean { t | nil }
```

### Description

Considers resistor elements as connectors or short devices based on the threshold value of resistors specified in a setup file. The default value is `t`.

In a specific cellview, the parameter value of resistors is checked against the threshold value and are considered as short devices if their parameter value is less than the threshold value. If the parameter value is above the threshold value, the resistors are considered as connector elements. When there is no threshold value defined, the default behavior is that resistors are considered as short devices or connectors based on the category in which they are originally registered.

For example, for `CellA`, parameter `r` is checked for its value. A value lower than 50 is considered as a short. For `CellB`, parameter `resVal` is checked for its value. A value higher than 10 is considered as connector.

```
connector (  
  ("VPM_TEST_LIB2" "CellA" nil  
    (nil  
      RestreshHold("r" 50)  
    )  
  )  
  ("VPM_TEST_LIB1" "CellB" nil  
    (nil  
      RestreshHold("resVal" 10)  
    )  
  )  
  ("VPM_TEST_LIB2" "CellC" nil)  
  ("VPM_TEST_LIB2" "CellD" nil)  
)
```

### GUI Equivalent

None

### Example

```
envGetVal("lp" "considerShortThreshold")
```

## Virtuoso Power Manager User Guide

### Virtuoso Power Manager Environment Variables

---

```
envSetVal("lp" "considerShortThreshold" 'boolean t)
```

#### ***Related Topics***

[Connectors](#)

[Resistors as Short Devices](#)

## **createExtractionLogFile**

```
lp createExtractionLogFile boolean { t | nil }
```

### **Description**

Prints extraction messages to a log file. The default value is `nil`.

### **GUI Equivalent**

None

### **Example**

```
envGetVal("lp" "createExtractionLogFile")  
envSetVal("lp" "createExtractionLogFile" 'boolean nil)
```

### ***Related Topics***

[Extracting the Power Intent from a Design](#)

## **createPinsOnImport**

```
lp createPinsOnImport boolean { t | nil }
```

### **Description**

Controls the creation of ports in the design while importing the 1801 file. This is based on the `create_supply_port` command found in the input 1801 file.

The default value is `t`. When set to `t`, ports are created in the design. If set to `nil`, a supply net with a global net expression or supply local net is created by using the `Create_supply_port` and `Create_supply_net` commands in the input 1801 file based on the `resolveTopNets` argument of `vpmImportPowerIntent`.

### **GUI Equivalent**

None

### **Example**

```
envGetVal("lp" "createPinsOnImport")  
envSetVal("lp" "createPinsOnImport" 'boolean nil)
```

### ***Related Topics***

[Extracting the Power Intent from a Design](#)

[vpmImportPowerIntent](#)

## delimiterForInternalPower

```
lp delimiterForInternalPower string "__"
```

### Description

Specifies a delimiter for internal supplies that are referenced by the Liberty file generated by Power Manager. The default value is "\_\_".

```
voltage_map( I0__gnd_int , 0.000000);  
voltage_map( I0__vdd_int , 0.800000);  
  
pg_pin(I0__vdd_int) {  
  witch_function      : "!(Enable)";  
  voltage_name        : I0__vdd_int;  
  pg_function         : vdd;  
  pg_type             : internal_power;  
  direction           : internal;  
}  
pg_pin(I0__gnd_int) {  
  switch_function     : "Sleep";  
  voltage_name        : I0__gnd_int;  
  pg_function         : gnd;  
  pg_type             : internal_ground;  
  direction           : internal;  
}  
  
pin(data) {  
  related_ground_pin  : I0__gnd_int;  
  related_power_pin   : I0__vdd_int;  
  direction           : input;
```

### GUI Equivalent

None

### Examples

```
envGetVal("lp" "delimiterForInternalPower")  
envSetVal("lp" "delimiterForInternalPower" 'string ",")
```

# Virtuoso Power Manager User Guide

## Virtuoso Power Manager Environment Variables

---

### ***Related Topics***

[Exporting Liberty Power Model](#)

## **enableCDMAttr**

```
lp enableCDMAttr boolean { t | nil }
```

### **Description**

Provides support for the `has_CDM` attribute, when set to `t`. The default value is `nil`.

### **GUI Equivalent**

None

### **Examples**

```
envGetVal("lp" "enableCDMAttr")  
envSetVal("lp" "enableCDMAttr" 'boolean t)
```

### ***Related Topics***

[Exporting Liberty Power Model](#)

## **exportSwitchFunctionDerivationForAllUsedVirtualSupplies**

```
lp exportSwitchFunctionDerivationForAllUsedVirtualSupplies boolean { t | nil }
```

### **Description**

Provides `switch_function` derivations for all virtual supplies included in dotlib, when set to `t`. The default value is `nil`, which means no derivation is printed in the CIW.

### **GUI Equivalent**

None

### **Examples**

```
envGetVal ("lp" "exportSwitchFunctionDerivationForAllUsedVirtualSupplies")  
envSetVal ("lp" "exportSwitchFunctionDerivationForAllUsedVirtualSupplies" 'boolean  
t)
```

### ***Related Topics***

[Export of Switch Function and Isolation Enable Condition Expressions](#)

[signalPortsForIsoEnableConditionDerivation](#)

[virtualSuppliesForSwitchFunctionDerivation](#)

[exportIsoEnableConditionDerivationForAllTopIsolatedPorts](#)

## **exportIsoEnableConditionDerivationForAllTopIsolatedPorts**

```
lp exportIsoEnableConditionDerivationForAllTopIsolatedPorts boolean { t | nil }
```

### **Description**

Provides `isolation_enable_condition` derivations for all isolated ports included in `dotlib`, when set to `t`. The default value is `nil`, which means no derivation is printed in the CIW.

### **GUI Equivalent**

None

### **Examples**

```
envGetVal("lp" "exportIsoEnableConditionDerivationForAllTopIsolatedPorts")  
envSetVal("lp" "exportIsoEnableConditionDerivationForAllTopIsolatedPorts"  
'boolean t)
```

### ***Related Topics***

[Export of Switch Function and Isolation Enable Condition Expressions](#)

[signalPortsForIsoEnableConditionDerivation](#)

[exportSwitchFunctionDerivationForAllUsedVirtualSupplies](#)

[virtualSuppliesForSwitchFunctionDerivation](#)

## **extractionLogPath**

```
lp extractionLogPath string "."
```

### **Description**

Controls the printing of the extraction log file at the path provided. The default value is "." and the extraction log is generated in the current working directory.

### **GUI Equivalent**

None

### **Examples**

```
envGetVal("lp" "extractionLogPath")  
envSetVal("lp" "extractionLogPath" 'string ".abc/testlib/ext.log")
```

### ***Related Topics***

[Extracting the Power Intent from a Design](#)

## **extractParasiticDiode**

```
lp extractParasiticDiode boolean { t | nil }
```

### **Description**

Controls the detection and printing of parasitic diode elements formed between the bulk terminal and source terminal, bulk terminal and drain terminal, or between MOS devices. When set to `t`, the parasitic diode information gets extracted in terms of the `antenna_diode_related_power_pins` and `antenna_diode_related_ground_pins` attributes corresponding to data pins at the source or drain end of a MOS device. The default value is `nil`.

### **GUI Equivalent**

None

### **Examples**


```
envGetVal("lp" "extractParasiticDiode")
```

# Virtuoso Power Manager User Guide


## Virtuoso Power Manager Environment Variables

---

With `envSetVal("lp" "extractParasiticDiode" 'boolean t)`



```
pin(A) {
  antenna_diode_related_power_pins : "VDD1";
  direction : "input";
  related_power_pin : "VDD1";
  related_ground_pin : "VSS1";
}
```



```
pin(A) {
  antenna_diode_related_ground_pins : "VSS1";
  direction : "input";
  related_power_pin : "VDD1";
  related_ground_pin : "VSS1";
}
```

### **Related Topics**

[Connectors](#)

## **lpDBGGlobalSearchLibs**

```
lp lpDBGGlobalSearchLibs string { "LibName" }
```

### **Description**

Sets the library list look-up order for enabling the power view creation in a different library if the parent library is not editable. This enables the power view creation and subsequent access of the cellview.

By default, no library name is specified. The parent library is the location for power view creation.

Else, the specified library name or a list of library names are considered as the location for power view creation.

### **GUI Equivalent**

None

### **Examples**

```
envGetVal("lp" "lpDBGGlobalSearchLibs")  
envSetVal("lp" "lpDBGGlobalSearchLibs" 'string "DESIGN_LIB_LDO DESIGN_NEW_LIB_LDO")
```

This would enable the creation and opening of the power view of the cell in the libraries DESIGN\_LIB\_LDO or DESIGN\_NEW\_LIB\_LDO. The order of look-up to create and access the power view is from DESIGN\_LIB\_LDO until DESIGN\_NEW\_LIB\_LDO. If the library DESIGN\_LIB\_LDO is not editable, the power view is created and accessed from library DESIGN\_NEW\_LIB\_LDO.

### ***Related Topics***

[Power View](#)

## **lpDBGlobalSearchViews**

```
lp lpDBGlobalSearchViews string { "power" }
```

### **Description**

Sets the look-up order of the list of power view names for enabling the power view creation in a different library if the parent library is not editable. This enables the access of the power view created using `lpDBGlobalSearchLibs`, which is based on the power view name. The power view name is looked up in the same order for the power view creation in the library as defined in [lpDBGlobalSearchLibs](#).

By default, `power` is specified as the power view name.

Else, the specified power view name or a list of power view names are considered as power views.

### **GUI Equivalent**

None

### **Examples**

```
envGetVal("lp" "lpDBGlobalSearchViews")  
envSetVal("lp" "lpDBGlobalSearchLibs" 'string "pwr power")
```

This would enable the creation and opening of the power view of the cell in the libraries `DESIGN_LIB_LDO` or `DESIGN_NEW_LIB_LDO`. The order of look-up to create and access the power view is from `DESIGN_LIB_LDO` until `DESIGN_NEW_LIB_LDO`. If the library `DESIGN_LIB_LDO` is not editable, the power view is created and accessed from library `DESIGN_NEW_LIB_LDO`.

### ***Related Topics***

[Power View](#)

## **lpDBPurgeOnDesignPurge**

```
lp lpDBPurgeOnDesignPurge boolean { t | nil }
```

### **Description**

Controls the purging of the power view while closing the source design. The default value is `t`. By default, the power view is purged when the source design gets purged.

### **GUI Equivalent**

None

### **Example**

```
envGetVal("lp" "lpDBPurgeOnDesignPurge")  
envSetVal("lp" "lpDBPurgeOnDesignPurge" 'boolean nil)
```

### ***Related Topics***

[Power View](#)

## lsSingleRailInputPrefix

```
lp lsSingleRailInputPrefix string "int_"
```

### Description

For a single rail cell in case the modeling information is coming from 1801 special cell definition file, it would not contain information of the attribute `input_signal_level` corresponding to the liberty model. A virtual supply name, with the prefix `int_`, will be created from output supply of the single rail level shifter. The data ports of the single rail level shifter would thus be related to a supply set containing the virtual supply name and the name of the ground supply as related power and related ground.

```
voltage_map( vdd_Int[0] , 0.800000);  
    voltage_map( vdd_Int[1] , 0.800000);  
    voltage_map( vdd_Int[2] , 0.800000);
```

```
pg_pin(vdd_Int[1]) {  
voltage_name      : "vdd_Int[1]";  
pg_type           : internal_power;  
direction         : "internal";  
switch_function  : "Enable[1]";  
pg_function       : "vdd";  
}
```

```
pin(in1) {  
direction         : "inout";  
related_power_pin : "vdd_Int[1]";  
related_ground_pin : "I0[int]gnd_int[1]";  
}
```

### GUI Equivalent

None

### Examples

```
envGetVal("lp" "lsSingleRailInputPrefix")  
envSetVal("lp" "lsSingleRailInputPrefix" 'string "int_abcd"))
```

# Virtuoso Power Manager User Guide

## Virtuoso Power Manager Environment Variables

---

### ***Related Topics***

[Single Rail Cells](#)

## **maxConsecutiveTxChannelCrossingsForABT**

`lp maxConsecutiveTxChannelCrossingsForABT int channels`

### **Description**

Specifies the maximum number of channels for automatic backtracing of transistor logic seen in its flat form or inside algorithm standard cell. The backtracing stops if the successive channel crossings reach a predefined limit. The default value is 3 and it can be changed to any integer less than or equal to 5.

### **GUI Equivalent**

None

### **Example**

```
envSetVal("lp" "maxConsecutiveTxChannelCrossingsForABT" 'int 3)
```

### ***Related Topics***

[Backtrace Enable Signals of Special Cells](#)

## **maxConsecutiveTxGateCrossingsForABT**

`lp maxConsecutiveTxGateCrossingsForABT int gates`

### **Description**

Specifies the maximum number of gates for automatic backtracing of transistor logic seen in its flat form or inside algorithm standard cell. The backtracing stops if the successive gate crossings reach a predefined limit. The default value is 3 and it can be changed to any integer less than or equal to 5.

### **GUI Equivalent**

None

### **Example**

```
envSetVal("lp" "maxConsecutiveTxChannelCrossingsForABT" 'int 3)
```

### ***Related Topics***

[Backtrace Enable Signals of Special Cells](#)

## **maxInputPinsForAlgoStdCellABT**

`lp maxInputPinsForAlgoStdCellABT int maxInputPins`

### **Description**

Specifies the maximum number of input pins in a cell for an unregistered cell in the backtracing path and identified as an Algorithm Standard cell to be considered for automatic logic extraction. The default value is 3 and it can be changed to any integer less than or equal to 5.

### **GUI Equivalent**

None

### **Example**

```
envSetVal("lp" "maxInputPinsForAlgoStdCellABT" 'int 3)
```

### ***Related Topics***

[Backtrace Enable Signals of Special Cells](#)

## **maxOutputPinsForAlgoStdCellABT**

```
lp maxOutputPinsForAlgoStdCellABT int maxOutputPins
```

### **Description**

Specifies the maximum number of output pins in a cell for an unregistered cell in the backtracing path and identified as an Algorithm Standard cell to be considered for automatic logic extraction. If count of outputs pins exceeds the limit specified this variable, Virtuoso Power Manager will skip logic extraction for such a cell. The default value is 3 and it can be changed to any integer less than or equal to 5.

### **GUI Equivalent**

None

### **Example**

```
envSetVal("lp" "maxOutputPinsForAlgoStdCellABT" 'int 3)
```

### ***Related Topics***

[Backtrace Enable Signals of Special Cells](#)

## **overrideSigTypeFromSetup**

```
lp overrideSigTypeFromSetup boolean { t | nil }
```

### **Description**

Uses the signal type specified in the setup information to specify the signal type for a net with conflicting signal types. If this environment variable is set but the net with conflicting sigTypes is not defined as a supply in the Registered Supply Nets table, Power Manager issues a message (LP-3103) informing that it is not able to set sigType for this net. The default value is `nil`, in which case `sigType` is not overridden by using the setup.

### **GUI Equivalent**

None

### **Example**

```
envSetVal("lp" "overrideSigTypeFromSetup" 'boolean t)
```

## **minTimeElapseForProgressInfo**

```
lp minTimeElapseForProgressInfo int intervalSecs
```

### **Description**

Sets the interval in seconds at which periodic extraction process updates are issued. The default value is 20 and it can be changed to any value greater than or equal to 0.

The default specifies that the extraction progress logging starts 20 seconds after triggering the *Extract 1801 Power Intent* command and you will see extraction progress updates after every 20 seconds.

**Note:** The shorter the time period, the bigger the impact on system performance. To reduce run time, increase the time interval.

### **GUI Equivalent**

None

### **Example**

```
envGetVal("lp" "minTimeElapseForProgressInfo")  
envSetVal("lp" "minTimeElapseForProgressInfo" 'int 50)
```

## **overrideSigTypeFromSetup**

```
lp overrideSigTypeFromSetup boolean { t | nil }
```

### **Description**

Uses the signal type specified in the setup information to specify the signal type for a net with conflicting signal types. If this environment variable is set but the net with conflicting sigTypes is not defined as a supply in the Registered Supply Nets table, Power Manager issues a message (LP-3103) informing that it is not able to set sigType for this net. The default value is `nil`, in which case `sigType` is not overridden by using the setup.

### **GUI Equivalent**

None

### **Example**

```
envSetVal("lp" "overrideSigTypeFromSetup" 'boolean t)
```

## **powerDownFunctionForIOPorts**

```
lp powerDownFunctionForIOPorts boolean { t | nil }
```

### **Description**

Specifies the `power_down_func` attribute for inout ports in a Liberty file. The default value is `nil`, in which case `power_down_func` is not printed for inout ports.

### **GUI Equivalent**

None

### **Example**

```
envSetVal("lp" "powerDownFunctionForIOPorts" 'boolean t)
```

## **printAliveAndPermitAttributesinDotlib**

```
lp printAliveAndPermitAttributesinDotlib boolean { t | nil }
```

### **Description**

Prints the `alive` and `permit` attributes for ports connected to isolation cells. When set to `nil`, the attributes are not printed.

### **GUI Equivalent**

None

### **Example**

```
envGetVal("lp" "printAliveAndPermitAttributesinDotlib")  
envSetVal("lp" "printAliveAndPermitAttributesinDotlib" 'boolean t)
```

### ***Related Topics***

[Special Isolation Cells in Liberty Power Model Export](#)

## printBusBitDirectionInLiberty

```
lp printBusBitDirectionInLiberty boolean { t | nil }
```

### Description

Controls the printing of the direction attribute for bus bits in the exported macro Liberty power model. The default value is `nil`, in which case the direction attribute is printed at the bus group level. When set to `t`, the direction attribute is printed for each individual bus bit.

### GUI Equivalent

None

### Examples

```
envGetVal("lp" "printBusBitDirectionInLiberty")
```

With the value of `printBusBitDirectionInLiberty` as `nil` ->

```
bus(OUT) {  
  
    bus_type           : CDS_BUS_1_To_0;  
    related_power_pin  : VDD;  
    related_ground_pin : VSS;  
    power_down_function : "!VDD + VSS";  
}  
pin(OUT[0]) {  
    related_power_pin  : VDD;  
    related_ground_pin : VSS;  
    power_down_function : "!VDD + VSS";  
}  
  
}
```

With the value of `printBusBitDirectionInLiberty` as `t` ->

```
bus(OUT) {  
  
    bus_type           : CDS_BUS_1_To_0;  
    pin(OUT[1]) {  
        related_power_pin  : VDD;  
        related_ground_pin : VSS;  
        power_down_function : "!VDD + VSS";  
    }  
}
```

## Virtuoso Power Manager User Guide

### Virtuoso Power Manager Environment Variables

---

```
direction          : output;
related_power_pin  : VDD;
related_ground_pin : VSS;
power_down_function : "!VDD + VSS";
}
pin(OUT[0]) {
direction          : output;
related_power_pin  : VDD;
related_ground_pin : VSS;
power_down_function : "!VDD + VSS";
}
}
```

### ***Related Topics***

[Exporting Liberty Power Model](#)

## printCoupledSupplies

```
lp printCoupledSupplies boolean { t | nil }
```

### Description

When two shorted supply ports are encountered in a design, prints the user-defined attribute `coupled_supplies` in the exported macro Liberty power model and the corresponding `UPF_feedthrough` attributes of the `set_port_attributes` statements in the 1801 power intent file. The default value is `nil`, which means that the coupled supply attributes are not printed.

For example, the following user-defined attributes are printed for shorted supply ports `VDD1` and `VDD2` and shorted ground ports `VSS1` and `VSS2`.

### Liberty Power Model

```
library(DemoWebinar4) {  
    voltage_map( VDD1 , 1.000000);  
    voltage_map( VDD2 , 1.000000);  
    voltage_map( VSS1 , 0.000000);  
    voltage_map( VSS2 , 0.000000);  
    define (coupled_supplies, cell, string);  
    cell(TESTCELL_4) {  
        is_macro_cell          : true;  
        short(VDD2,VDD1);  
        short(VSS2,VSS1);  
        coupled_supplies      : "(VDD2 VDD1)(VSS2 VSS1)";  
    }  
}
```

### 1801 Design Model

```
set_port_attributes -ports { VDD2 VDD1 } -attribute {UPF_feedthrough TRUE}  
set_port_attributes -ports { VSS2 VSS1 } -attribute {UPF_feedthrough TRUE}
```

### GUI Equivalent

None

### Example

```
envGetVal("lp" "printCoupledSupplies")  
envSetVal("lp" "printCoupledSupplies" 'boolean t)
```

# Virtuoso Power Manager User Guide

## Virtuoso Power Manager Environment Variables

---

### ***Related Topics***

[Exporting Liberty Power Model](#)

[Special Isolation Cells in Liberty Power Model Export](#)

## **printModelInSDA**

```
lp printModelInSDA boolean { t | nil }
```

### **Description**

Adds model names to the exported UPF file when set to `t`. The default value is `nil`. By default, the command used is:

```
set_design_attributes -attribute top_ports_have_anon_supply 0
```

With value is set as `t`, the command used is:

```
set_design_attributes -models top -attribute top_ports_have_anon_supply 0
```

### **GUI Equivalent**

None

### **Examples**

```
envGetVal("lp" "printModelInSDA")  
envSetVal("lp" "printModelInSDA" 'boolean nil)
```

### ***Related Topics***

[Exporting 1801 Design Model](#)

## printProgressInfo

```
lp printProgressInfo boolean { t | nil }
```

### Description

Prints the progress report for power intent extraction process when set to `t`. The default value is `nil`, which means that the progress report is not printed.

The following information is reported for power intent extraction:

- Beginning and end of each extractor stage
- Beginning and end of a specific sub-stage within each extractor stage with its percentage completion
- Information on the total number of stages and the current stage
- OA objects and the numbers recently processed

### GUI Equivalent

None

### Example

```
envGetVal("lp" "printProgressInfo")  
envSetVal("lp" "printProgressInfo" 'boolean nil)
```

### ***Related Topics***

[Extracting the Power Intent from a Design](#)

## **printSupplyNetInfo**

```
lp printSupplyNetInfo boolean { t | nil }
```

### **Description**

Prints the list of design nets that have been identified under any category of supply nets, such as `power`, `ground`, `exclude`, `monitor`, `pwell`, `nwell`, `deeppwell`, or `deepnwell` when the flag is set to `t`. The default value of the flag is `nil`.

### **GUI Equivalent**

None

### **Example**

```
envGetVal("lp" "printSupplyNetInfo")  
envSetVal("lp" "printSupplyNetInfo" 'boolean nil)
```

### ***Related Topics***

[Extracting the Power Intent from a Design](#)

## reduceBoolExpressions

```
lp reduceBoolExpressions boolean { t | nil }
```

### Description

Optimizes boolean functions during the dotlib export and 1801 export when set to `t`. For the dotlib export, the boolean expressions for `isolation_enable_condition` and `switch_function` attributes are optimized. For the 1801 export, the values for `-isolation_signal` in `set_isolation` and the values for `-on_state` and `-off_state` expressions in `create_power_switch` are optimized. By default, the boolean expression optimization is disabled.

### GUI Equivalent

None

### Example

```
envGetVal("lp" "reduceBoolExpressions")  
envSetVal("lp" "reduceBoolExpressions" 'boolean t)
```

### *Related Topics*

[Exporting 1801 Design Model](#)

[Exporting 1801 Power Model](#)

## **removeHierADSupForPorts**

```
lp removeHierADSupForPorts boolean { t | nil }
```

### **Description**

Removes hierarchical supplies for input, inout, and output ports when set to `t`. The default value of the flag is `nil`.

### **GUI Equivalent**

None

### **Examples**

```
envGetVal("lp" "removeHierADSupForPorts")  
envSetVal("lp" "removeHierADSupForPorts" 'boolean t)
```

### ***Related Topics***

[Support of Hierarchical 1801 for Import Flow](#)

## **removeHierSupForInPorts**

```
lp removeHierSupForInPorts boolean { t | nil }
```

### **Description**

Removes hierarchical supplies for input ports when set to `t`. The default value of the flag is `nil`.

### **GUI Equivalent**

None

### **Examples**

```
envGetVal("lp" "removeHierSupForInPorts")  
envSetVal("lp" "removeHierSupForInPorts" 'boolean t)
```

### ***Related Topics***

[Support of Hierarchical 1801 for Import Flow](#)

## **removeHierSupForOutPorts**

```
lp removeHierSupForOutPorts boolean { t | nil }
```

### **Description**

Removes hierarchical supplies for inout and out ports when set to `t`. The default value of the flag is `nil`.

### **GUI Equivalent**

None

### **Examples**

```
envGetVal("lp" "removeHierSupForOutPorts")  
envSetVal("lp" "removeHierSupForOutPorts" 'boolean t)
```

### ***Related Topics***

[Support of Hierarchical 1801 for Import Flow](#)

## removeInternalNetFromPgFn

```
lp removeInternalNetFromPgFn boolean { t | nil }
```

### Description

Removes internal supply or internal ground nets from `pg_function`. The default value of the flag is `t`. This behavior is not applied for the internal supply or internal ground nets that are related power or related ground of a signal pin. These internal supply or ground nets are still included in `pg_function`.

When set to `nil`,

```
pg_pin(VDD_INT2) {  
    voltage_name      : "VDD_INT2";  
    pg_type           : internal_power;  
    direction         : "internal";  
    pg_function       : "vdd_int";  
}
```

When set to `t`,

```
pg_pin(VDD_INT2) {  
    voltage_name      : "VDD_INT2";  
    pg_type           : internal_power;  
    direction         : "internal";  
}
```

### GUI Equivalent

None

### Examples

```
envGetVal("lp" "removeInternalNetFromPgFn")  
envSetVal("lp" "removeInternalNetFromPgFn" 'boolean nil)
```

### ***Related Topics***

[Excluding Power and Ground Nets from Name-Based Registration](#)

# Virtuoso Power Manager User Guide

## Virtuoso Power Manager Environment Variables

---

## **removePST**

```
lp removePST boolean { t | nil }
```

### **Description**

Controls whether the PST or power state format of commands are printed in or removed from the exported 1801 file. The default value is `nil`, which means that the commands are printed in the file.

### **GUI Equivalent**

None

### **Example**

```
envGetVal("lp" "removePST")  
envSetVal("lp" "removePST" 'boolean t)
```

### ***Related Topics***

[Exporting 1801 Design Model](#)

[Exporting 1801 Power Model](#)

## runIDCInBackground

```
lp runIDCInBackground boolean { t | nil }
```

### Description

Controls whether the in-design checks are run in the foreground or background. When set to `t`, the Run In-Design Checks non-blocking form is enabled in the GUI. A single In-Design Checks run is supported in a Virtuoso session at a time in non-blocking mode. The default value is `nil`, which means that the in-design checks are run in the foreground.

### GUI Equivalent

None

### Example

```
envGetVal( "lp" "runIDCInBackground")  
envSetVal( "lp" "runIDCInBackground" 'boolean t)
```

### ***Related Topics***

[Checking a Design in Foreground Mode](#)

[Checking a Design in Background Mode](#)

## separatorForBit

```
lp separatorForBit string "<>"
```

### Description

Specifies separators for pin names of the bus bits. The default value is "<>".

```
voltage_map( vdd_Int[0] , 0.800000);  
    voltage_map( vdd_Int[1] , 0.800000);  
    voltage_map( vdd_Int[2] , 0.800000);
```

```
pg_pin(vdd_Int[1]) {  
voltage_name      : "vdd_Int[1]";  
pg_type           : internal_power;  
direction         : "internal";  
switch_function   : "Enable[1]";  
pg_function       : "vdd";  
}
```

```
pin(in1) {  
direction         : "inout";  
related_power_pin : "vdd_Int[1]";  
related_ground_pin : "I0[int]gnd_int[1]";  
}
```

### GUI Equivalent

None

### Example

```
envGetVal("lp" "separatorForBit")  
envSetVal("lp" "separatorForBit" 'string "[ ]")
```

### ***Related Topics***

[Registering Name-Based Supply Nets](#)

## **signalPortsForIsoEnableConditionDerivation**

```
lp signalPortsForIsoEnableConditionDerivation string "data_port_names"
```

### **Description**

Registers the names of data ports in a setup file that need the `isolation_enable_condition` derivation. The default value is "", which means no derivation is printed in the CIW.

### **GUI Equivalent**

None

### **Example**

```
envGetVal("lp" "signalPortsForIsoEnableConditionDerivation")
envSetVal("lp" "signalPortsForIsoEnableConditionDerivation" 'string "OUT OUT2
IN1")
```

### ***Related Topics***

[Export of Switch Function and Isolation Enable Condition Expressions](#)

[virtualSuppliesForSwitchFunctionDerivation](#)

[exportSwitchFunctionDerivationForAllUsedVirtualSupplies](#)

[exportIsoEnableConditionDerivationForAllTopIsolatedPorts](#)

## singleRailAttrPropagation

```
lp singleRailAttrPropagation boolean { t | nil }
```

### Description

Propagates attributes, such as `input_signal_level` and `input_voltage_range`, from the input pin of a single rail standard cell instance to the top-level design port that is connected to the input pin of a single rail level shifter cell instance. The default value is `nil`, which means that the attributes are not propagated.

### GUI Equivalent

None

### Example

```
envGetVal("lp" "singleRailAttrPropagation")  
envSetVal("lp" "singleRailAttrPropagation" 'boolean t)
```

### ***Related Topics***

[Single Rail Cells](#)

## **specialCellInfoFile**

```
lp specialCellInfoFile string ""
```

### **Description**

Provides a mechanism to parse the 1801 special cell definition file to the 1801 extractor externally, which is outside the Power Manager setup. The 1801 extractor reads the 1801 special cell definition file accordingly and reads the modeling information from the same.

### **GUI Equivalent**

None

### **Example**

```
envGetVal("lp" "specialCellInfoFile")  
envSetVal("lp" "specialCellInfoFile" 'string "./spcells.upf")
```

### ***Related Topics***

[Exporting 1801 Design Model](#)

[Exporting 1801 Power Model](#)

## stopViewList

```
lp stopViewList string "symbol symbol_xform auCdl auLvs hspiceD spectre"
```

### Description

Specifies a space-separated list of cellview names that is used while elaborating the design under test to identify the view at which the traversal has to be stopped. While traversing a design hierarchy, the tool stops moving further when it finds any one of the cellviews given in this list. Power Manager uses the stop view list for design traversal during the power intent extraction phase and also to create the required design objects during the 1801 import flow.

The default value is "symbol symbol\_xform auCdl auLvs hspiceD spectre".

### GUI Equivalent

None

### Example

```
envGetVal("lp" "stopViewList")  
envSetVal("lp" "stopViewList" 'string "symbol symbol_xform aucdl")
```

### *Related Topics*

[Importing Power Intent](#)

## **switchPinForNoPortAtSwitchablePower**

```
lp switchPinForNoPortAtSwitchablePower boolean { t | nil }
```

### **Description**

Prints the `switchPin` attribute for enable pin even if there is no port for power switch output, when set to `t`, which is the default value.

### **GUI Equivalent**

None

### **Examples**

If value is `nil`:

```
pin(Enable) {  
direction          : input;  
related_power_pin  : vdd;  
related_ground_pin : I0__net7;  
}
```

If value is `t`:

```
pin(Enable) {  
direction          : input;  
switch_pin         : true;  
related_power_pin  : vdd;  
related_ground_pin : I0__net7;  
}
```

### ***Related Topics***

[Handling of Low Power Special Cells](#)

## switchViewList

```
lp switchViewList string "viewnames"
```

### Description

Specifies a space-separated list of cellview names that is used while reviewing the design under test to control the order in which the design hierarchy is traversed. Power Manager uses the switch view list for design traversal during the power intent extraction phase and also to create the required design objects during the 1801 import flow.

The default value is " ".

### GUI Equivalent

None

### Example

```
envGetVal("lp" "switchViewList")  
envSetVal("lp" "switchViewList" 'string "cmos_sch cmos.sch schematic symbol")
```

### ***Related Topics***

[Importing Power Intent](#)

[Extracting the Power Intent from a Design](#)

## **updateRelatedSuppliesForNorNandIsoPorts**

```
lp updateRelatedSuppliesForNorNandIsoPorts boolean { t | nil }
```

### **Description**

Updates the related supplies for the ports connected to NAND and NOR isolation cells. The default is `nil`, which means that related supplies are not updated.

### **GUI Equivalent**

None

### **Example**

```
envGetVal("lp" "updateRelatedSuppliesForNorNandIsoPorts")  
envSetVal("lp" "updateRelatedSuppliesForNorNandIsoPorts" 'boolean t)
```

### ***Related Topics***

[Special Isolation Cells in Liberty Power Model Export](#)

## **updateShortAttribute**

```
lp updateShortAttribute boolean { t | nil }
```

### **Description**

Controls printing the short attribute for supply and logic ports. The default is `t`, which means the short attribute will not be printed.

### **GUI Equivalent**

None

### **Example**

```
envGetVal ("lp" "updateShortAttribute")  
envSetVal ("lp" "updateShortAttribute" 'boolean nil)
```

### ***Related Topics***

[Resistors as Short Devices](#)

## **updateUnconnPortsforAD**

```
lp updateUnconnPortsforAD boolean { t | nil }
```

### **Description**

Controls printing the `is_connected` attribute for noconn, ignore cell, diode instance, and esd ports. The default is `nil`, which means the `is_connected` attribute will not be printed.

### **GUI Equivalent**

None

### **Example**

```
envGetVal("lp" "updateUnconnPortsforAD")  
envSetVal("lp" "updateUnconnPortsforAD" 'boolean t)
```

### ***Related Topics***

[Connectors](#)

## **useANDForMultipleSupplies**

```
lp useANDForMultipleSupplies boolean { t | nil }
```

### **Description**

Prints the multiple supplies in the output Liberty file as `ExtVDD&VDD`, when set to `t`. When the `cdsenv` is set to `nil`, multiple supplies are printed as `ExtVDD+VDD`.

### **GUI Equivalent**

None

### **Example**

```
envGetVal("lp" "useANDForMultipleSupplies")  
envSetVal("lp" "useANDForMultipleSupplies" 'boolean nil)
```

### ***Related Topics***

[Exporting Liberty Power Model](#)

## **useNandNorBaseIsolationTypes**

```
lp useNandNorBaseIsolationTypes boolean { t | nil }
```

### **Description**

Generates a NAND or NOR function when creating a functional expression for the output pin of an isolation or level shifter cell. The default value is `nil`, which means that the variable generates an AND or OR function.

### **GUI Equivalent**

None

### **Example**

```
envGetVal("lp" "useNandNorBaseIsolationTypes")  
envSetVal("lp" "useNandNorBaseIsolationTypes" 'boolean t)
```

### ***Related Topics***

[Special Cell and Standard Cell Modeling](#)

## vbHierScopeLevel

```
lp vbHierScopeLevel cyclic {"Current Cellview Only" | "Current Cellview To Depth"  
| "Top Cellview To Depth"}
```

### Description

Specifies the level in a design until which the in-design checks are to be run. The available options are:

- Top Cellview To Depth (default): Checks only the top cellview hierarchy.
- Current Cellview To Depth: Checks only the current cellview hierarchy.
- Current Cellview Only: Checks the current cellview without descending.

### GUI Equivalent

None

### Examples

```
envGetVal("lp" "vbHierScopeLevel")  
envSetVal("lp" "vbHierScopeLevel" 'cyclic "Current Cellview Only")
```

### ***Related Topics***

[Checking a Design in Foreground Mode](#)

[Run In-Design Checks](#)

## **vbMaxHierDepth**

```
lp vbMaxHierDepth int leveldepth
```

### **Description**

Sets the depth of level in numbers until which the in-design checks are to be run. The default value is 32 and it can be changed to any value between 0 and 32.

### **GUI Equivalent**

None

### **Examples**

```
envGetVal("lp" "vbMaxHierDepth")  
envSetVal("lp" "vbMaxHierDepth" 'int 10)
```

### ***Related Topics***

[Checking a Design in Foreground Mode](#)

[Run In-Design Checks](#)

## **virtualSuppliesForSwitchFunctionDerivation**

```
lp virtualSuppliesForSwitchFunctionDerivation string "virtual_supply_net_names"
```

### **Description**

Registers the names of virtual supply nets that need the `switch_function` derivation. The default value is " ", which means no derivation is printed in the CIW.

### **GUI Equivalent**

None

### **Example**

```
envGetVal("lp" "virtualSuppliesForSwitchFunctionDerivation")
envSetVal("lp" "virtualSuppliesForSwitchFunctionDerivation" 'string "VVDD VVDD_CPU
VVDD_LDO")
```

### ***Related Topics***

[Export of Switch Function and Isolation Enable Condition Expressions](#)

[signalPortsForIsoEnableConditionDerivation](#)

[exportSwitchFunctionDerivationForAllUsedVirtualSupplies](#)

[exportIsoEnableConditionDerivationForAllTopIsolatedPorts](#)

# Virtuoso Power Manager User Guide

## Virtuoso Power Manager Environment Variables

---

### writeMixedFormatPST

```
lp writeMixedFormatPST boolean { t | nil }
```

#### Description

Enables the use of syntax or semantics for writing mixed power states in the exported 1801 power model file. This allows the printing of a mix of Unified Power Format 2.0 and Unified Power Format 1.5 for specifying the power states in the extracted 1801 power model. The default value is `nil`. If the environment variable is set to `nil`, the power states are written using the `add_power_state` command only. The multiple supplies are printed as `ExtVDD+VDD`. When set to `t`, power states are written by using the following commands:

- `add_power_state`
- `create_pst`
- `add_pst_state`

#### When set to `t`

```
##### Power States #####
add_power_state ss_vddA_vssA -supply -state { on_lp0 -supply_expr { (power == {
FULL_ON 1.000000 }) && (ground == { OFF })}}
add_power_state ss_vddA_vssB -supply -state { on_lp0 -supply_expr { (power == {
FULL_ON 1.000000 }) && (ground == { OFF })}}
add_power_state ss_vddB_vssB -supply -state { on_lp5 -supply_expr { (power == {
FULL_ON 1.500000 }) && (ground == { OFF })}}
add_power_state ss_vddB_init_vssB -supply -state { on_lp5 -supply_expr { (power
== { FULL_ON 1.500000 }) && (ground == { OFF })}} -state { off_0p0 \
-supply_expr { (power == { OFF }) && (ground == { OFF })}}
add_power_state pd_vddA_vssA -domain -state { mode0 -logic_expr {ss_vddB_vssB
== on_lp5 && ss_vddA_vssB == on_lp0 && ss_vddA_vssA == on_lp0 && \
ss_vddB_init_vssB == on_lp5 }} -state { mode1 -logic_expr { ss_vddB_vssB ==
on_lp5 && ss_vddA_vssB == on_lp0 && ss_vddA_vssA == on_lp0 && \
ss_vddB_init_vssB == off_0p0}}
```

#### When set to `nil`

```
##### Power States #####
add_power_state ss_vddA_vssA -state { on_lp0 -supply_expr { power == { FULL_ON
1.000000 }}} -state { on_0p0 -supply_expr { ground == { FULL_ON 0.000000 }}}
add_power_state ss_vddA_vssB -state { on_lp0 -supply_expr { power == { FULL_ON
1.000000 }}} -state { on_0p0 -supply_expr { ground == { FULL_ON 0.000000 }}}
add_power_state ss_vddB_vssB -state { on_lp5 -supply_expr { power == { FULL_ON
```

# Virtuoso Power Manager User Guide

## Virtuoso Power Manager Environment Variables

---

```
1.500000 }}} -state { on_0p0 -supply_expr { ground == { FULL_ON 0.000000 }}}
add_power_state ss_vddB_init_vssB -state { on_1p5 -supply_expr { power == {
FULL_ON 1.500000 }}} -state { on_0p0 -supply_expr { ground == { FULL_ON 0.000000
}}} \
-state { off_0p0 -supply_expr { power == { OFF }}}
##### PST #####
create_pst cellA -supplies { ss_vddB_vssB.power ss_vddB_vssB.ground
ss_vddA_vssB.power ss_vddA_vssA.ground ss_vddB_init_vssB.power}
add_pst_state mode0 -pst cellA -state {on_1p5 on_0p0 on_1p0 on_0p0 on_1p5 }
add_pst_state model -pst cellA -state {on_1p5 on_0p0 on_1p0 on_0p0 off_0p0 }
```

### GUI Equivalent

None

### Examples

```
envGetVal("lp" "writeMixedFormatPST")
envSetVal("lp" "writeMixedFormatPST" 'boolean t)
```

### *Related Topics*

[Exporting 1801 Power Model](#)

---

# Virtuoso Power Manager SKILL Functions

---

This topic describes the public SKILL functions in Power Manager.

- [vpmDefinePowerSwitchInstance](#)
- [vpmExportDotLib](#)
- [vpmExportPowerIntent](#)
- [vpmExportPowerModel](#)
- [vpmExportPowerIntentSetup](#)
- [vpmExtractPowerIntent](#)
- [vpmGenerateSigInfo](#)
- [vpmImportPowerIntent](#)
- [vpmImportPowerIntentSetup](#)
- [vpmLoadInDesignViolations](#)
- [vpmRemoveImportedPowerIntent](#)
- [vpmRemovePowerSwitchInstance](#)
- [vpmRunInDesignChecks](#)
- [vpmSetViolationBrowserOptions](#)

## **vpmDefinePowerSwitchInstance**

```
vpmDefinePowerSwitchInstance (  
    t_cellName  
    t_instName  
    g_type  
    g_stage1Enable  
    [ ?stage2Enable g_stage2Enable ]  
    [ ?stage1Output g_stage1Output ]  
    [ ?stage2Output g_stage2Output ]  
    [ ?power g_power ]  
    [ ?powerSwitchable g_powerSwitchable ]  
    [ ?ground g_ground ]  
    [ ?groundSwitchable g_groundSwitchable ]  
)  
=> t / nil
```

### **Description**

Registers transistor instances as power or ground switches.

# Virtuoso Power Manager User Guide

## Virtuoso Power Manager SKILL Functions

---

### Arguments

<i>t_cellName</i>	The name of the parent cell name of power switch instance.
<i>t_instName</i>	The name of the power switch instance.
<i>g_type</i>	Specifies <code>header</code> for power switch or <code>footer</code> for ground switch.
<i>g_stage1Enable</i>	The stage 1 enable expression for power switch instance.
<i>?stage2Enable g_stage2Enable</i>	The stage 2 enable expression for power switch instance.
<i>?stage1Output g_stage1Output</i>	The stage 1 output expression for power switch instance.
<i>?stage2Output g_stage2Output</i>	The stage 2 output expression for power switch instance.
<i>g_power</i>	The power pin of power switch instance.
<i>?powerSwitchable g_powerSwitchable</i>	The switchable pin of power switch instance.
<i>g_ground</i>	The ground pin of ground switch instance.
<i>?groundSwitchable g_groundSwitchable</i>	The switchable pin of ground switch instance.

### Value Returned

<code>t</code>	The instances are registered successfully.
<code>nil</code>	The instances could not be registered.

### Example

```
vpmDefinePowerSwitchInstance("analog_blk" "M0" type "header" ?power "S"  
?powerSwitchable "D" stage1Enable "!G")
```

- M0 is power switch instance in the `analog_blk` cell.

***Related Topic***

Handling of Low Power Special Cells

## vpmExportDotLib

```
vpmExportDotLib(  
    x_session_id  
    t_file_dot_lib  
)  
=> t / nil
```

### Description

Exports the extracted power intent in the `.lib` file format.

### Arguments

<code>x_session_id</code>	The ID of the window for which you want to export the power intent.
<code>t_file_dot_lib</code>	The name of the file for exporting the power intent.

### Value Returned

<code>t</code>	The file is exported successfully.
<code>nil</code>	The file could not be exported.

### Example

```
vpmImportPowerIntentSetup( "test_pg" "pass_gate_SC" "schematic" "lpSetup.il")  
session = (vpmExtractPowerIntent "test_pg" "pass_gate_SC" "schematic")  
vpmExportDotLib (session "libModel.lib")
```

Exports the power intent as the Liberty Power Model `libModel.lib` file.

### ***Related Topic***

[Exporting Liberty Power Model](#)

## **vpmExportPowerIntent**

```
vpmExportPowerIntent(  
    x_session_id  
    t_file_1801  
)  
=> t / nil
```

### **Description**

Exports the 1801 Design Model for a design. Ensure that the design has been extracted by using [vpmExtractPowerIntent](#) or the GUI options in Virtuoso Schematic Editor. This function requires a session ID, which is generated upon successful power intent extraction for the design.

### **Arguments**

<code>x_session_id</code>	The ID of the window for which you want to export the power intent.
<code>t_file_1801</code>	The name of the file for exporting the power intent.

### **Value Returned**

<code>t</code>	Returns <code>t</code> if the power intent is successfully exported.
<code>nil</code>	Returns <code>nil</code> otherwise.

### **Example**

```
vpmImportPowerIntentSetup("test_pg" "pass_gate_SC" "schematic" "lpSetup.il")  
session = (vpmExtractPowerIntent "test_pg" "pass_gate_SC" "schematic")  
vpmExportPowerIntent (session "designmodel.upf")
```

### ***Related Topic***

[Exporting 1801 Design Model](#)

## vpmExportPowerModel

```
vpmExportPowerModel(  
    x_sessionID  
    t_output_file_name  
)  
=> t
```

### Description

Exports the 1801 power model for a design. Ensure that the design has been extracted by using `vpmExtractPowerIntent`, or using the GUI options in Virtuoso Schematic Editor. This function requires a session ID, which is generated upon successful power intent extraction for the design.

### Arguments

<code>x_sessionID</code>	The return value of <code>vpmExtractPowerIntent</code> .
<code>t_output_file_name</code>	The name of the file for exporting the 1801 power model.

### Value Returned

<code>t</code>	Returns <code>t</code> if the 1801 power intent model is successfully exported to the file. Displays an error message.
----------------	---

### Example

```
vpmImportPowerIntentSetup("test_pg" "pass_gate_SC" "schematic" "lpSetup.il")  
session = (vpmExtractPowerIntent "test_pg" "pass_gate_SC" "schematic")  
vpmExportPowerModel (session "designmodel.upf")
```

### ***Related Topic***

[Exporting 1801 Power Model](#)

## vpmExportPowerIntentSetup

```
vpmExportPowerIntentSetup(  
    t_setup_file_name  
    [ ?overwriteExisting g_overwriteExisting ]  
    [ ?filter g_filter ]  
    [ ?lpDBLibName g_lpDBLibName ]  
    [ ?lpDBCellName g_lpDBCellName ]  
    [ ?lpDBViewName g_lpDBViewName ]  
)  
=> t / nil
```

### Description

Exports the loaded setup to a specified file. This file can be verified for the setup options that the Power Manager has used during import/export of power intent.

### Arguments

<i>t_setup_file_name</i>	Name of the file to which the loaded setup is exported.
<i>?overwriteExisting g_overwriteExisting</i>	Specifies if the exported file can overwrite an existing file with the same name, if any.
<i>?filter g_filter</i>	Specifies which setup options out of <code>environmentSetupOptions</code> , <code>userSetupOptions</code> , or <code>allSetupOptions</code> are to be exported to the filename specified in <code>t_output_file_name</code> .
<i>?lpDBLibName g_lpDBLibName</i>	Name of the library in which the power view is generated.
<i>?lpDBCellName g_lpDBCellName</i>	Name of the cell in which the power view is generated.
<i>?lpDBViewName g_lpDBViewName</i>	Name of the power view generated.

## Virtuoso Power Manager User Guide

### Virtuoso Power Manager SKILL Functions

---

#### Value Returned

<code>t</code>	Returns <code>t</code> if the loaded power intent setup is successfully exported to the file specified.
<code>nil</code>	Returns <code>nil</code> otherwise.

#### Example

```
vpmExportPowerIntentSetup( "test_pg" "pass_gate_SC" "schematic" "lpSetup.il"  
?overwriteExisting t ?filter "allSetupOptions")
```

#### ***Related Topic***

[Setup for Automatic Extraction of Power Intent](#)

## **vpmExtractPowerIntent**

```
vpmExtractPowerIntent (  
    t_lib  
    t_cellName  
    t_viewName  
)  
=> session_id / nil
```

### **Description**

Extracts the power intent from the given design. It also identifies sub-hierarchical blocks in the top-level design, which need macro model extraction or are associated with a 1801 file.

### **Argument**

<i>t_lib</i>	Name of the library of the cellview to be extracted.
<i>t_cellName</i>	Name of the cell of the cellview to be extracted.
<i>t_viewName</i>	View name from which power intent is to be extracted.

### **Value Returned**

<i>session_id</i>	Returns the session id if the power intent model is successfully extracted.
<i>nil</i>	Returns <i>nil</i> otherwise.

### **Example**

```
vpmExtractPowerIntent ("test_pg" "pass_gate_SC" "schematic")
```

### ***Related Topic***

[Extracting the Power Intent from a Design](#)

## **vpmGenerateSigInfo**

```
vpmGenerateSigInfo(  
    t_libName  
    t_cellName  
    t_viewName  
    t_sigInfoFilePath  
)  
=> session_id / nil
```

### **Description**

Adds the signal type and voltage values for all the canonical nets in the design. If a design net spans across multiple levels in the hierarchy, the net at the highest level of the hierarchy is considered as canonical.

# Virtuoso Power Manager User Guide

## Virtuoso Power Manager SKILL Functions

---

### Argument

<i>t_libName</i>	Name of the design cellview.
<i>t_cellName</i>	
<i>t_viewName</i>	
<i>t_sigInfoFilePath</i>	Path of the text file that is created by the SKILL function that contains the details of the canonical design nets. For each canonical net listed in the file, its details include the signal type and net voltages. If no file path is specified, the function creates the file by the name of <i>t_libName_t_cellName.siginfo.txt</i> in the current working directory.

### Value Returned

<i>t</i>	Returns <i>t</i> if it is able to successfully generate the information for canonical nets.
<i>nil</i>	Returns <i>nil</i> in one of these situations: <ul style="list-style-type: none"><li>■ The <i>t_libName</i>, <i>t_cellName</i>, <i>t_viewName</i> are not strings or are empty strings.</li><li>■ The <i>t_libName</i>, <i>t_cellName</i>, <i>t_viewName</i> do not point to a valid and readable Open Access cellview.</li><li>■ One of the <i>t_libName</i>, <i>t_cellName</i>, or <i>t_viewName</i> argument is <i>nil</i>.</li><li>■ The <i>t_sigInfoFilePath</i> references to a directory location that is not writable.</li><li>■ Appropriate licenses required by the function are not available.</li><li>■ Power Manager Setup is not loaded for the specified design.</li></ul>

### Example

This example showcases how a signal information file is generated.

```
when (ret
    ;; If setup is loaded successfully, try to generate sigInfo
```

## Virtuoso Power Manager User Guide

### Virtuoso Power Manager SKILL Functions

---

```
ret = vpmGenerateSigInfo( "testlib" "adcTop" "schematic" )
when(ret
    ;; If the API run was successful it should have created a file by the name
of testlib_adcTop.siginfo.txt;
    ;; Open it in a view window to view the results
    view( "./testlib_adcTop.siginfo.txt")
)
)
```

#### ***Related Topic***

[Generating Signal Information](#)

## **vpmlImportPowerIntent**

```
vpmlImportPowerIntent (
    t_libname
    t_cellname
    t_viewname
    t_viewlist
    t_file1801Path
    [ ?resolveTopNets g_resolveTopNets ]
)
=> t / nil
```

### **Description**

Imports the power intent for any cellview. It also creates the netSet properties and resolves tie connections in the design hierarchy and creates supply pins corresponding to the power domain nets and global nets.

**Note:** This function requires a Virtuoso Schematic Editor XL license, which is released when the import is complete.

## Arguments

<code>t_libname</code>	Name of the library of the cellview to be imported or exported for power intent.
<code>t_cellname</code>	Name of the cell to be imported or exported for power intent.
<code>t_viewname</code>	Name of the view to be imported or exported for power intent.
<code>t_viewlist</code>	Switch view list specifying the order of traversal of hierarchical schematic to create the required OA objects.
<code>t_file1801Path</code>	Name or path of the 1801 file to be imported.
<code>?resolveTopNets</code> <code>g_resolveTopNets</code>	<p>Controls the generation of supply nets and supply ports in a design.</p> <p>When set to <code>t</code>,</p> <ul style="list-style-type: none"><li>■ Ports are created at the top level and their corresponding nets are non-inherited.</li><li>■ Ports are created at the scope level and their corresponding nets are inherited.</li></ul> <p>When set to <code>nil</code> (default),</p> <ul style="list-style-type: none"><li>■ Ports created at the top level and their corresponding nets are inherited.</li><li>■ Ports created at the scope level and their corresponding nets are inherited.</li></ul> <p>Local nets created using <code>create_supply_net</code> without ports are non-inherited at both the scope level and top level.</p>

## Value Returned

<code>t</code>	The power intent setup is successfully imported.
<code>nil</code>	The power intent setup could not be imported.

## Example

```
vpmImportPowerIntent( "test_pg" "pass_gate_SC" "schematic" "schematic symbol"  
"import.upf" ?resolveTopNets t)
```

## Virtuoso Power Manager User Guide

### Virtuoso Power Manager SKILL Functions

---

#### ***Related Topics***

[Power Intent Import](#)

## **vpImportPowerIntentSetup**

```
vpImportPowerIntentSetup (  
    t_libname  
    t_cellname  
    t_viewname  
    t_setup_file_name  
    [ ?lpDBLibName g_lpDBLibName ]  
    [ ?lpDBCellName g_lpDBCellName ]  
    [ ?lpDBViewName g_lpDBViewName ]  
    )  
=> t / nil
```

### **Description**

Imports a SKILL file that contains the user-defined setup. This has the attributes required to extract the desired information from the design cellview for importing or exporting the power intent.

# Virtuoso Power Manager User Guide

## Virtuoso Power Manager SKILL Functions

---

### Arguments

<i>t_libname</i>	Name of the library of the cellview to be imported or exported for power intent.
<i>t_cellname</i>	Name of the cell to be imported or exported for power intent.
<i>t_viewname</i>	Name of the view to be imported or exported for power intent.
<i>t_setup_file_name</i>	Name of the user-defined setup file.
<i>g_lpDBLibName</i>	Name of the library of the cellview in which the power view is generated.
<i>g_lpDBCellName</i>	Name of the cell in which the power view is generated.
<i>g_lpDBViewName</i>	Name of the power view in the cellview.

### Value Returned

<i>t</i>	Returns <i>t</i> if the power intent setup is successfully imported or loaded.
<i>nil</i>	Returns <i>nil</i> otherwise.

### Example

```
vpmImportPowerIntentSetup( "test_pg" "pass_gate_SC" "schematic" "lpSetup.il")
```

### ***Related Topics***

[Power Intent Import](#)

## **vpmLoadInDesignViolations**

```
vpmLoadInDesignViolations (  
    t_libname  
    t_cellname  
    t_viewname  
    t_vdbFilePath  
)  
=> t / nil
```

### **Description**

Loads the specified violation database file that contains the violation details for a previous check on a design. As the SKILL function processes each violation from the violations file, it creates markers on relevant design objects.

### **Arguments**

<i>t_libname</i>	Name of the library of the cellview to be imported or exported for power intent.
<i>t_cellname</i>	Name of the cell to be imported or exported for power intent.
<i>t_viewname</i>	Name of the view to be imported or exported for power intent.
<i>t_vdbFilePath</i>	Name or path of the 1801 file to be imported.

## Value Returned

<code>t</code>	Returns <code>t</code> if the violations are loaded successfully.
<code>nil</code>	Returns <code>nil</code> in one of these situations: <ul style="list-style-type: none"><li>■ <code>t_libName</code>, <code>t_cellName</code>, <code>t_viewName</code> are not strings, or are empty strings.</li><li>■ <code>t_libName</code>, <code>t_cellName</code>, <code>t_viewName</code> do not point to a valid and readable Open Access cellview.</li><li>■ One of the <code>t_libName</code>, <code>t_cellName</code>, <code>t_viewName</code>, argument is <code>nil</code>, the user gets a SKILL error.</li><li>■ The <code>t_libName</code>, <code>t_cellName</code>, and <code>t_viewName</code> do not match the library, cell, and view name of the design for which the violation file was generated.</li><li>■ The <code>t_vdbFilePath</code> references are non-existent or non-readable file.</li><li>■ Appropriate licenses required by the SKILL function are not available.</li></ul>

## Example

```
ret = vpmLoadInDesignViolations( "testlib" "adcTop" "schematic" "./  
testlib.adcTop.vdb")
```

## ***Related Topics***

[Loading the Violations Database](#)

## **vpmRemoveImportedPowerIntent**

```
vpmRemoveImportedPowerIntent (  
    t_libName  
    t_cellName  
    t_viewName  
)  
=> t_viewlist/ nil
```

### **Description**

Removes the entire power intent information that was imported for a cellview. This function also removes the netSet properties, tie connections, supply pins, and so on.

This function is used only when the Schematic XL license is checked out. Therefore, it first verifies whether the license is already checked out and if it is not, it tries to check out the license. The function also releases the license before exiting.

The view list specified by *t\_viewlist* is used for processing the removal of imported objects for the view type instantiated in the top cellview.

## Virtuoso Power Manager User Guide

### Virtuoso Power Manager SKILL Functions

---

#### Argument

<i>t_libname</i>	Name of the library of the cellview for which the power intent will be removed
<i>t_cellname</i>	Name of the cell of the cellview for which the power intent will be removed
<i>t_viewname</i>	Name of the view of the cellview for which the power intent will be removed
<i>t_viewlist</i>	List of the view names to be processed for removing the power intent information.

#### Value Returned

<i>t_viewlist</i>	Returns the list of the view names to be processed for removing the power intent information.
<i>nil</i>	Returns <i>nil</i> otherwise.

#### Examples

```
vpmRemoveImportedPowerIntent( "test_pg" "pass_gate_SC" "schematic" "schematic"  
"symbol")
```

#### ***Related Topic***

[Removing Imported Power Intent](#)

## **vpmRemovePowerSwitchInstance**

```
vpmRemovePowerSwitchInstance (  
    t_cellName  
    t_instName  
)  
=> t / nil
```

### **Description**

Removes registered transistor instances as power or ground switches.

### **Arguments**

<i>t_cellName</i>	The name of the parent cell name of power switch instance.
<i>t_instName</i>	The name of the power switch instance.

### **Value Returned**

t	The instances are removed successfully.
nil	The instances could not be removed.

### **Example**

```
vpmRemovePowerSwitchInstance ("analog_blk" "M0" )
```

M0 is an instance in the `analog_blk` cell, which had been registered as a power switch using SKILL API `vpmDefinePowerSwitchInstance`. This instance will not be treated as a power switch any more.

### ***Related Topic***

[Handling of Low Power Special Cells](#)

## vpmRunInDesignChecks

```
vpmRunInDesignChecks (  
    t_libName  
    t_cellName  
    t_viewName  
    [ ?instPath t_instPath ]  
    [ ?logFilePath t_lprcFilePath ]  
    [ ?vdbFilePath t_vdbFilePath ]  
)  
=> t / nil
```

### Description

Runs the In-Design Checks on a design specified by library, cell, and view.

### Arguments

<i>t_libname</i>	Name of the design cellview.
<i>t_cellname</i>	
<i>t_viewname</i>	
<i>t_instPath</i>	Specifies the path of a hierarchical instance within the design specified by <i>t_libname</i> , <i>t_cellname</i> , and <i>t_viewname</i> on which the checks would be run. If it is not provided, the checks are run on the complete design.
<i>t_logFilePath</i>	Path of the In-Design Checks log file that reports the summary and details of violations. If no value is specified, the function creates the file by the name of <i>t_libName_t_cellName.inDesign.log</i> in the current working directory.
<i>g_vdbFilePath</i>	Name of the violation database (.vdb). It contains the violation details for the current run. If none is specified, the function creates the file by the name of <i>t_libName_t_cellName.vdb</i> in the current working directory.

## Value Returned

<code>t</code>	The Power Manager has been run successfully.
<code>nil</code>	One or more of the following error conditions applies: <ul style="list-style-type: none"><li>■ The <code>t_libName</code>, <code>t_cellName</code> and <code>t_viewName</code> are not strings or are empty strings.</li><li>■ The <code>t_libName</code>, <code>t_cellName</code>, <code>t_viewName</code> do not point to a valid and readable OpenAccess cellview.</li><li>■ One of the <code>t_libName</code>, <code>t_cellName</code>, or <code>t_viewName</code> argument is <code>nil</code>.</li><li>■ If <code>t_lprcFilePath</code> references a directory location that is not writable.</li><li>■ If <code>t_vdbFilePath</code> references to a directory location that is not writable.</li><li>■ Appropriate licenses required by the function are not available.</li><li>■ The setup information is not loaded for the specified design.</li></ul>

## Example

```
when (ret
ret = vpmRunInDesignChecks( "testlib" "adcTop" "schematic" )
  when (ret
view( "./testlib_adcTop.inDesign.log" )
  )
)
```

## Related Topic

[Checking a Design in Foreground Mode](#)

## vpmSetViolationBrowserOptions

```
vpmSetViolationBrowserOptions (  
    w_window  
    t_openMode  
    t_openLocation  
    x_hierarchyDepth  
    [ ?hierarchicalScope b_hierarchicalScope ]  
=> t / nil
```

### Description

Sets the Annotation Browser options for viewing the design violations.

### Arguments

<i>w_window</i>	A valid GE window where the Power Manager application is running. When a valid window ID is specified, the function sets the specified options only for the specific Annotation Browser assistant occurrence.
<i>t_openMode</i>	The mode in which the marker cellview is opened when you choose to navigate the marker using the <i>Open</i> option in the Annotation Browser. The valid values are <i>edit</i> and <i>read</i> .
<i>t_openLocation</i>	The location where the marker cellview is opened when you choose to navigate the marker using the <i>Open</i> option in the Annotation Browser. The valid values are <i>current tab</i> , <i>new tab</i> , or <i>new window</i> .
<i>x_hierarchyDepth</i>	The valid values can be an integer between 0 and 32.
<i>b_hierarchicalScope</i>	The valid values are <i>t</i> and <i>nil</i> . It is an optional argument.  If set to <i>t</i> , it sets the Annotation Browser scope value to <i>Current Cellview To Depth</i> and the In-Design Checks markers in the current cellview hierarchy are displayed.  When set to <i>nil</i> , then it sets the Annotation Browser scope value to <i>Current Cellview Only</i> and only the In-Design Checks markers in the current cellview are displayed.

## Virtuoso Power Manager User Guide

### Virtuoso Power Manager SKILL Functions

---

#### Value Returned

<code>t</code>	Returns <code>t</code> if the Annotation Browser options have been set successfully.
<code>nil</code>	Returns <code>nil</code> if the Annotation Browser options could not be set successfully.

#### Example

```
when(window = hiGetCurrentWindow()  
  when(vpmSetViolationBrowserOptions(window ?hierarchicalScope t hierarchyDepth  
32)  
    println("Successfully set browser options")  
  )  
)
```

#### ***Related Topic***

[Loading the Violations Database](#)

# Virtuoso Power Manager User Guide

## Virtuoso Power Manager SKILL Functions

---

---

## 1801 Support in Power Manager

---

This topic provides the list of commands supported in Virtuoso Power Manager.

- [General 1801 Command Support](#)
- [1801 Special Cell Definition Command Support](#)
- [Liberty Attributes Support](#)

## General 1801 Command Support

In the IC6.1.8 and ICADVM20.1 releases, Power Manager supports 1801 commands as explained below:

- All 1801 commands are imported from the given 1801 file. The schematic connectivity in the 1801 Import flow happens according to the commands supported by the Power Manager.
- All supported commands and arguments are read from the tool and exported to a 1801 file.

The following table lists all the general 1801 commands and explains how they are supported in the 1801 import and export processes of Power Manager. All supported commands are indicated with an S and the unsupported commands with a U.

Command	Options	Valid in IEEE 1801 Version		Comments	Support for 1801 Import	Support for 1801 Export
		2.0	2.1			
create_power_domain		2.0	2.1		S	S
	-elements	2.0	2.1		S	S
	-include_scope	2.0	2.1	Deprecated in 2.1	S	S
	-supply	2.0	2.1		S	S
	-scope	2.0	2.1	Deprecated in 2.1	S	S
	-update	2.0	2.1		S	S
create_supply_port		2.0	2.1		S	S
	-direction	2.0	2.1		S	S
create_supply_net		2.0	2.1		S	S
	-resolve	2.0	2.1		S	S
connect_supply_net		2.0	2.1		S	S
	-ports	2.0	2.1		S	S
create_supply_set		2.0	2.1		S	S
	-function	2.0	2.1		S	S

## Virtuoso Power Manager User Guide

### 1801 Support in Power Manager

Command	Options	Valid in IEEE 1801 Version		Comments	Support for 1801 Import	Support for 1801 Export
		2.0	2.1			
	-update	2.0	2.1		S	S
associate_supply_set		2.0	2.1		S	S
	-handle	2.0	2.1		S	S
set_port_attributes		2.0	2.1		S	S
	-applies_to	2.0	2.1		S	S
	-ports	2.0	2.1		S	S
	-elements	2.0	2.1		S	S
	-attribute	2.0	2.1		S	S
	-driver_supply	2.0	2.1		S	S
	-receiver_supply	2.0	2.1		S	S
	-repeater_supply	2.0	2.1	Deprecated in 2.1	S	S
add_port_state		2.0	2.1		U	S
	-state	2.0	2.1	Not needed for 1801 Import	U	S
add_pst_state		2.0	2.1		U	S
	-pst	2.0	2.1	Not needed for 1801 Import	U	S
	-state	2.0	2.1	Not needed for 1801 Import	U	S
create_pst		2.0	2.1		U	S
	-supplies	2.0	2.1	Not needed for 1801 Import	U	S
create_power_switch		2.0	2.1		S	S
	-output_supply_port	2.0	2.1		S	S

## Virtuoso Power Manager User Guide

### 1801 Support in Power Manager

Command	Options	Valid in IEEE 1801 Version		Comments	Support for 1801 Import	Support for 1801 Export
		2.0	2.1			
	-input_supply_port	2.0	2.1		S	S
	-domain	2.0	2.1		S	S
	-control_port	2.0	2.1		S	S
	-on_state	2.0	2.1		S	S
	-off_state	2.0	2.1		S	S
	-supply_set	2.0	2.1		S	S
<b>define_signal_attributes</b>		<b>2.0</b>	<b>2.1</b>		<b>S</b>	<b>S</b>
	-model	2.0	2.1		S	S
	-signals	2.0	2.1		S	S
	-on_sense	2.0	2.1		S	S
	-off_sense	2.0	2.1		S	S
	-supplies	2.0	2.1		S	S
<b>set_level_shifter</b>		<b>2.0</b>	<b>2.1</b>		<b>S</b>	<b>S</b>
	-domain	2.0	2.1		S	S
	-elements	2.0	2.1		S	S
	-source	2.0	2.1		S	S
	-sink	2.0	2.1		S	S
	-applies_to	2.0	2.1		S	S
	-no_shift	2.0	2.1		S	S
	-location	2.0	2.1		S	S
	-update	2.0	2.1		S	S
	-input_supply_set	2.0	2.1		S	S
	-output_supply_set	2.0	2.1		S	S
	-internal_supply_set	2.0	2.1		S	S

## Virtuoso Power Manager User Guide

### 1801 Support in Power Manager

Command	Options	Valid in IEEE 1801 Version		Comments	Support for 1801 Import	Support for 1801 Export
		2.0	2.1			
set_isolation		2.0	2.1		S	S
	-domain	2.0	2.1		S	S
	-elements	2.0	2.1		U	S
	-source	2.0	2.1		U	S
	-sink	2.0	2.1		U	S
	-diff_supply_only	2.0	2.1		S	S
	-isolation_supply_net	2.0	2.1		S	S
	-update	2.0	2.1		S	S
	-applies_to	2.0	2.1		S	S
	-clamp_value	2.0	2.1		S	S
	-no_isolation	2.0	2.1		S	S
	-isolation_signal	2.0	2.1		S	S
	-isolation_sense	2.0	2.1		S	S
	-location self	2.0	2.1		S	S
	-location parent	2.0	2.1		S	S
load_upf		2.0	2.1		S	S
	-scope	2.0	2.1		S	S
set_scope		2.0	2.1		S	S
	Instance	2.0	2.1		S	S
begin_power_model			2.1		U	S
	power_model_name		2.1		U	S
	-for model_list		2.1		U	S

## Virtuoso Power Manager User Guide

### 1801 Support in Power Manager

Command	Options	Valid in IEEE 1801 Version		Comments	Support for 1801 Import	Support for 1801 Export
add_power_state			2.1		U	S
	-state		2.1		U	S
	-supply_expr		2.1		U	S
	-logic_expr		2.1		U	S
	-simstate		2.1		U	S
end_power_model			2.1		U	S

## 1801 Special Cell Definition Command Support

The following table lists all the 1801 special cell definition commands and explains how they are supported in the 1801 import and export processes of Power Manager. All supported commands are indicated with an *S* and the unsupported commands with a *U*.

Command	Options	Valid in IEEE 1801 Version		Comments	Support for 1801 Import	Support for 1801 Export
define_isolation_cell		2.0	2.1		S	S
	-cells	2.0	2.1		S	S
	-power	2.0	2.1		S	S
	-ground	2.0	2.1		S	S
	-enable	2.0	2.1		S	S
	-power_switchable	2.0	2.1		S	S
	-ground_switchable	2.0	2.1		S	S

## Virtuoso Power Manager User Guide

### 1801 Support in Power Manager

Command Options	Valid in IEEE 1801 Version		Comments	Support for 1801 Import	Support for 1801 Export	
define_level_shifter_cell	2.0	2.1		S	S	
input_voltage_range	2.0	2.1		S	S	
	-output_voltage_range	2.0	2.1		S	S
	-direction	2.0	2.1		S	S
	-input_power_pin	2.0	2.1		S	S
	-output_power_pin	2.0	2.1		S	S
	-input_ground_pin	2.0	2.1		S	S
	-output_ground_pin	2.0	2.1		S	S
	-ground	2.0	2.1		S	S
	-power	2.0	2.1		S	S
-enable	2.0	2.1		S	S	
define_power_switch_cell	2.0	2.1		S	S	
-cells	2.0	2.1		S	S	
	-type	2.0	2.1		S	S
	-stage_1_enable	2.0	2.1		S	S
	-stage_1_output	2.0	2.1		S	S
	-power_switchable	2.0	2.1		S	S
	-power	2.0	2.1		S	S
	-ground_switchable	2.0	2.1		S	S
	-ground	2.0	2.1		S	S

**Virtuoso Power Manager User Guide**  
1801 Support in Power Manager

---

## Customized Commands

define_power_switch_instance		2.0	2.1		S	S
	-instances	2.0	2.1		S	S
	-in_cell					
	-type	2.0	2.1		S	S
	-stage_1_enable	2.0	2.1		S	S
	-stage_2_enable	2.0	2.1		S	S
	-stage_1_output	2.0	2.1		S	S
	-power_switchable	2.0	2.1		S	S
	-power	2.0	2.1		S	S
	-ground_switchable	2.0	2.1		S	S
	-ground	2.0	2.1		S	S
define_isolation_instance		2.0	2.1		S	S
	-instances	2.0	2.1		S	S
	-in_cell					
	-type	2.0	2.1		S	S
	-enable	2.0	2.1		S	S
	-clamp_cell	2.0	2.1		S	S
	-no_enable	2.0	2.1		S	S
	-valid_location	2.0	2.1		S	S
	-power_switchable	2.0	2.1		S	S
	-power	2.0	2.1		S	S
	-ground_switchable	2.0	2.1		S	S
	-ground	2.0	2.1		S	S
define_level_shifter_instance		2.0	2.1		S	S
	-instances	2.0	2.1		S	S
	-in_cell					

## Virtuoso Power Manager User Guide

### 1801 Support in Power Manager

-input_voltage_range	2.0	2.1		S	S
-output_voltage_range	2.0	2.1		S	S
-direction	2.0	2.1		S	S
-input_power_pin	2.0	2.1		S	S
-output_power_pin	2.0	2.1		S	S
-input_ground_pin	2.0	2.1		S	S
-output_ground_pin	2.0	2.1		S	S
-ground	2.0	2.1		S	S
-power	2.0	2.1		S	S
-enable	2.0	2.1		S	S
-clamp_cell	2.0	2.1		S	S
- ground_input_voltage_ range	2.0	2.1		S	S
- ground_output_voltage_ range	2.0	2.1		S	S
-valid_location	2.0	2.1		S	S

## Liberty Attributes Support

The following table lists all the supported Liberty attributes and explains how they are supported in the 1801 export processes of the Power Manager. All supported commands are indicated with an S and the unsupported commands with a U.

Attribute	Valid in Liberty Versions		Comments	Support for Export Liberty Power Model
is_macro_cell	2014.09	2017.06		S
voltage_map	2014.09	2017.06		S

## Virtuoso Power Manager User Guide

### 1801 Support in Power Manager

Attribute	Valid in Liberty Versions		Comments	Support for Export Liberty Power Model
pg_pin	2014.09	2017.06		S
pg_type	2014.09	2017.06		S
direction	2014.09	2017.06		S
switch_function	2014.09	2017.06		S
related_power	2014.09	2017.06		S
is_isolated	2014.09	2017.06		S
isolation_enable_conditi on	2014.09	2017.06		S
power_down_function	2014.09	2017.06		S
switch_pin	2014.09	2017.06		S
is_analog	2014.09	2017.06		S

---

# **Virtuoso Power Manager Forms**

---

This appendix describes the Virtuoso Power Manager forms as they appear in the GUI.

## Add 1801 File Binding Form

Adds a cell and binds it to its existing 1801 power intent file.

---

Field Name	Description
<i>Cell</i>	Specifies the cell to be registered for binding.
<i>1801 File</i>	Specifies the name of the 1801 file for binding.

---

### ***Related Topic***

[Miscellaneous Settings](#)

## Add Device Form

Registers the device type from a specific library and cell.

---

<b>Field Name</b>	<b>Description</b>
<i>Device Type</i>	Specifies the types of devices available in the design.
<i>Library</i>	Specifies the library of the selected device type.
<i>Cells</i>	Specifies the cell of the selected device type.

---

### ***Related Topic***

[Registering Device and Cell](#)

## Add Port Attributes Form

Adds the attributes of a port. These attributes override those extracted by the tool during supply tracing.

---

<b>Field Name</b>	<b>Description</b>
<i>Ports</i>	Specifies the list of the ports to be added.
<i>Exclude Ports</i>	Specifies the ports to be excluded during registration.
<i>Driver Supply Set</i>	Specifies the driver supply set.
<i>Receiver Supply Set</i>	Specifies the receiver supply set.
<i>Analog Port</i>	Identifies the port or list of ports as analog. These have an associated <code>is_analog</code> attribute in the extracted 1801 or exported macro Liberty model.
<i>Unconnected Port</i>	Identifies the port or list of ports as unconnected. These have an associated <code>is_unconnected</code> attribute in the extracted 1801 file or exported macro Liberty model.
<i>Feedthrough Port</i>	Identifies the port or list of ports as feedthrough. These have an associated <code>short</code> attribute in the extracted 1801 or exported macro Liberty model.

---

### ***Related Topic***

[Registering Port Attributes](#)

## Add Power Domain Form

Registers power domains corresponding to the supply sets with the required attributes. This includes supply sets associated with the power domain along with the elements that constitute the power domain.

---

<b>Field Name</b>	<b>Description</b>
<i>Power Domain</i>	Specifies the name of the power domain to be registered.
<i>Primary Supply</i>	Specifies the supply sets associated with the power domain.
<i>Elements</i>	Specifies the elements of the power domain.
<i>Exclude Elements</i>	Specifies the elements to be excluded from the power domain.
<i>Include Scope</i>	Specifies whether the power domain should a top-level scope. All the elements at the current level and the levels below fall in the scope of this power domain.

---

### ***Related Topic***

[Registering Supply Set and Power Domain](#)

## Add Supply Nets Form

Lets you specify the supply nets for the Power Manager setup.

---

<b>Field Name</b>	<b>Description</b>
<i>Filter</i>	Filters the list of supply nets to limit the search scope.
<i>Add Nets</i>	Adds the user-specified supply nets.
<i>Net Type</i>	Specifies the type of the supply or ground net.
<i>Voltage</i>	Specifies the voltage value of the supply nets.
<i>External Switch Type</i>	Specifies whether the supply net is externally switchable.

---

### ***Related Topic***

[Registering Name-Based Supply Nets](#)

## Add Supply Sets Form

Adds supply sets with the required attributes. This includes registering the supply nets along with ground nets.

---

<b>Field Name</b>	<b>Description</b>
<i>Supply Set</i>	Specifies the various types of nets based on the substrate.
<i>Power</i>	
<i>Ground</i>	
<i>Pwell</i>	
<i>Nwell</i>	
<i>DeepPwell</i>	
<i>DeepNwell</i>	

---

### ***Related Topic***

[Registering Supply Set and Power Domain](#)

## Add Supply State Form

Adds you specify the supply states along with the voltage values.

---

Field Name	Description
<i>Get Default Supply State</i>	Populates default supply states. The default supply state has all the registered supply voltages from the <i>Registered Supply Nets</i> table and populates all of them in the form with value as 'OFF'.
<i>Supply State</i>	Specifies a user-defined supply state name. Each supply state consists of combinations of different supply voltages and their corresponding voltage values.
<i>Voltage</i>	Specifies the supply voltages that are registered in the setup on the Supply Nets tab or new.
<i>Value</i>	Specifies the supply voltage values corresponding to each supply voltage. This information is derived from the supply voltage values registered in the <i>Supply Nets</i> table in the setup. Each supply voltage comprises an OFF voltage value, which means that there is no deterministic voltage value for that supply in the current supply state. You can also specify a user-defined supply voltage value for supply voltage.

---

### ***Related Topic***

[Performing In-Design Checks](#)

## Export Liberty Model Form

Exports the power intent specified for the design as a Liberty power model template.

---

Field Name	Description
<i>Library</i>	Specifies the library of the cellview from which the power intent is exported.
<i>Cell</i>	Specifies the cell of the cellview from which the power intent is exported.
<i>View</i>	Specifies the view of the cellview from which the power intent is exported.
<i>Liberty File</i>	Specifies the name of the file for exporting the Liberty power model.  <b>Note:</b> The file path from the last session is retained.
<i>Overwrite Existing File</i>	Select the check box if you want the latest changes to be saved in the same Liberty file.

---

### ***Related Topic***

[Exporting Liberty Power Model](#)

## Export Power Intent Form

Imports the power intent to the currently open cellview from the specified 1801 file.

---

Field Name	Description
<i>Library</i>	Specifies the library of the cellview from which the power intent is exported.
<i>Cell</i>	Specifies the cell of the cellview from which the power intent is exported.
<i>View</i>	Specifies the view of the cellview from which the power intent is exported.
<i>1801 File</i>	Specifies the name of the file for exporting the 1801 power model.  <b>Note:</b> The file path from the last session is retained.
<i>Overwrite Existing File</i>	Select the check box if you want the latest changes to be saved in the same 1801 file.

---

### ***Related Topic***

[Exporting 1801 Design Model](#)

## Generate Signal Information Form

Lets you specify the file that contains the signal information for the given cellview.

---

Field Name	Description
<i>Library</i>	Specifies the library for which the signal information is to be generated.
<i>Cell</i>	Specifies the cell for which the signal information generated.
<i>View</i>	Specifies the view name for which the signal information generated.
<i>Signal Information File</i>	Specifies the name of the file that contains the signal information.  The file path from the last session is retained.

---

### ***Related Topic***

[Generating Signal Information](#)

## Import Power Intent Form

Imports the power intent to the currently open cellview from the specified 1801 file.

---

Field Name	Description
<i>Library</i>	Specifies the library of the cellview to which the power intent is imported.
<i>Cell</i>	Specifies the cell of the cellview to which the power intent is imported.
<i>View</i>	Specifies the view of the cellview to which the power intent is imported.
<i>View List</i>	Specifies the switch view list sequence as mentioned in the setup.
<i>1801 File</i>	Specifies the name of the file to import the power intent for the design.  <b>Note:</b> The file path from the last session is retained.
<i>Resolve Top netSets</i>	Select the check box if you do not want the global net to be created along with the associated supply ports defined in the input 1801 file. A local net is created that is associated to each supply port created in the schematic. This mode can be used during the 1801 import for IP integration and extract power intent at the top level.  Deselect the check box if you want a global net expression to be created instead of a local net that is associated with supply ports. Also, corresponding to each unique supply net that is defined in the 1801 file, pins are created. The pin creation is controlled by <code>createExtractionLogFile</code> .

### ***Related Topics***

[Importing Power Intent](#)

[createExtractionLogFile](#)

## Load Violations Form

Lets you specify the cellview and review its design violations in the Annotation Browser.

---

Field Name	Description
<i>Scope</i>	Specifies whether to run the checks on the complete design or the currently descended hierarchical instance of the top cellview.
<i>Library</i>	Specifies the library of the design that has violations.
<i>Cell</i>	Specifies the cell of the design that has violations.
<i>View</i>	Specifies the view name of the design that has violations.
<i>Instance Path</i>	Specifies the path to the currently descended hierarchical instance on which the checks are to be run. This field appears only when the <i>Hierarchical Instance</i> option is selected for the <i>Scope</i> field.
<i>Violations File</i>	Specifies the name of the file that will be uploaded to view the design violations.

---

### ***Related Topic***

[Performing In-Design Checks](#)

## Power Manager Setup Form

Use the Power Manager Setup form to specify inputs for user-defined settings though registration. The form contains the following tabs.

---

Tab	Description
<a href="#"><u>Supply Nets</u></a>	Lets you register certain names or regular expressions as names of power nets or ground nets.

## Virtuoso Power Manager User Guide

### Virtuoso Power Manager Forms

Tab	Description
<u>Libraries</u>	Lets you register the libraries-related information for reading the standard and special cells modeling information.
<u>Devices</u>	Lets you register the device and terminal related information for reading the device type and its topology in the design.
<u>In-Design Checks</u>	Lets you define the severity of reporting of a set of predefined and configurable circuit checks and supply states to set multiple voltages for efficient power management.
<u>Export</u>	Lets you register a power net and a ground net from the pair defined explicitly in the setup as a supply set and the associated power domain and port attributes.
<u>Miscellaneous</u>	Lets you specify some generic settings.

## Supply Nets

The following table describes the fields available on the *Supply Nets* tab of the Power Manager Setup form.

Section	Description
<i>Registered Supply Nets</i>	Specifies names as names of power nets or ground nets.
<i>Regular Expression Based Registration</i>	Specifies regular expressions for nets in the <i>Power Nets</i> , <i>Ground Nets</i> , <i>Pwell Nets</i> , <i>Nwell Nets</i> , <i>Deep Pwell Nets</i> , and <i>Deep Nwell Nets</i> fields.
<i>Excluded Nets</i>	Specifies names or regular expressions for excluded nets in the <i>Names and Regular Expressions</i> fields.
<i>Monitor Nets</i>	Specifies names or regular expressions for monitor nets in the <i>Names and Regular Expressions</i> fields.
<i>Supply NetSet Properties Prefix</i>	Specifies netSet properties prefix for nets in the <i>Power Nets</i> , <i>Ground Nets</i> , <i>Pwell Nets</i> , <i>Nwell Nets</i> , <i>Deep Pwell Nets</i> , and <i>Deep Nwell Nets</i> fields.

## Virtuoso Power Manager User Guide

### Virtuoso Power Manager Forms

---

### Libraries

The following table describes the fields available on the *Libraries* tab of the Power Manager Setup form.

---

Section	Description
<i>Liberty/Tech Files</i>	Specifies a list of Liberty model library files.
<i>1801 File Binding</i>	Specifies a list of 1801 special cell definition library files.
<i>Reference Library Cells</i>	Specifies the instances of any library or a particular cell in a design, apart from the Liberty cell, as reference libraries.
<i>MLDB Libraries</i>	Specifies project library that can be stored in an Model Library database (MLDB).

---

### Devices

The following table describes the fields available on the *Devices* tab of the Power Manager Setup form.

---

Field	Description
<i>Library Name</i>	Specifies the library to list the cells that will be registered as various device types.
<i>Category</i>	Specifies the types of cells in the specified library.
<i>Cells</i>	Specifies the list of cells that are available to be registered as various device types.
<i>Device Type</i>	Specifies the types of devices that can be used for registering the cells in a design.
<i>Terminals</i>	Specifies the list of device terminals of the cell, which has been already registered, for registration.

---

# Virtuoso Power Manager User Guide

## Virtuoso Power Manager Forms

---

### In-Design Checks

The following table describes the fields available on the *In-Design Checks* tab of the Power Manager Setup form.

---

Field/Section	Description
<i>Checks Categories</i>	Specifies the severity level of the results reported for the <i>Level Shifter</i> , <i>Isolation</i> , and <i>Bulk</i> checks and provides the flexibility to add tolerance for power and ground rail supply net voltage values for level shifter checks.
<i>Filters</i>	Specifies filter patterns to filter some of the error and warning messages.
<i>Supply States</i>	Specifies supply states in a design. Use the <a href="#">Add Supply State</a> form.
<i>Use Supply States</i>	Provides a choice to use supply states in a design.
<i>Similar Violations Limit</i>	Defines the maximum number of violations that are similar and should be reported. The default value is 1. If the value is 0, all similar violations are reported.
<i>Violations for ports without attributes</i>	Performs checks for the boundary ports that do not have any associated attributes, such as driver or receiver supply sets. By default, in-design checks do not report violations at the boundary ports unless information about the related power and ground nets of the boundary ports is specified using the registration information.
<i>Violations for all net voltages</i>	Reports violations for all net voltages specified in various supply states or different voltage values registered in the <i>Registered Supply Nets</i> table provided in the setup.
<i>Isolation violations for always-on to switched supply crossings:</i>	Reports violations for a missing isolation cell at the always-on to switched supply crossings.

---

# Virtuoso Power Manager User Guide

## Virtuoso Power Manager Forms

---

### Export

The following table describes the fields available on the *Export* tab of the Power Manager Setup form.

---

Section/Field	Description
<i>Supply Sets</i>	Specifies a list of supply sets by making a power net and a ground net from the pair defined explicitly in the setup as a supply set.
<i>Power Domains</i>	Specifies a list of power domains associated with the different sections of the design addressed by a specific supply set.
<i>Domain Name Prefix</i>	Specifies the prefix of the names being assigned to the power domains.
<i>Port Attributes</i>	Specifies a list of ports to avoid ambiguities during the 1801 power intent extraction or the In-Design checks to associate the boundary ports to a power domain.
<i>Consider inputOutput terms for internal power criterion</i>	Identifies supply nets, meeting the LDO net detection criteria, even when the nets are connected to <code>inout pin/term</code> .
<i>Consider inputOutput terms for monitor power criterion</i>	Identifies supply nets, meeting the monitor net detection criteria, even when the nets are connected to <code>inout pin/term</code> .
<i>Consider symmetrical source and drain for supply tracing</i>	Defines a port with a predefined supply set or power domain that can be checked for the correct or compatible connection at the receiver side.
<i>Use anonymous supply for top level ports</i>	Enables the use of an anonymous supply for the top-level ports instead of the default supply set.

---

# Virtuoso Power Manager User Guide

## Virtuoso Power Manager Forms

---

### Miscellaneous

The following table describes the fields available on the *Miscellaneous* tab of the Power Manager form.

---

Field	Description
<i>Delimiter</i>	Specifies specific notations for redirect netSets created during the 1801 import flow, automatically generated supply set and power domain names, and so on
<i>Switch View List</i>	Controls the order of the traversal of a design hierarchy during power intent extraction.
<i>Stop View List</i>	Defines the stop point where the design traversal must be stopped by the extractor during power intent extraction
<i>Use Signal Type</i>	Uses the <code>sigType</code> attribute of nets for detecting the supply nets during power intent extraction.
<i>Load Setup From Environment</i>	Loads the setup information from the environment. The project-level settings are considered as a part of the final setup.
<i>Use Setup Changes From Environment</i>	Uses setup changes from the environment setup. Any changes that are done to the project-level settings are read and updated.

---

### **Related Topics**

[Registering Name-Based Supply Nets](#)

[Registering Regular Expressions-Based Supply Nets](#)

[Registering Libraries](#)

[Registering Device and Cell](#)

[Registering Supply Set and Power Domain](#)

[Miscellaneous Settings](#)

## Prepare CLP Form

Lets you specify the 1801 file, Verilog netlist, and CLP dofile at the specified path for the CLP run.

---

<b>Field Name</b>	<b>Description</b>
<i>1801 File</i>	Specifies a 1801 file for the CLP run. This field is optional and only required if you want the tool to use a specific 1801 file for the run. If the field is blank, you need to first extract the power intent to ensure that a new 1801 file is available to be exported and placed in the Prepare CLP form.
<i>Liberty Files</i>	Specifies a Liberty file for the CLP run. This field is optional and only required if you want to include a Liberty file that is not a part of the setup. If the setup already has all the required Liberty files, these files are referred from the setup.
<i>Netlist Control File</i>	Specifies a control file for netlisting. This file contains flags used for netlist customization. The netlist customizations ensure that the power or ground information is available in the netlist in the desired format.
<i>Netlist View List</i>	Specifies a user switch view name list that is to be used for netlisting for the hierarchical designs.
<i>Output Directory</i>	Specifies the path to store a 1801 file, netlist, and dofile.
<i>Overwrite Existing Directory</i>	Select this check box if you want to overwrite the existing output directory. If this option is deselected, the output directory is created with a unique name on each successive run.

---

### ***Related Topic***

[Preparing and Running CLP](#)

## Run CLP Form

Lets you run CLP by using the files created during CLP preparation for power verification.

---

<b>Field Name</b>	<b>Description</b>
<i>dofile Path</i>	Specifies the path of the dofile.
<i>Run Directory</i>	Specifies the CLP run directory. The default value for this field is the current working directory.
<i>Command</i>	Specifies the command for running CLP from command line.

---

### ***Related Topic***

[Preparing and Running CLP](#)

## Run In-Design Checks

Runs In-Design checks and generates the log and violations files in the foreground.

---

Field Name	Description
<i>Scope</i>	Specifies whether to run the checks on the complete design or the currently descended hierarchical instance of the top cellview.
<i>Library</i>	Specifies the library of the cellview to be checked.
<i>Cell</i>	Specifies the cell of the cellview to be checked.
<i>View</i>	Specifies the view name of the cellview to be checked.
<i>Instance Path</i>	Specifies the path to the currently descended hierarchical instance on which the checks are to be run. This field appears only when the <i>Hierarchical Instance</i> option is selected for the <i>Scope</i> field.
<i>Log File</i>	Specifies the name of the log file to be generated at the end of checks.  The file path from the last session is retained.
<i>Violations File</i>	Specifies the name of the file that will contain the design violations at the end of checks.  The file path from the last session is retained.

---

### ***Related Topic***

[Checking a Design in Foreground Mode](#)

## Run In-Design Checks (Non-Blocking)

Runs In-Design checks and generates the log and violations files in the background.

---

Field Name	Description
<i>Scope</i>	Specifies whether to run the checks on the complete design or the currently descended hierarchical instance of the top cellview.
<i>Library</i>	Specifies the library of the cellview to be checked.
<i>Cell</i>	Specifies the cell of the cellview to be checked.
<i>View</i>	Specifies the view name of the cellview to be checked.
<i>Instance Path</i>	Specifies the path to the currently descended hierarchical instance on which the checks are to be run. This field appears only when the <i>Hierarchical Instance</i> option is selected for the <i>Scope</i> field.
<i>Run Directory</i>	Specifies the name of the run directory where the results are saved.
<i>Overwrite Existing Directory (directory will be removed)</i>	Overwrites any existing run directory.
<i>Run Status</i>	Specifies the stage and time of completion.
<i>Load Violations</i>	Opens the file containing the design violations at the end of checks.
<i>View Run Log</i>	Opens the replay log file for the background process.
<i>View Audit Log</i>	Opens the audit log for the In-Design Checks run.

---

### **Related Topic**

[Checking a Design in Background Mode](#)